

Mark X Description Function is supported.

Special Function

Automaker	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations	Special Functions
SKODA	EUROPE	2007-2010	Skoda Octavia			BXX - ENG		x	x	x	x	x	1.Adapt throttle valve control part 2.Adapt idling speed 3.Reset learned values 4.Reduce fuel pressure
SKODA	EUROPE	2007-2010	Skoda Octavia			6-shift automatic transmission 09G		x	x	x	x	x	1.Forced downshift self-adaptation
SKODA	EUROPE	2007-2010	Skoda Octavia			Brake ABS Mark 70		x	x	x	x	x	1.Calibration steering angle sensor 2.Bleeding
SKODA	EUROPE	2007-2010	Skoda Octavia			Instr. Clstr		x	x	x	x	x	1.Maintenance reminding lamp 2.Adapt language
SKODA	EUROPE	2007-2010	Skoda Octavia			Immobilizer		x	x	x	x	x	1.Immobilizer, enable immobilizer
SKODA	EUROPE	2007-2010	Skoda Octavia			Automatic headlight illumination distance adjustment device		x	x	x	x	x	1.Identification services 2.Code control unit 3.Basic setting
SKODA	EUROPE	2007-2010	Skoda Octavia			MANUAL A/C		x	x	x	x	x	1.Throttle motor foundation setting
SKODA	EUROPE	2007-2010	Skoda Octavia			Airbag		x	x	x	x	x	1.Seat occupation identification resetting 2.Lock or activate airbag and seat belt pretensioner

Mark
X Description
Function is supported.

SKODA	EUROPE	2007-2010	Skoda Octavia			driver's side door of electronic devices		x	x	x	x	x	1.Identification services 2.Code control unit
SKODA	EUROPE	2007-2010	Skoda Octavia			BYJ - ENG		x	x	x	x	x	1.Adapt throttle valve control part 2.Adapt idling speed 3.Reset learned values 4.Reduce fuel pressure
SKODA	EUROPE	2007-2010	Skoda Octavia			CDF - ENG		x	x	x	x	x	1.Adapt throttle valve control part 2.Adapt idling speed 3.Reset learned values 4.Reduce fuel pressure
SKODA	EUROPE	2007-2010	Skoda Octavia			brake ABS/EDS/ASR/ESP Mark 60		x	x	x	x	x	1.Calibration steering angle sensor 2.Bleeding
SKODA	EUROPE	2007-2010	Skoda Octavia			CGZ - ENG		x	x	x	x	x	1.Adapt throttle valve control part 2.Adapt idling speed 3.Reset learned values 4.Reduce fuel pressure
SKODA	EUROPE	2008-2010	Skoda Fabia			CDD && CDE - ENG		x	x	x	x	x	1.Adapt throttle valve control part 2.Adapt idling speed 3.Reset learned values 4.Reduce fuel pressure
SKODA	EUROPE	2008-2010	Skoda Fabia			6-shift automatic transmission 09G		x	x	x	x	x	1.Forced downshift self-adaptation
SKODA	EUROPE	2008-2010	Skoda Fabia			Brake System		x	x	x	x	x	1.Calibration steering angle sensor

Mark
X Description
Function is supported.

														2.Bleeding
SKODA	EUROPE	2008-2010	Skoda Fabia			MANUAL A/C		x	x	x	x	x		1.Throttle motor foundation setting
SKODA	EUROPE	2009-2010	Skoda Superb			6-shift automatic transmission 09G		x	x	x	x	x		1.Forced downshift self-adaptation
SKODA	EUROPE	2009-2010	Skoda Superb			Brake ABS Mark 70		x	x	x	x	x		1.Calibration steering angle sensor 2.Bleeding
SKODA	EUROPE	2009-2010	Skoda Superb			brake ABS/EDS/ASR/ESP Mark 60 EC		x	x	x	x	x		1.Calibration steering angle sensor 2.Bleeding
SKODA	EUROPE	2009-2010	Skoda Superb			With dynamic AFS adjustment device headlight Illumination distance		x	x	x	x	x		1.Identification services 2.Code control unit 3.Basic setting
SKODA	EUROPE	2009-2010	Skoda Superb			Airbag		x	x	x	x	x		1.Seat occupation identification resetting 2.Lock or activate airbag and seat belt pretensioner
SKODA	EUROPE	2009-2010	Skoda Superb			driver's side door control unit		x	x	x	x	x		1.Identification services 2.Code control unit
SKODA	EUROPE	2010-2011	New Skoda Octavia			CLR - ENG		x	x	x	x	x		1.Adapt throttle valve control part 2.Adapt idling speed 3.Reset learned values 4.Reduce fuel pressure
SKODA	EUROPE	2010-2011	New Skoda Octavia			6-shift automatic transmission 09G		x	x	x	x	x		1.Forced downshift self-adaptation
SKODA	EUROPE	2010-2011	New Skoda Octavia			brake ABS/EDS/ASR/ESP Mark 60 EC		x	x	x	x	x		1.Calibration steering angle sensor 2.Bleeding

Mark X Description Function is supported.

SKODA	EUROPE	2010-2011	New Skoda Octavia			With dynamic AFS adjustment device headlight Illumination distance		x	x	x	x	x	1. Identification services 2. Code control unit 3. Basic setting
SKODA	EUROPE	2010-2011	New Skoda Octavia			Airbag		x	x	x	x	x	1. Seat occupation identification resetting 2. Lock or activate airbag and seat belt pretensioner
SKODA	EUROPE	2010-2011	New Skoda Octavia			driver's side door of electronic devices		x	x	x	x	x	1. Identification services 2. Code control unit
SKODA	EUROPE	2010-2011	New Skoda Octavia			CGZ - ENG		x	x	x	x	x	1. Adapt throttle valve control part 2. Adapt idling speed 3. Reset learned values 4. Reduce fuel pressure
SKODA	EUROPE	2010-2011	New Skoda Octavia			CFBA-Tsi ENG		x	x	x	x	x	1. Adapt throttle valve control part 2. Adapt idling speed 3. Reset learned values 4. Reduce fuel pressure
SKODA	EUROPE	2010-2011	New Skoda Octavia			7 - speed dual-clutch gearbox OAM		x	x	x	x	x	1. Forced downshift self-adaptation
SKODA	EUROPE				Experts function	Instrument reset service							x
SKODA	EUROPE				Experts function	Adapt throttle valve control module							x
SKODA	EUROPE				Experts	SRS reset service							x

Mark X Description Function is supported.

					function								
SKODA	EUROPE				Experts function	Read PIN(III IMMO from Engine)							x
SKODA	EUROPE				Experts function	Read PIN(II IMMO from immobilizer box)							x
SKODA	EUROPE				Experts function	Read PIN(II IMMO from instrument)							x
SKODA	EUROPE				Experts function	Removing and installing brake pads							x

Basic Function

Automaker	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations
SKODA	EUROPE	2007-2010	Skoda Octavia			BXX - ENG		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			6-shift automatic transmission 09G		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			Brake ABS Mark 70		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			Electromechanical Steering device		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			Instr. Clstr		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			Immobilizer		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			Diagnosis - the interface of the data bus		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			Steering Wheel system		x	x	x	x	x

Mark X Description Function is supported.

SKODA	EUROPE	2007-2010	Skoda Octavia			Automatic headlight illumination distance adjustment device		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			Phone		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			Vehicle electronic management system control unit		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			Radio		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			MANUAL A/C		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			FULL AUTO AIR/CON.		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			Airbag		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			Passenger side door of electronic devices		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			driver's side door of electronic devices		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			Rear left door electronic unit		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			Rear right door electronic unit		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			comfort system central control module		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			BYJ - ENG		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			CDF - ENG		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			brake ABS/EDS/ASR/ESP Mark 60		x	x	x	x	x
SKODA	EUROPE	2007-2010	Skoda Octavia			CGZ - ENG		x	x	x	x	x
SKODA	EUROPE	2008-2010	Skoda Fabia			CDD && CDE - ENG		x	x	x	x	x

Mark
X Description
Function is supported.

SKODA	EUROPE	2008-2010	Skoda Fabia			6-shift automatic transmission 09G		x	x	x	x	x
SKODA	EUROPE	2008-2010	Skoda Fabia			Brake System		x	x	x	x	x
SKODA	EUROPE	2008-2010	Skoda Fabia			Body control unit (BCM)		x	x	x	x	x
SKODA	EUROPE	2008-2010	Skoda Fabia			MANUAL A/C		x	x	x	x	x
SKODA	EUROPE	2008-2010	Skoda Fabia			Semi-automatic air condition		x	x	x	x	x
SKODA	EUROPE	2008-2010	Skoda Fabia			door controller		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			6-shift automatic transmission 09G		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			Brake ABS Mark 70		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			brake ABS/EDS/ASR/ESP Mark 60 EC		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			Electromechanical Steering device		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			Radio		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			radio navigation system(RNS)		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			telephone Multimedia		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			Body controller		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			Steering Wheel system		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			Parking Assistance		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			With dynamic AFS adjustment device headlight illumination distance		x	x	x	x	x

Mark
X Description
Function is supported.

SKODA	EUROPE	2009-2010	Skoda Superb			Diagnosis - the interface of the data bus		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			Airbag		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			Seat adjustment, passenger side		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			Co - driver's side door control unit		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			driver's side door control unit		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			rear left door control unit		x	x	x	x	x
SKODA	EUROPE	2009-2010	Skoda Superb			Rear right door control unit		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			CLR - ENG		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			6-shift automatic transmission 09G		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			brake ABS/EDS/ASR/ESP Mark 60 EC		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			Electromechanical Steering device		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			Steering Wheel system		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			Radio		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			Radio navigation system (RNS510)		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			Parking Assistance(rear PDC)		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			telephone Multimedia		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			Body controller		x	x	x	x	x

Mark X Description Function is supported.

SKODA	EUROPE	2010-2011	New Skoda Octavia			With dynamic AFS adjustment device headlight illumination distance		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			Airbag		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			Passenger side door of electronic devices		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			driver's side door of electronic devices		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			Rear left door electronic unit		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			Rear right door electronic unit		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			CGZ - ENG		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			CFBA-Tsi ENG		x	x	x	x	x
SKODA	EUROPE	2010-2011	New Skoda Octavia			7 - speed dual-clutch gearbox OAM		x	x	x	x	x
SKODA	EUROPE				Experts function	Instrument reset service						
SKODA	EUROPE				Experts function	Adapt throttle valve control module						
SKODA	EUROPE				Experts function	SRS reset service						
SKODA	EUROPE				Experts function	Read PIN(III IMMO from Engine)						
SKODA	EUROPE				Experts function	Read PIN(II IMMO from immobilizer box)						
SKODA	EUROPE				Experts function	Read PIN(II IMMO from instrument)						
SKODA	EUROPE				Experts function	Removing and installing brake pads						