

SPX. AUTOBOSS TECH. INC.
Autoboss Scanner Function List

Basic Function List

CHANGHE

Autoboss Scanner: V30
 Version: V3.2
 Date: 2008-10-16

vehicle	system	Control unit version	Read fault code	Erase fault code	Actual values	System status	Actuation	Anti-theft status
Minivan	CH7131A(DA471 Q)	√	√	√	√	√	√	
	Delphi ENG	√	√	√	√	√	√	Immobilizer status
	UAES1	√	√	√	√	√	√	Idle Initialization Distributor Adjustment
Ideal	DA465(Denso)		√	√	√	√		
	DA465(UAES M154)	√	√	√	√	√	√	√
	CH7131(C13DC)	√	√	√	√	√	√	
	CH711A(DA468Q)	√	√	√	√	√	√	
	CH7131A(DA471 Q)	√	√	√	√	√	√	
	UAES2 M7		√	√	√		√	Distributor Adjustment
	UAES1	√	√	√	√	√	√	Idle Initialization Distributor Adjustment
	ABS	√	√	√	√	√	√	
	SRS		√	√	√			Read ID