

Basic Function List

LIFAN

Autoboss Scanner: V30
 Version: V2.1
 Date: 2008-10-13

Vehicle	System	Read DTC	Clear DTC	Read Datastream	Actuator	Version	Output contrl
LIFAN	DELPHI ENGINE SYSTEM	√	√	√	√		√
	TAIKE ENGINE SYSTEM	√	√	√	√		
	WANXIANG ABS	√	√	√	√	√	
	ABS(AP)	√	√	√	√	√	
	IMMOBILIZER	√	√	√	√		
	AIRBAG JH-ACU-4A	√	√	√			

Special Function List

LIFAN

Autoboss Scanner: V30
Version: V2.1
Date: 2008-10-13

Vehicle	System	Description
LIFAN	IMMOBILIZER	<ol style="list-style-type: none">1. Input PIN code;2. Delete key;3. Self-learn programming key;4. Read immobilizer to EMS;5. Read EMS to immobilizer;6. Immobilizer reset.