

How to read this list:	
Mark	Description
√	Function is supported.
*	Function is added or developed newly

Asia INFINITI V4.5 --- Function List										
Menu					Functions					
Brand	Model	Vehicle Type	Year	System	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations	Special Functions
INFINITI	INFINITI EX35	J50	01/2008	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI EX35	J50	01/2008	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI EX35	J50	01/2008	ABS	√	√	√	*	√	
INFINITI	INFINITI EX35	J50	01/2008	AIRBAG	√	√	√			
INFINITI	INFINITI EX35	J50	01/2008	BCM	√	√	√	√	√	
INFINITI	INFINITI EX35	J50	01/2008	METER/M&A	√	√	√	√		
INFINITI	INFINITI EX35	J50	01/2008	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI EX35	J50	01/2008	ICC	√	√	√	√		
INFINITI	INFINITI EX35	J50	01/2008	HVAC	√	√	√	√		
INFINITI	INFINITI EX35	J50	01/2008	MULTI AV	√	√	√	√		
INFINITI	INFINITI EX35	J50	01/2008	EPS	√	√	√	√		
INFINITI	INFINITI EX35	J50	01/2008	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI EX35	J50	01/2008	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI EX35	J50	01/2008	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI EX35	J50	01/2008	e-4WD	√	√	√	√	√	

<http://www.autoboss.net>

<http://www.servicesolutions.com.cn>

INFINITI	INFINITI EX35	J50	01/2008	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI EX35	J50	01/2008	DIU	√	√	√	√		
INFINITI	INFINITI EX35	J50	01/2008	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI EX35	J50	01/2008	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI EX35	J50	01/2008	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI EX35	J50	01/2008	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI EX35	J50	01/2008	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI EX35	J50	01/2008	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI EX35	J50	01/2008	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI EX35	J50	01/2008	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI EX35	J50	01/2008	ASCD		√	√	√		
INFINITI	INFINITI EX35	J50	01/2008	HCM		√	√	√		
INFINITI	INFINITI EX35	J50	01/2008	LDW		√	√	√		
INFINITI	INFINITI EX37	J50	06/2008	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI EX37	J50	06/2008	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI EX37	J50	06/2008	ABS	√	√	√	*	√	
INFINITI	INFINITI EX37	J50	06/2008	AIRBAG	√	√	√			
INFINITI	INFINITI EX37	J50	06/2008	BCM	√	√	√	√	√	
INFINITI	INFINITI EX37	J50	06/2008	METER/M&A	√	√	√	√		
INFINITI	INFINITI EX37	J50	06/2008	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI EX37	J50	06/2008	ICC	√	√	√	√		
INFINITI	INFINITI EX37	J50	06/2008	HVAC	√	√	√	√		
INFINITI	INFINITI EX37	J50	06/2008	MULTI AV	√	√	√	√		
INFINITI	INFINITI EX37	J50	06/2008	EPS	√	√	√	√		
INFINITI	INFINITI EX37	J50	06/2008	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI EX37	J50	06/2008	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI EX37	J50	06/2008	HEAD LAMP LEVELIZER	√	√	√	√	√	

INFINITI	INFINITI EX37	J50	06/2008	e-4WD	√	√	√	√	√	
INFINITI	INFINITI EX37	J50	06/2008	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI EX37	J50	06/2008	DIU	√	√	√	√		
INFINITI	INFINITI EX37	J50	06/2008	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI EX37	J50	06/2008	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI EX37	J50	06/2008	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI EX37	J50	06/2008	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI EX37	J50	06/2008	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI EX37	J50	06/2008	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI EX37	J50	06/2008	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI EX37	J50	06/2008	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI EX37	J50	06/2008	ASCD		√	√	√		
INFINITI	INFINITI EX37	J50	06/2008	HCM		√	√	√		
INFINITI	INFINITI EX37	J50	06/2008	LDW		√	√	√		
INFINITI	INFINITI FX35/FX45	S50	06/2007	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI FX35/FX45	S50	06/2007	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI FX35/FX45	S50	06/2007	ABS	√	√	√	*	√	
INFINITI	INFINITI FX35/FX45	S50	06/2007	AIRBAG	√	√	√			
INFINITI	INFINITI FX35/FX45	S50	06/2007	BCM	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	06/2007	METER/M&A	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	06/2007	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	06/2007	ICC	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	06/2007	HVAC	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	06/2007	MULTI AV	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	06/2007	EPS	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	06/2007	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	06/2007	AIR PRESSURE MONITOR	√	√	√	√	√	

INFINITI	INFINITI FX35/FX45	S50	06/2007	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	06/2007	e-4WD	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	06/2007	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	06/2007	DIU	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	06/2007	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	06/2007	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	06/2007	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	06/2007	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	06/2007	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	06/2007	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	06/2007	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI FX35/FX45	S50	06/2007	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	06/2007	ASCD		√	√	√		
INFINITI	INFINITI FX35/FX45	S50	06/2007	HCM		√	√	√		
INFINITI	INFINITI FX35/FX45	S50	06/2007	LDW		√	√	√		
INFINITI	INFINITI FX35/FX45	S50	07/2006	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI FX35/FX45	S50	07/2006	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI FX35/FX45	S50	07/2006	ABS	√	√	√	*	√	
INFINITI	INFINITI FX35/FX45	S50	07/2006	AIRBAG	√	√	√			
INFINITI	INFINITI FX35/FX45	S50	07/2006	BCM	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	07/2006	METER/M&A	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	07/2006	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	07/2006	ICC	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	07/2006	HVAC	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	07/2006	MULTI AV	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	07/2006	EPS	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	07/2006	IPDM E/R	√	√	√	√	√	

INFINITI	INFINITI FX35/FX45	S50	07/2006	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	07/2006	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	07/2006	e-4WD	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	07/2006	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	07/2006	DIU	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	07/2006	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	07/2006	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	07/2006	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	07/2006	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	07/2006	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	07/2006	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI FX35/FX45	S50	07/2006	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI FX35/FX45	S50	07/2006	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI FX35/FX45	S50	07/2006	ASCD		√	√	√		
INFINITI	INFINITI FX35/FX45	S50	07/2006	HCM		√	√	√		
INFINITI	INFINITI FX35/FX45	S50	07/2006	LDW		√	√	√		
INFINITI	INFINITI FX35/FX50	S51	05/2008	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI FX35/FX50	S51	05/2008	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI FX35/FX50	S51	05/2008	ABS	√	√	√	*	√	
INFINITI	INFINITI FX35/FX50	S51	05/2008	AIRBAG	√	√	√			
INFINITI	INFINITI FX35/FX50	S51	05/2008	BCM	√	√	√	√	√	
INFINITI	INFINITI FX35/FX50	S51	05/2008	METER/M&A	√	√	√	√		
INFINITI	INFINITI FX35/FX50	S51	05/2008	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI FX35/FX50	S51	05/2008	ICC	√	√	√	√		
INFINITI	INFINITI FX35/FX50	S51	05/2008	HVAC	√	√	√	√		
INFINITI	INFINITI FX35/FX50	S51	05/2008	MULTI AV	√	√	√	√		
INFINITI	INFINITI FX35/FX50	S51	05/2008	EPS	√	√	√	√		

INFINITI	INFINITI FX35/FX50	S51	05/2008	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI FX35/FX50	S51	05/2008	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI FX35/FX50	S51	05/2008	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI FX35/FX50	S51	05/2008	e-4WD	√	√	√	√	√	
INFINITI	INFINITI FX35/FX50	S51	05/2008	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI FX35/FX50	S51	05/2008	DIU	√	√	√	√		
INFINITI	INFINITI FX35/FX50	S51	05/2008	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI FX35/FX50	S51	05/2008	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI FX35/FX50	S51	05/2008	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI FX35/FX50	S51	05/2008	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI FX35/FX50	S51	05/2008	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI FX35/FX50	S51	05/2008	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI FX35/FX50	S51	05/2008	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI FX35/FX50	S51	05/2008	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI FX35/FX50	S51	05/2008	ASCD		√	√	√		
INFINITI	INFINITI FX35/FX50	S51	05/2008	HCM		√	√	√		
INFINITI	INFINITI FX35/FX50	S51	05/2008	LDW		√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	07/2006	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI G35 Coupe	CV35	07/2006	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI G35 Coupe	CV35	07/2006	ABS	√	√	√	*	√	
INFINITI	INFINITI G35 Coupe	CV35	07/2006	AIRBAG	√	√	√			
INFINITI	INFINITI G35 Coupe	CV35	07/2006	BCM	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	07/2006	METER/M&A	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	07/2006	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	07/2006	ICC	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	07/2006	HVAC	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	07/2006	MULTI AV	√	√	√	√		

INFINITI	INFINITI G35 Coupe	CV35	07/2006	EPS	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	07/2006	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	07/2006	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	07/2006	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	07/2006	e-4WD	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	07/2006	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	07/2006	DIU	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	07/2006	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	07/2006	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	07/2006	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	07/2006	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	07/2006	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	07/2006	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	07/2006	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI G35 Coupe	CV35	07/2006	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	07/2006	ASCD		√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	07/2006	HCM		√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	07/2006	LDW		√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	08/2005	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI G35 Coupe	CV35	08/2005	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI G35 Coupe	CV35	08/2005	ABS	√	√	√	*	√	
INFINITI	INFINITI G35 Coupe	CV35	08/2005	AIRBAG	√	√	√			
INFINITI	INFINITI G35 Coupe	CV35	08/2005	BCM	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	08/2005	METER/M&A	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	08/2005	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	08/2005	ICC	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	08/2005	HVAC	√	√	√	√		



SERVICE SOLUTIONS

INFINITI	INFINITI G35 Coupe	CV35	08/2005	MULTI AV	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	08/2005	EPS	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	08/2005	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	08/2005	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	08/2005	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	08/2005	e-4WD	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	08/2005	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	08/2005	DIU	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	08/2005	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	08/2005	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	08/2005	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	08/2005	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	08/2005	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	08/2005	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	08/2005	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI G35 Coupe	CV35	08/2005	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	08/2005	ASCD		√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	08/2005	HCM		√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	08/2005	LDW		√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	01/2005	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI G35 Coupe	CV35	01/2005	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI G35 Coupe	CV35	01/2005	ABS	√	√	√	*	√	
INFINITI	INFINITI G35 Coupe	CV35	01/2005	AIRBAG	√	√	√			
INFINITI	INFINITI G35 Coupe	CV35	01/2005	BCM	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	01/2005	METER/M&A	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	01/2005	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	01/2005	ICC	√	√	√	√		

<http://www.autoboss.net>

<http://www.servicesolutions.com.cn>



SERVICE SOLUTIONS

INFINITI	INFINITI G35 Coupe	CV35	01/2005	HVAC	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	01/2005	MULTI AV	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	01/2005	EPS	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	01/2005	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	01/2005	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	01/2005	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	01/2005	e-4WD	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	01/2005	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	01/2005	DIU	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	01/2005	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	01/2005	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	01/2005	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	01/2005	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	01/2005	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	01/2005	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI G35 Coupe	CV35	01/2005	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI G35 Coupe	CV35	01/2005	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	01/2005	ASCD		√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	01/2005	HCM		√	√	√		
INFINITI	INFINITI G35 Coupe	CV35	01/2005	LDW		√	√	√		
INFINITI	INFINITI G35 Sedan	V36	12/2007	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI G35 Sedan	V36	12/2007	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI G35 Sedan	V36	12/2007	ABS	√	√	√	*	√	
INFINITI	INFINITI G35 Sedan	V36	12/2007	AIRBAG	√	√	√			
INFINITI	INFINITI G35 Sedan	V36	12/2007	BCM	√	√	√	√	√	
INFINITI	INFINITI G35 Sedan	V36	12/2007	METER/M&A	√	√	√	√		
INFINITI	INFINITI G35 Sedan	V36	12/2007	METER ACAMP	√	√	√	√	√	

<http://www.autoboss.net>

<http://www.servicesolutions.com.cn>



SERVICE SOLUTIONS

INFINITI	INFINITI G35 Sedan	V36	12/2007	ICC	✓	✓	✓	✓		
INFINITI	INFINITI G35 Sedan	V36	12/2007	HVAC	✓	✓	✓	✓		
INFINITI	INFINITI G35 Sedan	V36	12/2007	MULTI AV	✓	✓	✓	✓		
INFINITI	INFINITI G35 Sedan	V36	12/2007	EPS	✓	✓	✓	✓		
INFINITI	INFINITI G35 Sedan	V36	12/2007	IPDM E/R	✓	✓	✓	✓	✓	
INFINITI	INFINITI G35 Sedan	V36	12/2007	AIR PRESSURE MONITOR	✓	✓	✓	✓	✓	
INFINITI	INFINITI G35 Sedan	V36	12/2007	HEAD LAMP LEVELIZER	✓	✓	✓	✓	✓	
INFINITI	INFINITI G35 Sedan	V36	12/2007	e-4WD	✓	✓	✓	✓	✓	
INFINITI	INFINITI G35 Sedan	V36	12/2007	INTELLIGENT KEY	✓	✓	✓	✓	✓	
INFINITI	INFINITI G35 Sedan	V36	12/2007	DIU	✓	✓	✓	✓		
INFINITI	INFINITI G35 Sedan	V36	12/2007	AUTO DRIVE POS	✓	✓	✓	✓	✓	
INFINITI	INFINITI G35 Sedan	V36	12/2007	AUTO SLIDE POS	✓	✓	✓	✓	✓	
INFINITI	INFINITI G35 Sedan	V36	12/2007	PRECRASH SEATBELT	✓	✓	✓	✓		
INFINITI	INFINITI G35 Sedan	V36	12/2007	ALL MODE AWD/4WD	✓	✓	✓	✓		
INFINITI	INFINITI G35 Sedan	V36	12/2007	4WAS(MAIN)/RAS/HICAS	✓	✓	✓	✓	✓	
INFINITI	INFINITI G35 Sedan	V36	12/2007	ADAPTIVE LIGHT	✓	✓	✓	✓	✓	
INFINITI	INFINITI G35 Sedan	V36	12/2007	SMART ENTRANCE	✓	✓	✓			
INFINITI	INFINITI G35 Sedan	V36	12/2007	ACTIVE SUS	✓	✓	✓	✓		
INFINITI	INFINITI G35 Sedan	V36	12/2007	ASCD		✓	✓	✓		
INFINITI	INFINITI G35 Sedan	V36	12/2007	HCM		✓	✓	✓		
INFINITI	INFINITI G35 Sedan	V36	12/2007	LDW		✓	✓	✓		
INFINITI	INFINITI G35 Sedan	V36	12/2006	ENGINE	✓	✓	✓	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI G35 Sedan	V36	12/2006	TRANSMISSION	✓	✓	✓	*		
INFINITI	INFINITI G35 Sedan	V36	12/2006	ABS	✓	✓	✓	*	✓	
INFINITI	INFINITI G35 Sedan	V36	12/2006	AIRBAG	✓	✓	✓			
INFINITI	INFINITI G35 Sedan	V36	12/2006	BCM	✓	✓	✓	✓	✓	
INFINITI	INFINITI G35 Sedan	V36	12/2006	METER/M&A	✓	✓	✓	✓		

<http://www.autoboss.net>

<http://www.servicesolutions.com.cn>

INFINITI	INFINITI G35 Sedan	V36	12/2006	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI G35 Sedan	V36	12/2006	ICC	√	√	√	√		
INFINITI	INFINITI G35 Sedan	V36	12/2006	HVAC	√	√	√	√		
INFINITI	INFINITI G35 Sedan	V36	12/2006	MULTI AV	√	√	√	√		
INFINITI	INFINITI G35 Sedan	V36	12/2006	EPS	√	√	√	√		
INFINITI	INFINITI G35 Sedan	V36	12/2006	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI G35 Sedan	V36	12/2006	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI G35 Sedan	V36	12/2006	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI G35 Sedan	V36	12/2006	e-4WD	√	√	√	√	√	
INFINITI	INFINITI G35 Sedan	V36	12/2006	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI G35 Sedan	V36	12/2006	DIU	√	√	√	√		
INFINITI	INFINITI G35 Sedan	V36	12/2006	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI G35 Sedan	V36	12/2006	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI G35 Sedan	V36	12/2006	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI G35 Sedan	V36	12/2006	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI G35 Sedan	V36	12/2006	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI G35 Sedan	V36	12/2006	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI G35 Sedan	V36	12/2006	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI G35 Sedan	V36	12/2006	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI G35 Sedan	V36	12/2006	ASCD		√	√	√		
INFINITI	INFINITI G35 Sedan	V36	12/2006	HCM		√	√	√		
INFINITI	INFINITI G35 Sedan	V36	12/2006	LDW		√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	06/2008	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI G37 Coupe	CV36	06/2008	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI G37 Coupe	CV36	06/2008	ABS	√	√	√	*	√	
INFINITI	INFINITI G37 Coupe	CV36	06/2008	AIRBAG	√	√	√			
INFINITI	INFINITI G37 Coupe	CV36	06/2008	BCM	√	√	√	√	√	

INFINITI	INFINITI G37 Coupe	CV36	06/2008	METER/M&A	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	06/2008	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	06/2008	ICC	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	06/2008	HVAC	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	06/2008	MULTI AV	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	06/2008	EPS	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	06/2008	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	06/2008	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	06/2008	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	06/2008	e-4WD	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	06/2008	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	06/2008	DIU	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	06/2008	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	06/2008	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	06/2008	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	06/2008	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	06/2008	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	06/2008	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	06/2008	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI G37 Coupe	CV36	06/2008	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	06/2008	ASCD		√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	06/2008	HCM		√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	06/2008	LDW		√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	11/2007	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI G37 Coupe	CV36	11/2007	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI G37 Coupe	CV36	11/2007	ABS	√	√	√	*	√	
INFINITI	INFINITI G37 Coupe	CV36	11/2007	AIRBAG	√	√	√			

INFINITI	INFINITI G37 Coupe	CV36	11/2007	BCM	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	11/2007	METER/M&A	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	11/2007	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	11/2007	ICC	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	11/2007	HVAC	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	11/2007	MULTI AV	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	11/2007	EPS	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	11/2007	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	11/2007	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	11/2007	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	11/2007	e-4WD	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	11/2007	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	11/2007	DIU	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	11/2007	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	11/2007	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	11/2007	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	11/2007	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	11/2007	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	11/2007	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI G37 Coupe	CV36	11/2007	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI G37 Coupe	CV36	11/2007	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	11/2007	ASCD		√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	11/2007	HCM		√	√	√		
INFINITI	INFINITI G37 Coupe	CV36	11/2007	LDW		√	√	√		
INFINITI	INFINITI G37 Sedan	V36	07/2008	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI G37 Sedan	V36	07/2008	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI G37 Sedan	V36	07/2008	ABS	√	√	√	*	√	

INFINITI	INFINITI G37 Sedan	V36	07/2008	AIRBAG	√	√	√			
INFINITI	INFINITI G37 Sedan	V36	07/2008	BCM	√	√	√	√	√	
INFINITI	INFINITI G37 Sedan	V36	07/2008	METER/M&A	√	√	√	√		
INFINITI	INFINITI G37 Sedan	V36	07/2008	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI G37 Sedan	V36	07/2008	ICC	√	√	√	√		
INFINITI	INFINITI G37 Sedan	V36	07/2008	HVAC	√	√	√	√		
INFINITI	INFINITI G37 Sedan	V36	07/2008	MULTI AV	√	√	√	√		
INFINITI	INFINITI G37 Sedan	V36	07/2008	EPS	√	√	√	√		
INFINITI	INFINITI G37 Sedan	V36	07/2008	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI G37 Sedan	V36	07/2008	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI G37 Sedan	V36	07/2008	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI G37 Sedan	V36	07/2008	e-4WD	√	√	√	√	√	
INFINITI	INFINITI G37 Sedan	V36	07/2008	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI G37 Sedan	V36	07/2008	DIU	√	√	√	√		
INFINITI	INFINITI G37 Sedan	V36	07/2008	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI G37 Sedan	V36	07/2008	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI G37 Sedan	V36	07/2008	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI G37 Sedan	V36	07/2008	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI G37 Sedan	V36	07/2008	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI G37 Sedan	V36	07/2008	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI G37 Sedan	V36	07/2008	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI G37 Sedan	V36	07/2008	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI G37 Sedan	V36	07/2008	ASCD		√	√	√		
INFINITI	INFINITI G37 Sedan	V36	07/2008	HCM		√	√	√		
INFINITI	INFINITI G37 Sedan	V36	07/2008	LDW		√	√	√		
INFINITI	INFINITI M35/M45	Y50	08/2008	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI M35/M45	Y50	08/2008	TRANSMISSION	√	√	√	*		

INFINITI	INFINITI M35/M45	Y50	08/2008	ABS	✓	✓	✓	*	✓	
INFINITI	INFINITI M35/M45	Y50	08/2008	AIRBAG	✓	✓	✓			
INFINITI	INFINITI M35/M45	Y50	08/2008	BCM	✓	✓	✓	✓	✓	
INFINITI	INFINITI M35/M45	Y50	08/2008	METER/M&A	✓	✓	✓	✓		
INFINITI	INFINITI M35/M45	Y50	08/2008	METER ACAMP	✓	✓	✓	✓	✓	
INFINITI	INFINITI M35/M45	Y50	08/2008	ICC	✓	✓	✓	✓		
INFINITI	INFINITI M35/M45	Y50	08/2008	HVAC	✓	✓	✓	✓		
INFINITI	INFINITI M35/M45	Y50	08/2008	MULTI AV	✓	✓	✓	✓		
INFINITI	INFINITI M35/M45	Y50	08/2008	EPS	✓	✓	✓	✓		
INFINITI	INFINITI M35/M45	Y50	08/2008	IPDM E/R	✓	✓	✓	✓	✓	
INFINITI	INFINITI M35/M45	Y50	08/2008	AIR PRESSURE MONITOR	✓	✓	✓	✓	✓	
INFINITI	INFINITI M35/M45	Y50	08/2008	HEAD LAMP LEVELIZER	✓	✓	✓	✓	✓	
INFINITI	INFINITI M35/M45	Y50	08/2008	e-4WD	✓	✓	✓	✓	✓	
INFINITI	INFINITI M35/M45	Y50	08/2008	INTELLIGENT KEY	✓	✓	✓	✓	✓	
INFINITI	INFINITI M35/M45	Y50	08/2008	DIU	✓	✓	✓	✓		
INFINITI	INFINITI M35/M45	Y50	08/2008	AUTO DRIVE POS	✓	✓	✓	✓	✓	
INFINITI	INFINITI M35/M45	Y50	08/2008	AUTO SLIDE POS	✓	✓	✓	✓	✓	
INFINITI	INFINITI M35/M45	Y50	08/2008	PRECRASH SEATBELT	✓	✓	✓	✓		
INFINITI	INFINITI M35/M45	Y50	08/2008	ALL MODE AWD/4WD	✓	✓	✓	✓		
INFINITI	INFINITI M35/M45	Y50	08/2008	4WAS(MAIN)/RAS/HICAS	✓	✓	✓	✓	✓	
INFINITI	INFINITI M35/M45	Y50	08/2008	ADAPTIVE LIGHT	✓	✓	✓	✓	✓	
INFINITI	INFINITI M35/M45	Y50	08/2008	SMART ENTRANCE	✓	✓	✓			
INFINITI	INFINITI M35/M45	Y50	08/2008	ACTIVE SUS	✓	✓	✓	✓		
INFINITI	INFINITI M35/M45	Y50	08/2008	ASCD		✓	✓	✓		
INFINITI	INFINITI M35/M45	Y50	08/2008	HCM		✓	✓	✓		
INFINITI	INFINITI M35/M45	Y50	08/2008	LDW		✓	✓	✓		
INFINITI	INFINITI M35/M45	Y50	01/2008	ENGINE	✓	✓	✓	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ

INFINITI	INFINITI M35/M45	Y50	01/2008	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI M35/M45	Y50	01/2008	ABS	√	√	√	*	√	
INFINITI	INFINITI M35/M45	Y50	01/2008	AIRBAG	√	√	√			
INFINITI	INFINITI M35/M45	Y50	01/2008	BCM	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	01/2008	METER/M&A	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	01/2008	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	01/2008	ICC	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	01/2008	HVAC	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	01/2008	MULTI AV	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	01/2008	EPS	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	01/2008	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	01/2008	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	01/2008	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	01/2008	e-4WD	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	01/2008	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	01/2008	DIU	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	01/2008	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	01/2008	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	01/2008	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	01/2008	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	01/2008	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	01/2008	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	01/2008	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI M35/M45	Y50	01/2008	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	01/2008	ASCD		√	√	√		
INFINITI	INFINITI M35/M45	Y50	01/2008	HCM		√	√	√		
INFINITI	INFINITI M35/M45	Y50	01/2008	LDW		√	√	√		

										TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI M35/M45	Y50	07/2006	ENGINE	√	√	√	*	*	
INFINITI	INFINITI M35/M45	Y50	07/2006	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI M35/M45	Y50	07/2006	ABS	√	√	√	*	√	
INFINITI	INFINITI M35/M45	Y50	07/2006	AIRBAG	√	√	√			
INFINITI	INFINITI M35/M45	Y50	07/2006	BCM	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	07/2006	METER/M&A	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	07/2006	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	07/2006	ICC	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	07/2006	HVAC	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	07/2006	MULTI AV	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	07/2006	EPS	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	07/2006	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	07/2006	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	07/2006	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	07/2006	e-4WD	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	07/2006	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	07/2006	DIU	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	07/2006	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	07/2006	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	07/2006	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	07/2006	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	07/2006	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	07/2006	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI M35/M45	Y50	07/2006	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI M35/M45	Y50	07/2006	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI M35/M45	Y50	07/2006	ASCD		√	√	√		
INFINITI	INFINITI M35/M45	Y50	07/2006	HCM		√	√	√		

INFINITI	INFINITI M35/M45	Y50	07/2006	LDW		√	√	√		
INFINITI	INFINITI M45	2005	ALL	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI M45	2005	ALL	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI M45	2005	ALL	ABS	√	√	√	*	√	
INFINITI	INFINITI M45	2005	ALL	AIRBAG	√	√	√			
INFINITI	INFINITI M45	2005	ALL	BCM	√	√	√	√	√	
INFINITI	INFINITI M45	2005	ALL	METER/M&A	√	√	√	√		
INFINITI	INFINITI M45	2005	ALL	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI M45	2005	ALL	ICC	√	√	√	√		
INFINITI	INFINITI M45	2005	ALL	HVAC	√	√	√	√		
INFINITI	INFINITI M45	2005	ALL	MULTI AV	√	√	√	√		
INFINITI	INFINITI M45	2005	ALL	EPS	√	√	√	√		
INFINITI	INFINITI M45	2005	ALL	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI M45	2005	ALL	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI M45	2005	ALL	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI M45	2005	ALL	e-4WD	√	√	√	√	√	
INFINITI	INFINITI M45	2005	ALL	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI M45	2005	ALL	DIU	√	√	√	√		
INFINITI	INFINITI M45	2005	ALL	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI M45	2005	ALL	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI M45	2005	ALL	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI M45	2005	ALL	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI M45	2005	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI M45	2005	ALL	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI M45	2005	ALL	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI M45	2005	ALL	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI M45	2005	ALL	ASCD		√	√	√		

INFINITI	INFINITI M45	2005	ALL	HCM		✓	✓	✓		
INFINITI	INFINITI M45	2005	ALL	LDW		✓	✓	✓		
INFINITI	INFINITI M45	2004	ALL	ENGINE	✓	✓	✓	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI M45	2004	ALL	TRANSMISSION	✓	✓	✓	*		
INFINITI	INFINITI M45	2004	ALL	ABS	✓	✓	✓	*	✓	
INFINITI	INFINITI M45	2004	ALL	AIRBAG	✓	✓	✓			
INFINITI	INFINITI M45	2004	ALL	BCM	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2004	ALL	METER/M&A	✓	✓	✓	✓		
INFINITI	INFINITI M45	2004	ALL	METER ACAMP	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2004	ALL	ICC	✓	✓	✓	✓		
INFINITI	INFINITI M45	2004	ALL	HVAC	✓	✓	✓	✓		
INFINITI	INFINITI M45	2004	ALL	MULTI AV	✓	✓	✓	✓		
INFINITI	INFINITI M45	2004	ALL	EPS	✓	✓	✓	✓		
INFINITI	INFINITI M45	2004	ALL	IPDM E/R	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2004	ALL	AIR PRESSURE MONITOR	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2004	ALL	HEAD LAMP LEVELIZER	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2004	ALL	e-4WD	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2004	ALL	INTELLIGENT KEY	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2004	ALL	DIU	✓	✓	✓	✓		
INFINITI	INFINITI M45	2004	ALL	AUTO DRIVE POS	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2004	ALL	AUTO SLIDE POS	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2004	ALL	PRECRASH SEATBELT	✓	✓	✓	✓		
INFINITI	INFINITI M45	2004	ALL	ALL MODE AWD/4WD	✓	✓	✓	✓		
INFINITI	INFINITI M45	2004	ALL	4WAS(MAIN)/RAS/HICAS	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2004	ALL	ADAPTIVE LIGHT	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2004	ALL	SMART ENTRANCE	✓	✓	✓			
INFINITI	INFINITI M45	2004	ALL	ACTIVE SUS	✓	✓	✓	✓		

INFINITI	INFINITI M45	2004	ALL	ASCD		✓	✓	✓		
INFINITI	INFINITI M45	2004	ALL	HCM		✓	✓	✓		
INFINITI	INFINITI M45	2004	ALL	LDW		✓	✓	✓		
INFINITI	INFINITI M45	2003	ALL	ENGINE	✓	✓	✓	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI M45	2003	ALL	TRANSMISSION	✓	✓	✓	*		
INFINITI	INFINITI M45	2003	ALL	ABS	✓	✓	✓	*	✓	
INFINITI	INFINITI M45	2003	ALL	AIRBAG	✓	✓	✓			
INFINITI	INFINITI M45	2003	ALL	BCM	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2003	ALL	METER/M&A	✓	✓	✓	✓		
INFINITI	INFINITI M45	2003	ALL	METER ACAMP	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2003	ALL	ICC	✓	✓	✓	✓		
INFINITI	INFINITI M45	2003	ALL	HVAC	✓	✓	✓	✓		
INFINITI	INFINITI M45	2003	ALL	MULTI AV	✓	✓	✓	✓		
INFINITI	INFINITI M45	2003	ALL	EPS	✓	✓	✓	✓		
INFINITI	INFINITI M45	2003	ALL	IPDM E/R	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2003	ALL	AIR PRESSURE MONITOR	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2003	ALL	HEAD LAMP LEVELIZER	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2003	ALL	e-4WD	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2003	ALL	INTELLIGENT KEY	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2003	ALL	DIU	✓	✓	✓	✓		
INFINITI	INFINITI M45	2003	ALL	AUTO DRIVE POS	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2003	ALL	AUTO SLIDE POS	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2003	ALL	PRECRASH SEATBELT	✓	✓	✓	✓		
INFINITI	INFINITI M45	2003	ALL	ALL MODE AWD/4WD	✓	✓	✓	✓		
INFINITI	INFINITI M45	2003	ALL	4WAS(MAIN)/RAS/HICAS	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2003	ALL	ADAPTIVE LIGHT	✓	✓	✓	✓	✓	
INFINITI	INFINITI M45	2003	ALL	SMART ENTRANCE	✓	✓	✓			

INFINITI	INFINITI M45	2003	ALL	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI M45	2003	ALL	ASCD		√	√	√		
INFINITI	INFINITI M45	2003	ALL	HCM		√	√	√		
INFINITI	INFINITI M45	2003	ALL	LDW		√	√	√		
INFINITI	INFINITI Q45	F50	11/2005	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI Q45	F50	11/2005	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI Q45	F50	11/2005	ABS	√	√	√	*	√	
INFINITI	INFINITI Q45	F50	11/2005	AIRBAG	√	√	√			
INFINITI	INFINITI Q45	F50	11/2005	BCM	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	11/2005	METER/M&A	√	√	√	√		
INFINITI	INFINITI Q45	F50	11/2005	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	11/2005	ICC	√	√	√	√		
INFINITI	INFINITI Q45	F50	11/2005	HVAC	√	√	√	√		
INFINITI	INFINITI Q45	F50	11/2005	MULTI AV	√	√	√	√		
INFINITI	INFINITI Q45	F50	11/2005	EPS	√	√	√	√		
INFINITI	INFINITI Q45	F50	11/2005	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	11/2005	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	11/2005	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	11/2005	e-4WD	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	11/2005	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	11/2005	DIU	√	√	√	√		
INFINITI	INFINITI Q45	F50	11/2005	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	11/2005	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	11/2005	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI Q45	F50	11/2005	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI Q45	F50	11/2005	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	11/2005	ADAPTIVE LIGHT	√	√	√	√	√	

INFINITI	INFINITI Q45	F50	11/2005	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI Q45	F50	11/2005	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI Q45	F50	11/2005	ASCD		√	√	√		
INFINITI	INFINITI Q45	F50	11/2005	HCM		√	√	√		
INFINITI	INFINITI Q45	F50	11/2005	LDW		√	√	√		
INFINITI	INFINITI Q45	F50	08/2004	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI Q45	F50	08/2004	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI Q45	F50	08/2004	ABS	√	√	√	*	√	
INFINITI	INFINITI Q45	F50	08/2004	AIRBAG	√	√	√			
INFINITI	INFINITI Q45	F50	08/2004	BCM	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2004	METER/M&A	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2004	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2004	ICC	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2004	HVAC	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2004	MULTI AV	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2004	EPS	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2004	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2004	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2004	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2004	e-4WD	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2004	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2004	DIU	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2004	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2004	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2004	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2004	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2004	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	

INFINITI	INFINITI Q45	F50	08/2004	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2004	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI Q45	F50	08/2004	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2004	ASCD		√	√	√		
INFINITI	INFINITI Q45	F50	08/2004	HCM		√	√	√		
INFINITI	INFINITI Q45	F50	08/2004	LDW		√	√	√		
INFINITI	INFINITI Q45	F50	08/2003	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI Q45	F50	08/2003	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI Q45	F50	08/2003	ABS	√	√	√	*	√	
INFINITI	INFINITI Q45	F50	08/2003	AIRBAG	√	√	√			
INFINITI	INFINITI Q45	F50	08/2003	BCM	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2003	METER/M&A	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2003	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2003	ICC	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2003	HVAC	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2003	MULTI AV	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2003	EPS	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2003	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2003	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2003	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2003	e-4WD	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2003	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2003	DIU	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2003	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2003	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2003	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2003	ALL MODE AWD/4WD	√	√	√	√		

INFINITI	INFINITI Q45	F50	08/2003	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2003	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2003	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI Q45	F50	08/2003	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2003	ASCD		√	√	√		
INFINITI	INFINITI Q45	F50	08/2003	HCM		√	√	√		
INFINITI	INFINITI Q45	F50	08/2003	LDW		√	√	√		
INFINITI	INFINITI Q45	F50	09/2002	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI Q45	F50	09/2002	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI Q45	F50	09/2002	ABS	√	√	√	*	√	
INFINITI	INFINITI Q45	F50	09/2002	AIRBAG	√	√	√			
INFINITI	INFINITI Q45	F50	09/2002	BCM	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	09/2002	METER/M&A	√	√	√	√		
INFINITI	INFINITI Q45	F50	09/2002	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	09/2002	ICC	√	√	√	√		
INFINITI	INFINITI Q45	F50	09/2002	HVAC	√	√	√	√		
INFINITI	INFINITI Q45	F50	09/2002	MULTI AV	√	√	√	√		
INFINITI	INFINITI Q45	F50	09/2002	EPS	√	√	√	√		
INFINITI	INFINITI Q45	F50	09/2002	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	09/2002	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	09/2002	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	09/2002	e-4WD	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	09/2002	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	09/2002	DIU	√	√	√	√		
INFINITI	INFINITI Q45	F50	09/2002	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	09/2002	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	09/2002	PRECRASH SEATBELT	√	√	√	√		

INFINITI	INFINITI Q45	F50	09/2002	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI Q45	F50	09/2002	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	09/2002	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	09/2002	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI Q45	F50	09/2002	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI Q45	F50	09/2002	ASCD		√	√	√		
INFINITI	INFINITI Q45	F50	09/2002	HCM		√	√	√		
INFINITI	INFINITI Q45	F50	09/2002	LDW		√	√	√		
INFINITI	INFINITI Q45	F50	08/2001	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI Q45	F50	08/2001	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI Q45	F50	08/2001	ABS	√	√	√	*	√	
INFINITI	INFINITI Q45	F50	08/2001	AIRBAG	√	√	√			
INFINITI	INFINITI Q45	F50	08/2001	BCM	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2001	METER/M&A	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2001	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2001	ICC	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2001	HVAC	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2001	MULTI AV	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2001	EPS	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2001	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2001	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2001	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2001	e-4WD	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2001	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2001	DIU	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2001	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2001	AUTO SLIDE POS	√	√	√	√	√	

INFINITI	INFINITI Q45	F50	08/2001	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2001	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2001	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2001	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI Q45	F50	08/2001	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI Q45	F50	08/2001	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI Q45	F50	08/2001	ASCD		√	√	√		
INFINITI	INFINITI Q45	F50	08/2001	HCM		√	√	√		
INFINITI	INFINITI Q45	F50	08/2001	LDW		√	√	√		
INFINITI	INFINITI QX4	2003	ALL	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI QX4	2003	ALL	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI QX4	2003	ALL	ABS	√	√	√	*	√	
INFINITI	INFINITI QX4	2003	ALL	AIRBAG	√	√	√			
INFINITI	INFINITI QX4	2003	ALL	BCM	√	√	√	√	√	
INFINITI	INFINITI QX4	2003	ALL	METER/M&A	√	√	√	√		
INFINITI	INFINITI QX4	2003	ALL	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI QX4	2003	ALL	ICC	√	√	√	√		
INFINITI	INFINITI QX4	2003	ALL	HVAC	√	√	√	√		
INFINITI	INFINITI QX4	2003	ALL	MULTI AV	√	√	√	√		
INFINITI	INFINITI QX4	2003	ALL	EPS	√	√	√	√		
INFINITI	INFINITI QX4	2003	ALL	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI QX4	2003	ALL	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI QX4	2003	ALL	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI QX4	2003	ALL	e-4WD	√	√	√	√	√	
INFINITI	INFINITI QX4	2003	ALL	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI QX4	2003	ALL	DIU	√	√	√	√		
INFINITI	INFINITI QX4	2003	ALL	AUTO DRIVE POS	√	√	√	√	√	

INFINITI	INFINITI QX4	2003	ALL	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI QX4	2003	ALL	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI QX4	2003	ALL	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI QX4	2003	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI QX4	2003	ALL	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI QX4	2003	ALL	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI QX4	2003	ALL	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI QX4	2003	ALL	ASCD		√	√	√		
INFINITI	INFINITI QX4	2003	ALL	HCM		√	√	√		
INFINITI	INFINITI QX4	2003	ALL	LDW		√	√	√		
INFINITI	INFINITI QX4	2002	ALL	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI QX4	2002	ALL	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI QX4	2002	ALL	ABS	√	√	√	*	√	
INFINITI	INFINITI QX4	2002	ALL	AIRBAG	√	√	√			
INFINITI	INFINITI QX4	2002	ALL	BCM	√	√	√	√	√	
INFINITI	INFINITI QX4	2002	ALL	METER/M&A	√	√	√	√		
INFINITI	INFINITI QX4	2002	ALL	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI QX4	2002	ALL	ICC	√	√	√	√		
INFINITI	INFINITI QX4	2002	ALL	HVAC	√	√	√	√		
INFINITI	INFINITI QX4	2002	ALL	MULTI AV	√	√	√	√		
INFINITI	INFINITI QX4	2002	ALL	EPS	√	√	√	√		
INFINITI	INFINITI QX4	2002	ALL	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI QX4	2002	ALL	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI QX4	2002	ALL	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI QX4	2002	ALL	e-4WD	√	√	√	√	√	
INFINITI	INFINITI QX4	2002	ALL	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI QX4	2002	ALL	DIU	√	√	√	√		

INFINITI	INFINITI QX4	2002	ALL	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI QX4	2002	ALL	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI QX4	2002	ALL	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI QX4	2002	ALL	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI QX4	2002	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI QX4	2002	ALL	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI QX4	2002	ALL	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI QX4	2002	ALL	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI QX4	2002	ALL	ASCD		√	√	√		
INFINITI	INFINITI QX4	2002	ALL	HCM		√	√	√		
INFINITI	INFINITI QX4	2002	ALL	LDW		√	√	√		
INFINITI	INFINITI QX4	2001	ALL	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI QX4	2001	ALL	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI QX4	2001	ALL	ABS	√	√	√	*	√	
INFINITI	INFINITI QX4	2001	ALL	AIRBAG	√	√	√			
INFINITI	INFINITI QX4	2001	ALL	BCM	√	√	√	√	√	
INFINITI	INFINITI QX4	2001	ALL	METER/M&A	√	√	√	√		
INFINITI	INFINITI QX4	2001	ALL	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI QX4	2001	ALL	ICC	√	√	√	√		
INFINITI	INFINITI QX4	2001	ALL	HVAC	√	√	√	√		
INFINITI	INFINITI QX4	2001	ALL	MULTI AV	√	√	√	√		
INFINITI	INFINITI QX4	2001	ALL	EPS	√	√	√	√		
INFINITI	INFINITI QX4	2001	ALL	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI QX4	2001	ALL	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI QX4	2001	ALL	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI QX4	2001	ALL	e-4WD	√	√	√	√	√	
INFINITI	INFINITI QX4	2001	ALL	INTELLIGENT KEY	√	√	√	√	√	

INFINITI	INFINITI QX4	2001	ALL	DIU	√	√	√	√		
INFINITI	INFINITI QX4	2001	ALL	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI QX4	2001	ALL	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI QX4	2001	ALL	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI QX4	2001	ALL	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI QX4	2001	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI QX4	2001	ALL	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI QX4	2001	ALL	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI QX4	2001	ALL	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI QX4	2001	ALL	ASCD		√	√	√		
INFINITI	INFINITI QX4	2001	ALL	HCM		√	√	√		
INFINITI	INFINITI QX4	2001	ALL	LDW		√	√	√		
INFINITI	INFINITI QX4	2000	ALL	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI QX4	2000	ALL	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI QX4	2000	ALL	ABS	√	√	√	*	√	
INFINITI	INFINITI QX4	2000	ALL	AIRBAG	√	√	√			
INFINITI	INFINITI QX4	2000	ALL	BCM	√	√	√	√	√	
INFINITI	INFINITI QX4	2000	ALL	METER/M&A	√	√	√	√		
INFINITI	INFINITI QX4	2000	ALL	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI QX4	2000	ALL	ICC	√	√	√	√		
INFINITI	INFINITI QX4	2000	ALL	HVAC	√	√	√	√		
INFINITI	INFINITI QX4	2000	ALL	MULTI AV	√	√	√	√		
INFINITI	INFINITI QX4	2000	ALL	EPS	√	√	√	√		
INFINITI	INFINITI QX4	2000	ALL	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI QX4	2000	ALL	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI QX4	2000	ALL	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI QX4	2000	ALL	e-4WD	√	√	√	√	√	

INFINITI	INFINITI QX4	2000	ALL	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI QX4	2000	ALL	DIU	√	√	√	√		
INFINITI	INFINITI QX4	2000	ALL	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI QX4	2000	ALL	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI QX4	2000	ALL	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI QX4	2000	ALL	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI QX4	2000	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI QX4	2000	ALL	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI QX4	2000	ALL	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI QX4	2000	ALL	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI QX4	2000	ALL	ASCD		√	√	√		
INFINITI	INFINITI QX4	2000	ALL	HCM		√	√	√		
INFINITI	INFINITI QX4	2000	ALL	LDW		√	√	√		
INFINITI	INFINITI QX4	1999	ALL	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI QX4	1999	ALL	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI QX4	1999	ALL	ABS	√	√	√	*	√	
INFINITI	INFINITI QX4	1999	ALL	AIRBAG	√	√	√			
INFINITI	INFINITI QX4	1999	ALL	BCM	√	√	√	√	√	
INFINITI	INFINITI QX4	1999	ALL	METER/M&A	√	√	√	√		
INFINITI	INFINITI QX4	1999	ALL	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI QX4	1999	ALL	ICC	√	√	√	√		
INFINITI	INFINITI QX4	1999	ALL	HVAC	√	√	√	√		
INFINITI	INFINITI QX4	1999	ALL	MULTI AV	√	√	√	√		
INFINITI	INFINITI QX4	1999	ALL	EPS	√	√	√	√		
INFINITI	INFINITI QX4	1999	ALL	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI QX4	1999	ALL	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI QX4	1999	ALL	HEAD LAMP LEVELIZER	√	√	√	√	√	

INFINITI	INFINITI QX4	1999	ALL	e-4WD	√	√	√	√	√	
INFINITI	INFINITI QX4	1999	ALL	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI QX4	1999	ALL	DIU	√	√	√	√		
INFINITI	INFINITI QX4	1999	ALL	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI QX4	1999	ALL	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI QX4	1999	ALL	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI QX4	1999	ALL	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI QX4	1999	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI QX4	1999	ALL	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI QX4	1999	ALL	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI QX4	1999	ALL	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI QX4	1999	ALL	ASCD		√	√	√		
INFINITI	INFINITI QX4	1999	ALL	HCM		√	√	√		
INFINITI	INFINITI QX4	1999	ALL	LDW		√	√	√		
INFINITI	INFINITI QX4	1998	ALL	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI QX4	1998	ALL	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI QX4	1998	ALL	ABS	√	√	√	*	√	
INFINITI	INFINITI QX4	1998	ALL	AIRBAG	√	√	√			
INFINITI	INFINITI QX4	1998	ALL	BCM	√	√	√	√	√	
INFINITI	INFINITI QX4	1998	ALL	METER/M&A	√	√	√	√		
INFINITI	INFINITI QX4	1998	ALL	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI QX4	1998	ALL	ICC	√	√	√	√		
INFINITI	INFINITI QX4	1998	ALL	HVAC	√	√	√	√		
INFINITI	INFINITI QX4	1998	ALL	MULTI AV	√	√	√	√		
INFINITI	INFINITI QX4	1998	ALL	EPS	√	√	√	√		
INFINITI	INFINITI QX4	1998	ALL	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI QX4	1998	ALL	AIR PRESSURE MONITOR	√	√	√	√	√	

INFINITI	INFINITI QX4	1998	ALL	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI QX4	1998	ALL	e-4WD	√	√	√	√	√	
INFINITI	INFINITI QX4	1998	ALL	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI QX4	1998	ALL	DIU	√	√	√	√		
INFINITI	INFINITI QX4	1998	ALL	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI QX4	1998	ALL	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI QX4	1998	ALL	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI QX4	1998	ALL	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI QX4	1998	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI QX4	1998	ALL	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI QX4	1998	ALL	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI QX4	1998	ALL	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI QX4	1998	ALL	ASCD		√	√	√		
INFINITI	INFINITI QX4	1998	ALL	HCM		√	√	√		
INFINITI	INFINITI QX4	1998	ALL	LDW		√	√	√		
INFINITI	INFINITI QX4	1997	ALL	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI QX4	1997	ALL	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI QX4	1997	ALL	ABS	√	√	√	*	√	
INFINITI	INFINITI QX4	1997	ALL	AIRBAG	√	√	√			
INFINITI	INFINITI QX4	1997	ALL	BCM	√	√	√	√	√	
INFINITI	INFINITI QX4	1997	ALL	METER/M&A	√	√	√	√		
INFINITI	INFINITI QX4	1997	ALL	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI QX4	1997	ALL	ICC	√	√	√	√		
INFINITI	INFINITI QX4	1997	ALL	HVAC	√	√	√	√		
INFINITI	INFINITI QX4	1997	ALL	MULTI AV	√	√	√	√		
INFINITI	INFINITI QX4	1997	ALL	EPS	√	√	√	√		
INFINITI	INFINITI QX4	1997	ALL	IPDM E/R	√	√	√	√	√	

INFINITI	INFINITI QX4	1997	ALL	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI QX4	1997	ALL	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI QX4	1997	ALL	e-4WD	√	√	√	√	√	
INFINITI	INFINITI QX4	1997	ALL	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI QX4	1997	ALL	DIU	√	√	√	√		
INFINITI	INFINITI QX4	1997	ALL	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI QX4	1997	ALL	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI QX4	1997	ALL	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI QX4	1997	ALL	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI QX4	1997	ALL	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI QX4	1997	ALL	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI QX4	1997	ALL	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI QX4	1997	ALL	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI QX4	1997	ALL	ASCD		√	√	√		
INFINITI	INFINITI QX4	1997	ALL	HCM		√	√	√		
INFINITI	INFINITI QX4	1997	ALL	LDW		√	√	√		
INFINITI	INFINITI QX56	JA60	04/2008	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI QX56	JA60	04/2008	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI QX56	JA60	04/2008	ABS	√	√	√	*	√	
INFINITI	INFINITI QX56	JA60	04/2008	AIRBAG	√	√	√			
INFINITI	INFINITI QX56	JA60	04/2008	BCM	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	04/2008	METER/M&A	√	√	√	√		
INFINITI	INFINITI QX56	JA60	04/2008	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	04/2008	ICC	√	√	√	√		
INFINITI	INFINITI QX56	JA60	04/2008	HVAC	√	√	√	√		
INFINITI	INFINITI QX56	JA60	04/2008	MULTI AV	√	√	√	√		
INFINITI	INFINITI QX56	JA60	04/2008	EPS	√	√	√	√		

INFINITI	INFINITI QX56	JA60	04/2008	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	04/2008	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	04/2008	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	04/2008	e-4WD	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	04/2008	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	04/2008	DIU	√	√	√	√		
INFINITI	INFINITI QX56	JA60	04/2008	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	04/2008	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	04/2008	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI QX56	JA60	04/2008	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI QX56	JA60	04/2008	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	04/2008	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	04/2008	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI QX56	JA60	04/2008	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI QX56	JA60	04/2008	ASCD		√	√	√		
INFINITI	INFINITI QX56	JA60	04/2008	HCM		√	√	√		
INFINITI	INFINITI QX56	JA60	04/2008	LDW		√	√	√		
INFINITI	INFINITI QX56	JA60	08/2007	ENGINE	√	√	√	*	*	TP/SW SEN IDLE POSI ADJ,IGNITION TIMING ADJ,FUEL PRESSURE RELEASE,IDLE AIR VOL LEARN,TARGET IGN TIM ADJ,TARGET IDLE PRM ADJ
INFINITI	INFINITI QX56	JA60	08/2007	TRANSMISSION	√	√	√	*		
INFINITI	INFINITI QX56	JA60	08/2007	ABS	√	√	√	*	√	
INFINITI	INFINITI QX56	JA60	08/2007	AIRBAG	√	√	√			
INFINITI	INFINITI QX56	JA60	08/2007	BCM	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	08/2007	METER/M&A	√	√	√	√		
INFINITI	INFINITI QX56	JA60	08/2007	METER ACAMP	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	08/2007	ICC	√	√	√	√		
INFINITI	INFINITI QX56	JA60	08/2007	HVAC	√	√	√	√		
INFINITI	INFINITI QX56	JA60	08/2007	MULTI AV	√	√	√	√		

INFINITI	INFINITI QX56	JA60	08/2007	EPS	√	√	√	√		
INFINITI	INFINITI QX56	JA60	08/2007	IPDM E/R	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	08/2007	AIR PRESSURE MONITOR	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	08/2007	HEAD LAMP LEVELIZER	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	08/2007	e-4WD	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	08/2007	INTELLIGENT KEY	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	08/2007	DIU	√	√	√	√		
INFINITI	INFINITI QX56	JA60	08/2007	AUTO DRIVE POS	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	08/2007	AUTO SLIDE POS	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	08/2007	PRECRASH SEATBELT	√	√	√	√		
INFINITI	INFINITI QX56	JA60	08/2007	ALL MODE AWD/4WD	√	√	√	√		
INFINITI	INFINITI QX56	JA60	08/2007	4WAS(MAIN)/RAS/HICAS	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	08/2007	ADAPTIVE LIGHT	√	√	√	√	√	
INFINITI	INFINITI QX56	JA60	08/2007	SMART ENTRANCE	√	√	√			
INFINITI	INFINITI QX56	JA60	08/2007	ACTIVE SUS	√	√	√	√		
INFINITI	INFINITI QX56	JA60	08/2007	ASCD		√	√	√		
INFINITI	INFINITI QX56	JA60	08/2007	HCM		√	√	√		
INFINITI	INFINITI QX56	JA60	08/2007	LDW		√	√	√		