

How to read this list:	
Mark	Description
√	Function is supported.
*	Function is added or developed newly

V30/PC-MAX Function List

Automaker:				Mazda									
Software Version:				v3.7									
Automaker	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations	Special Functions
Mazda	Asia	2000-2008	MAZDA2			PCM			√	√	√		
Mazda	Asia	2000-2008	MAZDA2			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	MAZDA2			ICM			√	√	√		
Mazda	Asia	2000-2008	MAZDA2			TCM			√	√	√		
Mazda	Asia	2000-2008	MAZDA2			EPS			√	√	√		
Mazda	Asia	2000-2008	MAZDA2			RCM			√	√	√		
Mazda	Asia	2000-2008	MAZDA2			GEM			√	√	√		
Mazda	Asia	2000-2008	MAZDA3			PCM			√	√	√		
Mazda	Asia	2000-2008	MAZDA3			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	MAZDA3			ICM			√	√	√		
Mazda	Asia	2000-2008	MAZDA3			TCM			√	√	√		
Mazda	Asia	2000-2008	MAZDA3			EPS			√	√	√		
Mazda	Asia	2000-2008	MAZDA3			RCM			√	√	√		
Mazda	Asia	2000-2008	MAZDA3			GEM			√	√	√		
Mazda	Asia	2000-2008	MAZDA5			PCM			√	√	√		
Mazda	Asia	2000-2008	MAZDA5			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	MAZDA5			ICM			√	√	√		
Mazda	Asia	2000-2008	MAZDA5			TCM			√	√	√		
Mazda	Asia	2000-2008	MAZDA5			EPS			√	√	√		
Mazda	Asia	2000-2008	MAZDA5			RCM			√	√	√		
Mazda	Asia	2000-2008	MAZDA5			GEM			√	√	√		
Mazda	Asia	2000-2008	MAZDA6			PCM			√	√	√		
Mazda	Asia	2000-2008	MAZDA6			ABS\TCS			√	√	√		

<http://www.autoboss.net>

<http://www.servicesolutions.com.cn>

Mazda	Asia	2000-2008	MAZDA6			ICM			√	√	√		
Mazda	Asia	2000-2008	MAZDA6			TCM			√	√	√		
Mazda	Asia	2000-2008	MAZDA6			EPS			√	√	√		
Mazda	Asia	2000-2008	MAZDA6			RCM			√	√	√		
Mazda	Asia	2000-2008	MAZDA6			GEM			√	√	√		
Mazda	Asia	2000-2008	MAZDA8			PCM			√	√	√		
Mazda	Asia	2000-2008	MAZDA8			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	MAZDA8			ICM			√	√	√		
Mazda	Asia	2000-2008	MAZDA8			TCM			√	√	√		
Mazda	Asia	2000-2008	MAZDA8			EPS			√	√	√		
Mazda	Asia	2000-2008	MAZDA8			RCM			√	√	√		
Mazda	Asia	2000-2008	MAZDA8			GEM			√	√	√		
Mazda	Asia	2000-2008	PREMACY			PCM			√	√	√		
Mazda	Asia	2000-2008	PREMACY			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	PREMACY			ICM			√	√	√		
Mazda	Asia	2000-2008	PREMACY			TCM			√	√	√		
Mazda	Asia	2000-2008	PREMACY			EPS			√	√	√		
Mazda	Asia	2000-2008	PREMACY			RCM			√	√	√		
Mazda	Asia	2000-2008	PREMACY			GEM			√	√	√		
Mazda	Asia	2000-2008	TRIBUTE/ESCAPE			PCM			√	√	√		
Mazda	Asia	2000-2008	TRIBUTE/ESCAPE			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	TRIBUTE/ESCAPE			ICM			√	√	√		
Mazda	Asia	2000-2008	TRIBUTE/ESCAPE			TCM			√	√	√		
Mazda	Asia	2000-2008	TRIBUTE/ESCAPE			EPS			√	√	√		
Mazda	Asia	2000-2008	TRIBUTE/ESCAPE			RCM			√	√	√		
Mazda	Asia	2000-2008	TRIBUTE/ESCAPE			GEM			√	√	√		
Mazda	Asia	2000-2008	RX-8			PCM			√	√	√		
Mazda	Asia	2000-2008	RX-8			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	RX-8			ICM			√	√	√		
Mazda	Asia	2000-2008	RX-8			TCM			√	√	√		
Mazda	Asia	2000-2008	RX-8			EPS			√	√	√		
Mazda	Asia	2000-2008	RX-8			RCM			√	√	√		
Mazda	Asia	2000-2008	RX-8			GEM			√	√	√		
Mazda	Asia	2000-2008	VERSIA			PCM			√	√	√		

Mazda	Asia	2000-2008	VERSIA			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	VERSIA			ICM			√	√	√		
Mazda	Asia	2000-2008	VERSIA			TCM			√	√	√		
Mazda	Asia	2000-2008	VERSIA			EPS			√	√	√		
Mazda	Asia	2000-2008	VERSIA			RCM			√	√	√		
Mazda	Asia	2000-2008	VERSIA			GEM			√	√	√		
Mazda	Asia	2000-2008	MPV			PCM			√	√	√		
Mazda	Asia	2000-2008	MPV			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	MPV			ICM			√	√	√		
Mazda	Asia	2000-2008	MPV			TCM			√	√	√		
Mazda	Asia	2000-2008	MPV			EPS			√	√	√		
Mazda	Asia	2000-2008	MPV			RCM			√	√	√		
Mazda	Asia	2000-2008	MPV			GEM			√	√	√		
Mazda	Asia	2000-2008	ATENZA			PCM			√	√	√		
Mazda	Asia	2000-2008	ATENZA			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	ATENZA			ICM			√	√	√		
Mazda	Asia	2000-2008	ATENZA			TCM			√	√	√		
Mazda	Asia	2000-2008	ATENZA			EPS			√	√	√		
Mazda	Asia	2000-2008	ATENZA			RCM			√	√	√		
Mazda	Asia	2000-2008	ATENZA			GEM			√	√	√		
Mazda	Asia	2000-2008	AXELA			PCM			√	√	√		
Mazda	Asia	2000-2008	AXELA			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	AXELA			ICM			√	√	√		
Mazda	Asia	2000-2008	AXELA			TCM			√	√	√		
Mazda	Asia	2000-2008	AXELA			EPS			√	√	√		
Mazda	Asia	2000-2008	AXELA			RCM			√	√	√		
Mazda	Asia	2000-2008	AXELA			GEM			√	√	√		
Mazda	Asia	2000-2008	BONGO			PCM			√	√	√		
Mazda	Asia	2000-2008	BONGO			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	BONGO			ICM			√	√	√		
Mazda	Asia	2000-2008	BONGO			TCM			√	√	√		
Mazda	Asia	2000-2008	BONGO			EPS			√	√	√		
Mazda	Asia	2000-2008	BONGO			RCM			√	√	√		
Mazda	Asia	2000-2008	BONGO			GEM			√	√	√		



SERVICE SOLUTIONS

Mazda	Asia	2000-2008	BONGO BRAWNY			PCM			√	√	√		
Mazda	Asia	2000-2008	BONGO BRAWNY			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	BONGO BRAWNY			ICM			√	√	√		
Mazda	Asia	2000-2008	BONGO BRAWNY			TCM			√	√	√		
Mazda	Asia	2000-2008	BONGO BRAWNY			EPS			√	√	√		
Mazda	Asia	2000-2008	BONGO BRAWNY			RCM			√	√	√		
Mazda	Asia	2000-2008	BONGO BRAWNY			GEM			√	√	√		
Mazda	Asia	2000-2008	RANGER/BT-50			PCM			√	√	√		
Mazda	Asia	2000-2008	RANGER/BT-50			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	RANGER/BT-50			ICM			√	√	√		
Mazda	Asia	2000-2008	RANGER/BT-50			TCM			√	√	√		
Mazda	Asia	2000-2008	RANGER/BT-50			EPS			√	√	√		
Mazda	Asia	2000-2008	RANGER/BT-50			RCM			√	√	√		
Mazda	Asia	2000-2008	RANGER/BT-50			GEM			√	√	√		
Mazda	Asia	2000-2008	CX-7			PCM			√	√	√		
Mazda	Asia	2000-2008	CX-7			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	CX-7			ICM			√	√	√		
Mazda	Asia	2000-2008	CX-7			TCM			√	√	√		
Mazda	Asia	2000-2008	CX-7			EPS			√	√	√		
Mazda	Asia	2000-2008	CX-7			RCM			√	√	√		
Mazda	Asia	2000-2008	CX-7			GEM			√	√	√		
Mazda	Asia	2000-2008	CX-9			PCM			√	√	√		
Mazda	Asia	2000-2008	CX-9			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	CX-9			ICM			√	√	√		
Mazda	Asia	2000-2008	CX-9			TCM			√	√	√		
Mazda	Asia	2000-2008	CX-9			EPS			√	√	√		
Mazda	Asia	2000-2008	CX-9			RCM			√	√	√		
Mazda	Asia	2000-2008	CX-9			GEM			√	√	√		
Mazda	Asia	2000-2008	DEMIO			PCM			√	√	√		
Mazda	Asia	2000-2008	DEMIO			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	DEMIO			ICM			√	√	√		
Mazda	Asia	2000-2008	DEMIO			TCM			√	√	√		
Mazda	Asia	2000-2008	DEMIO			EPS			√	√	√		
Mazda	Asia	2000-2008	DEMIO			RCM			√	√	√		

<http://www.autoboss.net>

<http://www.servicesolutions.com.cn>



SERVICE SOLUTIONS

Mazda	Asia	2000-2008	DEMIO			GEM			√	√	√		
Mazda	Asia	2000-2008	MX-5			PCM			√	√	√		
Mazda	Asia	2000-2008	MX-5			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	MX-5			ICM			√	√	√		
Mazda	Asia	2000-2008	MX-5			TCM			√	√	√		
Mazda	Asia	2000-2008	MX-5			EPS			√	√	√		
Mazda	Asia	2000-2008	MX-5			RCM			√	√	√		
Mazda	Asia	2000-2008	MX-5			GEM			√	√	√		
Mazda	Asia	2000-2008	ROADSTER			PCM			√	√	√		
Mazda	Asia	2000-2008	ROADSTER			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	ROADSTER			ICM			√	√	√		
Mazda	Asia	2000-2008	ROADSTER			TCM			√	√	√		
Mazda	Asia	2000-2008	ROADSTER			EPS			√	√	√		
Mazda	Asia	2000-2008	ROADSTER			RCM			√	√	√		
Mazda	Asia	2000-2008	ROADSTER			GEM			√	√	√		
Mazda	Asia	2000-2008	SPECTRON			PCM			√	√	√		
Mazda	Asia	2000-2008	SPECTRON			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	SPECTRON			ICM			√	√	√		
Mazda	Asia	2000-2008	SPECTRON			TCM			√	√	√		
Mazda	Asia	2000-2008	SPECTRON			EPS			√	√	√		
Mazda	Asia	2000-2008	SPECTRON			RCM			√	√	√		
Mazda	Asia	2000-2008	SPECTRON			GEM			√	√	√		
Mazda	Asia	2000-2008	TITAN DASH			PCM			√	√	√		
Mazda	Asia	2000-2008	TITAN DASH			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	TITAN DASH			ICM			√	√	√		
Mazda	Asia	2000-2008	TITAN DASH			TCM			√	√	√		
Mazda	Asia	2000-2008	TITAN DASH			EPS			√	√	√		
Mazda	Asia	2000-2008	TITAN DASH			RCM			√	√	√		
Mazda	Asia	2000-2008	TITAN DASH			GEM			√	√	√		
Mazda	Asia	2000-2008	PROTEGE			PCM			√	√	√		
Mazda	Asia	2000-2008	PROTEGE			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	PROTEGE			ICM			√	√	√		
Mazda	Asia	2000-2008	PROTEGE			TCM			√	√	√		
Mazda	Asia	2000-2008	PROTEGE			EPS			√	√	√		

<http://www.autoboss.net>

<http://www.servicesolutions.com.cn>

Mazda	Asia	2000-2008	PROTEGE			RCM			√	√	√		
Mazda	Asia	2000-2008	PROTEGE			GEM			√	√	√		
Mazda	Asia	2000-2008	626/626 WAGON/TELSTAR			PCM			√	√	√		
Mazda	Asia	2000-2008	626/626 WAGON/TELSTAR			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	626/626 WAGON/TELSTAR			ICM			√	√	√		
Mazda	Asia	2000-2008	626/626 WAGON/TELSTAR			TCM			√	√	√		
Mazda	Asia	2000-2008	626/626 WAGON/TELSTAR			EPS			√	√	√		
Mazda	Asia	2000-2008	626/626 WAGON/TELSTAR			RCM			√	√	√		
Mazda	Asia	2000-2008	626/626 WAGON/TELSTAR			GEM			√	√	√		
Mazda	Asia	2000-2008	LASER/323/TIERRA			PCM			√	√	√		
Mazda	Asia	2000-2008	LASER/323/TIERRA			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	LASER/323/TIERRA			ICM			√	√	√		
Mazda	Asia	2000-2008	LASER/323/TIERRA			TCM			√	√	√		
Mazda	Asia	2000-2008	LASER/323/TIERRA			EPS			√	√	√		
Mazda	Asia	2000-2008	LASER/323/TIERRA			RCM			√	√	√		
Mazda	Asia	2000-2008	LASER/323/TIERRA			GEM			√	√	√		
Mazda	Asia	2000-2008	AZ/WAGON(MJ)			PCM			√	√	√		
Mazda	Asia	2000-2008	AZ/WAGON(MJ)			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	AZ/WAGON(MJ)			ICM			√	√	√		
Mazda	Asia	2000-2008	AZ/WAGON(MJ)			TCM			√	√	√		
Mazda	Asia	2000-2008	AZ/WAGON(MJ)			EPS			√	√	√		
Mazda	Asia	2000-2008	AZ/WAGON(MJ)			RCM			√	√	√		
Mazda	Asia	2000-2008	AZ/WAGON(MJ)			GEM			√	√	√		
Mazda	Asia	2000-2008	FAMILIA/LASER			PCM			√	√	√		
Mazda	Asia	2000-2008	FAMILIA/LASER			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	FAMILIA/LASER			ICM			√	√	√		
Mazda	Asia	2000-2008	FAMILIA/LASER			TCM			√	√	√		
Mazda	Asia	2000-2008	FAMILIA/LASER			EPS			√	√	√		
Mazda	Asia	2000-2008	FAMILIA/LASER			RCM			√	√	√		
Mazda	Asia	2000-2008	FAMILIA/LASER			GEM			√	√	√		
Mazda	Asia	2000-2008	XEDOS9			PCM			√	√	√		
Mazda	Asia	2000-2008	XEDOS9			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	XEDOS9			ICM			√	√	√		
Mazda	Asia	2000-2008	XEDOS9			TCM			√	√	√		

Mazda	Asia	2000-2008	XEDOS9			EPS			√	√	√		
Mazda	Asia	2000-2008	XEDOS9			RCM			√	√	√		
Mazda	Asia	2000-2008	XEDOS9			GEM			√	√	√		
Mazda	Asia	2000-2008	CAPELLA/CAPELA W/TELSTAR/TELSTAR W			PCM			√	√	√		
Mazda	Asia	2000-2008	CAPELLA/CAPELA W/TELSTAR/TELSTAR W			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	CAPELLA/CAPELA W/TELSTAR/TELSTAR W			ICM			√	√	√		
Mazda	Asia	2000-2008	CAPELLA/CAPELA W/TELSTAR/TELSTAR W			TCM			√	√	√		
Mazda	Asia	2000-2008	CAPELLA/CAPELA W/TELSTAR/TELSTAR W			EPS			√	√	√		
Mazda	Asia	2000-2008	CAPELLA/CAPELA W/TELSTAR/TELSTAR W			RCM			√	√	√		
Mazda	Asia	2000-2008	CAPELLA/CAPELA W/TELSTAR/TELSTAR W			GEM			√	√	√		
Mazda	Asia	2000-2008	DEMIO/121			PCM			√	√	√		
Mazda	Asia	2000-2008	DEMIO/121			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	DEMIO/121			ICM			√	√	√		
Mazda	Asia	2000-2008	DEMIO/121			TCM			√	√	√		
Mazda	Asia	2000-2008	DEMIO/121			EPS			√	√	√		
Mazda	Asia	2000-2008	DEMIO/121			RCM			√	√	√		
Mazda	Asia	2000-2008	DEMIO/121			GEM			√	√	√		
Mazda	Asia	2000-2008	DEMIO/FESTIVA MINI WAGON			PCM			√	√	√		
Mazda	Asia	2000-2008	DEMIO/FESTIVA MINI WAGON			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	DEMIO/FESTIVA MINI WAGON			ICM			√	√	√		
Mazda	Asia	2000-2008	DEMIO/FESTIVA MINI WAGON			TCM			√	√	√		
Mazda	Asia	2000-2008	DEMIO/FESTIVA MINI WAGON			EPS			√	√	√		

Mazda	Asia	2000-2008	DEMI0/FESTIVA MINI WAGON			RCM			√	√	√		
Mazda	Asia	2000-2008	DEMI0/FESTIVA MINI WAGON			GEM			√	√	√		
Mazda	Asia	2000-2008	FRIENDEE/FREDA/BONGO FRIENDEE			PCM			√	√	√		
Mazda	Asia	2000-2008	FRIENDEE/FREDA/BONGO FRIENDEE			ABS\TCS			√	√	√		
Mazda	Asia	2000-2008	FRIENDEE/FREDA/BONGO FRIENDEE			ICM			√	√	√		
Mazda	Asia	2000-2008	FRIENDEE/FREDA/BONGO FRIENDEE			TCM			√	√	√		
Mazda	Asia	2000-2008	FRIENDEE/FREDA/BONGO FRIENDEE			EPS			√	√	√		
Mazda	Asia	2000-2008	FRIENDEE/FREDA/BONGO FRIENDEE			RCM			√	√	√		
Mazda	Asia	2000-2008	FRIENDEE/FREDA/BONGO FRIENDEE			GEM			√	√	√		