

How to read this list:	
Mark	Description
√	Function is supported.
*	Newly added function or modified

V30/PC-MAX Function List													
Automaker:				Mercedes-Benz									
Software Version:				V7.6									
Brand	Reg ion	Year	Model	Vehicle	ECU Type	System	ECU Sup	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations	Special Functions
Mercedes	All	1998-2004	A-Class	168	Drive	ECM - Engine control monolith		√	√	√	√	√	
						CDI - Common Rail Diesel Injection		√	√	√	√	√	
						ACS - Automatic clutch system		√	√	√	√	√	
						FTC - Front transmission control		√	√	√	√	√	Control module adaptations Diagnosis routiness
						GRM - Gear recognition module		√	√	√	√	√	
					Chassis	ESP - Electronic stability program		√	√	√	√		
						Body	AB - Airbag		√	√	√	√	
					LCP - Lower control panel			√	√	√	√	√	
					ATA - Anti-theft alarm system			√	√	√	√	√	
					RFL - Radio frequency locking/electric central locking		√	√	√	√	√		
					Information and Communication	ICM - Instrument cluster with maintenance interval disp	√	√	√	√	√	√	
						PTS - Parktronic system		√	√	√	√	√	Read coding and change if necessary
						D2B - AUDIO		√	√	√	√	√	Read coding and change if necessary
						CDC - CD changer		√	√	√			
						CTEL - Cellular telephone 1(fixed installation or portab	√	√	√				
						APS - Auto pilot system		√	√	√			
					Seats and doors	DCM-FL - Door control module front left		√	√	√	√	√	
						DCM-FR - Door control module front right		√	√	√	√	√	
						DCM-RL - Door control module rear left		√	√	√	√	√	
						DCM-RR - Door control module rear right		√	√	√	√	√	
					Air Conditioning	HEAT/TAC - Automatic heater + PTC heater booster/A	√	√	√	√	√	√	
						STH/HB - Stationary heater/Heater booster		√	√	√	√	√	
					Drive	ESM - Electronic selector module		√	√	√	√	√	Read coding and change if necessary
FCVT - Continuously variable automatic transmission	√	√	√	√									

Mercedes	All	2004-2005	A-Class	169	DRIVE	ME-SFI - Motor electronics	✓	✓	✓	✓	✓	
						CDI - Common Rail Diesel Injection	✓	✓	✓	✓	✓	
					Chassis	ESP - Electronic stability program	✓	✓	✓	✓		
						ES - Electrical power steering	✓	✓	✓	✓		
					Body	AB - Airbag	✓	✓	✓	✓		
						CGW - Central gateway	✓	✓	✓			
						EIS - Electronic ignition switch(Without Keyless Go)	✓	✓	✓	✓		
						HRA-FR - Front right headlamp range control	✓	✓	✓	✓		
						HRA-FL - Front left headlamp range control	✓	✓	✓	✓	✓	
						OCP - Overhead control panel	✓	✓	✓	✓		
						UCP - Upper control panel	✓	✓	✓	✓	✓	
						SAM - Signal acquisition and actuation module	✓	✓	✓	✓	✓	
						AHE - Trailer recognition	✓	✓	✓	✓	✓	
						SVMCM - Special vehicle multifunction control module	✓	✓	✓			
						On-board electrical system(voltage supply)	✓	✓	✓	✓		
						ATA - Anti-theft alarm system	✓	✓	✓	✓	✓	
						Information and communication	IC - Instrument cluster	✓	✓	✓	✓	✓
					ASSYST Active Service System		✓	✓	✓	✓		AssystSetting
					ASSYST PLUS - PLUS Active Service System		✓	✓	✓	✓		General servicing Control unit adaptations
					SCM - Steering column module		✓	✓	✓	✓	✓	Initial startup
					PTS - Parktronic system		✓	✓	✓	✓	✓	
					AGW - Audio gateway(MOST network management,dis		✓	✓	✓	✓	✓	
					COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓	
					CDC - CD changer		✓	✓	✓	✓		
					TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓	
					CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓		
					Seats and Doors	DCM-FL - Door control module front left	✓	✓	✓	✓	✓	
DCM-FR - Door control module front right	✓	✓	✓	✓		✓						
DCM-RL - Door control module rear left	✓	✓	✓	✓		✓						
DCM-RR - Door control module rear right	✓	✓	✓	✓		✓						
Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air condit	✓	✓	✓	✓	✓						
Drive	ESM - Electronic selector module	✓	✓	✓	✓	✓	Read coding and change if necessary					
	FCVT - Continuously variable automatic transmission	✓	✓	✓	✓							

Mercedes	All	2005-2009	A-Class	169	Drive	ME-SFI - Motor electronics	✓	✓	✓	✓	✓		
						CDI - Common Rail Diesel Injection	✓	✓	✓	✓	✓		
					Chassis	ESP - Electronic stability program	✓	✓	✓	✓			
						ES - Electrical power steering	✓	✓	✓	✓			
					Body	AB - Airbag	✓	✓	✓	✓			
						EIS - Electronic ignition switch(Without Keyless Go)	✓	✓	✓				
						HRA-FR - Front right headlamp range control	✓	✓	✓	✓			
						HRA-FL - Front left headlamp range control	✓	✓	✓	✓			
						OCP - Overhead control panel	✓	✓	✓	✓	✓		
						UCP - Upper control panel	✓	✓	✓	✓			
						SAM - Signal acquisition and actuation module	✓	✓	✓	✓	✓		
						AHE - Trailer recognition	✓	✓	✓	✓	✓		
						SVMCM - Special vehicle multifunction control module	✓	✓	✓	✓	✓		
						On-board electrical system(voltage supply)	✓	✓	✓				
						ATA - Anti-theft alarm system	✓	✓	✓	✓			
						Information and communication	ICM - Instrument cluster with maintenance interval display	✓	✓	✓	✓	✓	
							SCM - Steering column module	✓	✓	✓	✓	✓	Initial startup
					PTS - Parktronic system		✓	✓	✓	✓	✓		
					AGW - Audio gateway(MOST network management,diagnostic)		✓	✓	✓	✓	✓		
					COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓		
					CDC - CD changer		✓	✓	✓	✓			
					TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓		
					CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓			
					Seats and Doors	DCM-FL - Door control module front left	✓	✓	✓	✓	✓		
						DCM-FR - Door control module front right	✓	✓	✓	✓	✓		
						DCM-RL - Door control module rear left	✓	✓	✓	✓	✓		
						DCM-RR - Door control module rear right	✓	✓	✓	✓	✓		
					Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air conditioning	✓	✓	✓	✓	✓		
					Drive	ESM - Electronic selector module		✓	✓	✓	✓	Read coding and change if necessary	
						CDI - Common Rail Diesel Injection		✓	✓	✓	✓		
						FCVT - Continuously variable automatic transmission		✓	✓	✓	✓		
						ME-SFI - Motor electronics		✓	✓	✓	✓		
					Chassis	ESP - Electronic stability program		✓	✓	✓	✓		
ES - Electrical power steering		✓	✓	✓		✓							

Mercedes	All	2005	B-Class	245	Body	AB - Airbag	✓	✓	✓	✓		
						CGW - Central gateway	✓	✓	✓			
						EIS - Electronic ignition switch(Without Keyless Go)	✓	✓	✓	✓		
						XALWA-L - Xenon headlamp,left	✓	✓	✓	✓		
						XALWA-R - Xenon headlamp,right	✓	✓	✓	✓		
						OCP - Overhead control panel	✓	✓	✓	✓		
						UCP - Upper control panel	✓	✓	✓	✓	✓	
						SAM - Signal acquisition and actuation module	✓	✓	✓	✓	✓	
						AHE - Trailer recognition	✓	✓	✓	✓	✓	
						SVMCM - Special vehicle multifunction control module	✓	✓	✓			
						On-board electrical system(voltage supply)	✓	✓	✓	✓		
						ATA - Anti-theft alarm system	✓	✓	✓	✓	✓	
					Information and communication	IC - Instrument cluster	✓	✓	✓	✓	✓	
						ASSYST Active Service System	✓	✓	✓	✓		
						ASSYST PLUS - PLUS Active Service System	✓	✓	✓	✓		
						SCM - Steering column module	✓	✓	✓	✓	✓	Initial startup
						PTS - Parktronic system	✓	✓	✓	✓	✓	
						AGW - Audio gateway(MOST network management,di	✓	✓	✓	✓	✓	
						COMAND/AUDIO - Audio50 or COMAND	✓	✓	✓	✓	✓	
						CDC - CD changer	✓	✓	✓	✓		
						TV - TV tuner(Not valid for Japan and USA)	✓	✓	✓	✓	✓	
					CTEL - Telephone adapter for portable CTEL	✓	✓	✓	✓			
					Seats and Doors	DCM-FL - Door control module front left	✓	✓	✓	✓	✓	
						DCM-FR - Door control module front right	✓	✓	✓	✓	✓	
						DCM-RL - Door control module rear left	✓	✓	✓	✓	✓	
						DCM-RR - Door control module rear right	✓	✓	✓	✓	✓	
					Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air condit	✓	✓	✓	✓	✓	
					Drive	ESM - Electronic selector module	✓	✓	✓	✓	✓	Read coding and change if necessary
						CDI - Common Rail Diesel Injection	✓	✓	✓	✓	✓	
						FCVT - Continuously variable automatic transmission	✓	✓	✓	✓		
						ME-SFI - Motor electronics	✓	✓	✓	✓	✓	
					Chassis	ESP - Electronic stability program	✓	✓	✓	✓		
						ES - Electrical power steering	✓	✓	✓	✓		
	AB - Airbag	✓	✓	✓	✓							

Mercedes	All	2005-2009	B-Class	245	Body	CGW - Central gateway		√	√	√			
						EIS - Electronic ignition switch(Without Keyless Go)		√	√	√	√		
						XALWA-L - Xenon headlamp,left		√	√	√	√		
						XALWA-R - Xenon headlamp,right		√	√	√	√		
						OCP - Overhead control panel		√	√	√	√		
						UCP - Upper control panel		√	√	√	√	√	
						SAM - Signal acquisition and actuation module		√	√	√	√	√	
						AHE - Trailer recognition		√	√	√	√	√	
						SVMCM - Special vehicle multifunction control module		√	√	√			
						On-board electrical system(voltage supply)		√	√	√	√		
						ATA - Anti-theft alarm system		√	√	√	√	√	
					Information and communication	IC - Instrument cluster		√	√	√	√	√	
						ASSYST Active Service System		√	√	√	√		
						ASSYST PLUS - PLUS Active Service System		√	√	√	√		
						SCM - Steering column module		√	√	√	√	√	Initial startup
						PTS - Parktronic system		√	√	√	√	√	
						AGW - Audio gateway(MOST network management,di		√	√	√	√	√	
						COMAND/AUDIO - Audio50 or COMAND		√	√	√	√	√	
						CDC - CD changer		√	√	√	√		
						TV - TV tuner(Not valid for Japan and USA)		√	√	√	√	√	
					CTEL - Telephone adapter for portable CTEL		√	√	√	√			
					Seats and Doors	DCM-FL - Door control module front left		√	√	√	√	√	
						DCM-FR - Door control module front right		√	√	√	√	√	
DCM-RL - Door control module rear left		√	√	√		√	√						
DCM-RR - Door control module rear right		√	√	√		√	√						
Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air condit		√	√	√		√						
Mercedes	All	1984-1993	C-CLASS	201	Body	AB		√	√	√	√		
					Drive	HFM		√	√	√	√		
						ME2		√	√	√	√		
						PMS		√	√	√	*		
						ERE		√	√	√	√		
					ABS		√	√	√	√			
					ASR		√	√	√	√			

Mercedes	All	1994-1996	C-CLASS	202	Chassis	ETS		✓	✓	✓	✓		
						ESP		✓	✓	✓	✓		
						BAS		✓	✓	✓	✓		
						EGS		✓	✓	✓	✓	✓	
					Body	RCL(DAS1/X)		✓	✓	✓	✓		
						RCL(DAS2/X)		✓	✓	✓	✓		
						ATA		✓	✓	✓	✓		
						AB		✓	✓	✓	✓		
						KI		✓	✓	✓	✓	✓	
						LWR		✓	✓	✓	✓		
Air conditioning	TAC		✓	✓	✓								
Mercedes	All	1997-2000	C-CLASS	202	Drive	ETC - Electronic transmission control		✓	✓	✓	✓	✓	
						ESM - Electronic selector module		✓	✓	✓	✓	✓	
						HFM-SFI - Hot film engine management		✓	✓	✓	✓		
						ME2-SFI - Motor electronics		✓	✓	✓	✓		
						CDI - Common Rail Diesel Injection		✓	✓	✓	✓	✓	
						IFI - Electronic in-line injection system diesel/DFI - Elec		✓	✓	✓	✓	✓	
					Chassis	Traction systems ABS,ASR,ETS,ESP		✓	✓	✓	✓	✓	Road test Learning processes Resetting of variant locking
						BAS - Brake assist		✓	✓	✓	✓		
					Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Coded vehicle data
						OCP - Overhead control panel		✓	✓	✓	✓	✓	
						EIS - Electronic ignition switch / KG - keyless Go(Spec		✓	✓	✓	✓		
						PSE - Pneumatic system equipment		✓	✓	✓	✓		Variant coding
						SAM - Signal acquisition and actuation module		✓	✓	✓	✓		
						LCP - Lower control panel		✓	✓	✓	✓		
						HRA - Headlamp rage adjustment		✓	✓	✓	✓		
						SVMCM - Special vehicle multifunction control module		✓	✓	✓			
					Information	ICM - Instrument cluster with maintenance interval disp		✓	✓	✓	✓	✓	Setting
						SCM - Steering column module(AS of model year 2002		✓	✓	✓	✓	✓	Initial startup
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						D2B - COMAND or AUDIO		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer		✓	✓	✓			

				and communication	VCS - Voice control system		✓	✓	✓			
					SOUND - Sound system		✓	✓	✓			
					CTEL - Cellular telephone 1(fixed installation or portabl		✓	✓	✓			
					TELE AID,E-call or cellular telephone - Emergency call		✓	✓	✓	✓	✓	
					DN - Dynamic navigation by means of CTEL(K-wire)		✓	✓	✓			
					APS - Auto pilot system		✓	✓	✓			
					SDAR - Satellite radio(USA)		✓	✓	✓	✓	✓	
				Seats and Doors	DCM1 - Door control module front driver side		✓	✓	✓	✓		
					DCM2 - Door control module front passenger side		✓	✓	✓	✓		
					DCM3 - Door control module rear driver side		✓	✓	✓	✓		
					DCM4 - Door control module rear passenger side		✓	✓	✓	✓		
					ESA-FL - Electric seat adjustment front left		✓	✓	✓	✓		
					ESA-FR - Electric seat adjustment front right		✓	✓	✓	✓		
				Air conditioning	TAC - Automatic temperature control/AAC - Automatic air conditioning		✓	✓	✓	✓		Read coding and change if necessary
STH - Stationary heater with remote control		✓	✓		✓							
Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit				
	ESM - Electronic selector module		✓	✓	✓	✓	✓					
	DTR - Distronic		✓	✓	✓	✓		Control unit adaptations				
	ME-SFI - Motor electronics		✓	✓	✓	✓						
	ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓					
	CDI2 - Common Rail Diesel Injection 2		✓	✓	✓	✓	✓	Adjustment On temperature of heater booster(Electric heater booster) Injector classification/Injector shutoff				
	CDI3 - Common Rail Diesel Injection 3		✓	✓	✓	✓	✓					
	Chassis	ESP - Electronic stability program		✓	✓	✓	✓	✓				
		BAS - Brake assist		✓	✓	✓	✓	✓				
		AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Chassis number			
OCP - Overhead control panel			✓	✓	✓	✓	✓	Setting of limit position of excess force limiter				
EIS - Electronic ignition switch			✓	✓	✓	✓						
HRA-FL - Front left headlamp range control			✓	✓	✓	✓						

Mercedes	All	2001-2003	C-CLASS	203	Body	HRA-FR - Front right headlamp range control		✓	✓	✓	✓	✓	Zero position adjustment
						LCP - Lower control panel		✓	✓	✓	✓	✓	
						UCP - Upper control panel		✓	✓	✓	✓	✓	Control unit adaptations
						SAM-F - Signal acquisition and actuation module front		✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓	Control unit adaptations
						AHE - Trailer recognition		✓	✓	✓	✓	✓	
						SVMCM - Special vehicle multifunction control module		✓	✓	✓			
					Information and communication	ICM - Instrument cluster with maintenance interval display		✓	✓	✓	✓	✓	✓
						SCM - Steering column module(AS of model year 2002)		✓	✓	✓	✓	✓	Initial startup
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						D2B - COMAND or AUDIO		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer		✓	✓	✓			
						VCS - Voice control system		✓	✓	✓	✓		
						SOUND - Sound system		✓	✓	✓			
						CTEL - Cellular telephone 1(fixed installation or portable)		✓	✓	✓			
						TELE AID,E-call or cellular telephone - Telematic system		✓	✓	✓	✓		
						TV - TV tuner(Not valid for Japan)		✓	✓	✓	✓		
					Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	
						DCM-FR - Door control module front right		✓	✓	✓	✓	✓	
						DCM-RL - Door control module rear left		✓	✓	✓	✓	✓	
						DCM-RR - Door control module rear right		✓	✓	✓	✓	✓	
						ESA driver - Electric seat adjustment front passenger		✓	✓	✓	✓	✓	
						ESA passenger - Electric seat adjustment front passenger		✓	✓	✓	✓	✓	
					Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air conditioning		✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
						STH - Stationary heater with remote control		✓	✓	✓	✓	✓	
					Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
						ESM - Electronic selector module		✓	✓	✓	✓	✓	Read coding and change if necessary
						ME-SFI - Motor electronics		✓	✓	✓	✓		
						ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓	
						ME 9.7 - Motor electronics 9.7		✓	✓	✓	✓	✓	

Mercedes	All	2004-2007	C-CLASS	203	CDI2 - Common Rail Diesel Injection 2		√	√	√	√	√	Adjustment On temperature of heater booster(Electric heater booster) Injector classification/Injector shutoff	
					CDI3 - Common Rail Diesel Injection 3		√	√	√	√	√		
					CDI4 - Common Rail Diesel Injection 4		√	√	√	√	√		
					Chassis	ESP - Electronic stability program		√	√	√	√	√	Road test Erase zero point offset error of component N49(steering angle sensor)
						CGW - Central gateway		√	√	√			
					Body	EIS - Electronic ignition switch / KG - keyless Go(Spec	√	√	√	√			
						AB - Airbag		√	√	√	√		Read coding and change if necessary Chassis number
						WSS - Weight sensing system(USA)		√	√	√			
						SAM-F - Signal acquisition and actuation module front	√	√	√	√	√		
						REAR SAM - Rear signal acquisition and actuation mod	√	√	√	√	√		
						HRA-FL - Front left headlamp range control		√	√	√	√		
						HRA-FR - Front right headlamp range control		√	√	√	√	√	Zero position adjustment
						OCP - Overhead control panel		√	√	√	√	√	Read coding and change if necessary
						LCP - Lower control panel		√	√	√	√	√	
						UCP - Upper control panel		√	√	√	√	√	
						System diagnosis		√	√	√	√		
						AHE - Trailer recognition		√	√	√	√	√	
						On-board electrical system(voltage supply)		√	√	√	√		
					Information and communication	ICM - Instrument cluster with maintenance interval disp	√	√	√	√	√	√	√
						SCM[MRM] - Steering column module		√	√	√	√	√	Initial startup
						PTS - Parktronic system		√	√	√	√	√	
						AGW - Audio gateway(MOST network management,dis	√	√	√	√	√	√	
						COMAND/AUDIO - Audio50 or COMAND		√	√	√	√	√	Read coding and change if necessary
						CDC - CD changer		√	√	√	√		
						TV - TV tuner(Not valid for Japan and USA)		√	√	√	√	√	
						CTEL - Telephone adapter for portable CTEL		√	√	√	√		
						VCS - Voice control system		√	√	√			
						SOUND - Sound system		√	√	√			
					TELE AID,E-call or cellular telephone - Telematic syste	√	√	√	√	√	√		
						DCM-FL - Door control module front left		√	√	√	√	√	Read coding and change if necessary Normalize left power window
DCM-FR - Door control module front right		√	√	√		√	√						

					Seats and Doors	DCM-RL - Door control module rear left		✓	✓	✓	✓	✓	
						DCM-RR - Door control module rear right		✓	✓	✓	✓	✓	
						ESA driver - Electric seat adjustment front passenger	✓	✓	✓	✓	✓	✓	
						ESA passenger - Electric seat adjustment front passenger	✓	✓	✓	✓	✓	✓	
					Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air conditioning	✓	✓	✓	✓	✓	✓	
						STH - Stationary heater with remote control		✓	✓	✓	✓		
Mercedes	All	2009	CLC	203	Drive	Transmission		✓	✓	✓	✓	✓	
						ESM - Electronic selector module		✓	✓	✓	✓	✓	
						ME-SFI - Motor electronics		✓	✓	✓	✓	✓	
						ME 9.7 - Motor electronic 9.7		✓	✓	✓	✓	✓	
						CDI D2 - Common Rail Diesel Injection( Chassis CAN)	✓	✓	✓	✓	✓	✓	
					Chassis	ESP - Electronic stability program		✓	✓	✓	✓	✓	
						EIS - Electronic ignition switch		✓	✓	✓	✓		
					Body	AB - Airbag		✓	✓	✓	✓		
						SAM-F - Signal acquisition and actuation module front	✓	✓	✓	✓	✓		
						REAR SAM - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓		
						XALWA-L - Xenon headlamp,left( Front end CAN bus )	✓	✓	✓	✓	✓		
						XALWA-R - Xenon headlamp,right( Front end CAN bus )	✓	✓	✓	✓	✓		
						OCP - Overhead control panel		✓	✓	✓	✓	✓	
						LCP - Lower control panel		✓	✓	✓	✓	✓	
						UCP - Upper control panel		✓	✓	✓	✓	✓	
						On-board electrical system(voltage supply)		✓	✓	✓	✓		
					Information and communication	ICM - Instrument cluster with maintenance interval display	✓	✓	✓	✓	✓		
						SCM[MRM] - Steering column module		✓	✓	✓	✓	✓	
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						AGW - Audio gateway(MOST network management,diagnostic)	✓	✓	✓	✓	✓		
						COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓	
						CDC - CD changer		✓	✓	✓	✓		
						TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓	
CTEL - Telephone adapter for portable CTEL		✓	✓	✓									
VCS - Voice control system		✓	✓	✓									
SOUND - Sound system		✓	✓	✓									
TELE AID,E-call or cellular telephone - Telematic system	✓	✓	✓	✓		✓							
	DCM-FL - Door control module front left		✓	✓	✓	✓	✓						

Mercedes	All	2008-2009	C-CLASS	204	Seats and Doors	DCM-FR - Door control module front right	✓	✓	✓	✓	✓	
						ESA driver - Electric seat adjustment front passenger	✓	✓	✓	✓	✓	
					ESA passenger - Electric seat adjustment front passenger	✓	✓	✓	✓	✓		
					Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air conditioning	✓	✓	✓	✓	✓	
						STH - Stationary heater with remote control	✓	✓	✓	✓		
					Drive	ME-SFI - Motor electronics( Chassis CAN bus )	✓	✓	✓	✓	✓	
						ME 9.7 - Motor electronics 9.7( Chassis CAN bus )	✓	✓	✓	✓	✓	
						CDI D - Common Rail Diesel Injection( Chassis CAN bus )	✓	✓	✓	✓	✓	
						CDI D2 - Common Rail Diesel Injection( Chassis CAN bus )	✓	✓	✓	✓	✓	
						CDI 6 - Common Rail Diesel Injection( Chassis CAN bus )	✓	✓	✓	✓	✓	
						FSCU - Fuel Pump( Drive train CAN bus )	✓	✓	✓	✓	✓	
						Transmission	✓	✓	✓	✓	✓	
						ESM - Electronic selector module( Drive train CAN bus )	✓	✓	✓	✓	✓	
					Chassis	ABR - Adaptive Brake( Chassis CAN bus )	✓	✓	✓	✓		
						Suspension( Chassis CAN bus )	✓	✓	✓	✓	✓	
						TPC - Tire pressure monitor( Interior CAN bus )	✓	✓	✓	✓	✓	
					Body	CGW - Central gateway( Central CAN bus )	✓	✓	✓	✓		
						EZS - Electronic ignition switch( Interior CAN bus )	✓	✓	✓	✓		
						KG - Keyless Go( Interior CAN bus )	✓	✓	✓			
						XALWA-L - Xenon headlamp,left( Front end CAN bus )	✓	✓	✓	✓	✓	
						XALWA-R - Xenon headlamp,right( Front end CAN bus )	✓	✓	✓	✓	✓	
						AB - Airbag	✓	✓	✓	✓		
						WSS - Weight sensor system (USA)( Interior CAN bus )	✓	✓	✓			
						System 'Dr-side SAM' with connected LIN components	✓	✓	✓	✓	✓	
						System 'REAR SAM' with connected LIN components	✓	✓	✓	✓	✓	
						OCP - Overhead control panel( Interior CAN bus )	✓	✓	✓	✓	✓	
						COU[ZBE] - Central operating unit( Telematic CAN bus )	✓	✓	✓	✓	✓	
					RevETR-LF - Left front reversible emergency tensioning	✓	✓	✓	✓			
RevETR-RF - Right front reversible emergency tensioning	✓	✓	✓	✓								
	ICM - Instrument cluster with maintenance interval display	✓	✓	✓	✓	✓	confirm overall maintenance					
	SCM[MRM] - Steering column module( Chassis CAN bus )	✓	✓	✓	✓	✓						
	PTS - Parktronic( Interior CAN bus )	✓	✓	✓	✓	✓						
	RFK - Backup camera Japan( Interior CAN bus )	✓	✓	✓	✓							
	COMAND - COMAND with integral telematics gateway	✓	✓	✓	✓	✓						

Mercedes	All	1998-2002	CLK	208	Information and communication	Tuner - Radio tuner with amplifier	✓	✓	✓			
						CTEL - Mobile telephone adapter with universal interface	✓	✓	✓	✓	✓	
						VCS - Voice control(Linguatronic)	✓	✓	✓	✓	✓	
						TV - TV tuner(Not valid for Japan and USA)	✓	✓	✓	✓		
						SDAR - Satellite radio (Valid for USA)	✓	✓	✓	✓	✓	
						ZAN - Central Display	✓	✓	✓	✓	✓	
						COU[ZBE] - Central operating unit( Telematic CAN bus)	✓	✓	✓	✓	✓	
						KBE-H -Rear A/C operating unit	✓	✓	✓			
					Seats and Doors	System 'Door control module front left' with connected	✓	✓	✓	✓	✓	
						System 'Door control module front right' with connected	✓	✓	✓	✓	✓	
						DCM-RL - Door control module rear left( Interior CAN bus)	✓	✓	✓	✓	✓	
						DCM-RR - Door control module rear right( Interior CAN bus)	✓	✓	✓	✓	✓	
						ESA driver - Electric seat adjustment driver( Interior CAN bus)	✓	✓	✓	✓	✓	
					Air conditioning	AAC - Automatic air conditioning( Interior CAN bus )	✓	✓	✓	✓	✓	
					Drive	Transmission	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
						ESM - Electronic selector module	✓	✓	✓	✓	✓	
						HFM-SFI - Hot film engine management	✓	✓	✓	✓		
						ME2-SFI - Motor electronics	✓	✓	✓	✓	✓	
					Chassis	Traction systems ABS,ASR,ETS,ESP	✓	✓	✓	✓	✓	
						BAS - Brake assist	✓	✓	✓	✓	✓	
						VP-Vacuum pump braker booster	✓	✓	✓	✓	✓	
Body	AB - Airbag	✓	✓	✓	✓		Read coding and change if necessary Coded vehicle data					
	OCP - Overhead control panel	✓	✓	✓	✓	✓						
	EIS - Electronic ignition switch ELCODE	✓	✓	✓	✓	✓						
	PSE -Pneumatic system equipment	✓	✓	✓	✓	✓	Variant coding					
	SAM - Signal acquisition and actuation module	✓	✓	✓	✓							
	LCP - Lower control panel	✓	✓	✓	✓							
HRA - Headlamp range adjustment	✓	✓	✓	✓	✓							



Mercedes	All	2003-2004	CLK	209	Body	HRA-FL - Front left headlamp range control		✓	✓	✓	✓		
						HRA-FR - Front right headlamp range control		✓	✓	✓	✓	✓	Zero position adjustment
						LCP - Lower control panel		✓	✓	✓	✓	✓	
						UCP - Upper control panel		✓	✓	✓	✓	✓	Control unit adaptations
						SAM-F - Signal acquisition and actuation module front	✓	✓	✓	✓	✓		
						REAR SAM - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓		
						RVC - Rollover bar soft top control module		✓	✓	✓	✓	✓	
						AHE - Trailer recognition		✓	✓	✓	✓	✓	
					Information and communication	ICM - Instrument cluster with maintenance interval display	✓	✓	✓	✓	✓	✓	✓
						SCM - Steering column module(AS of model year 2002)	✓	✓	✓	✓	✓	✓	initial startup
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						D2B - COMAND or AUDIO		✓	✓	✓	✓	✓	
						CDC - CD changer		✓	✓	✓			
						VCS - Voice control system		✓	✓	✓			
						SOUND - Sound system		✓	✓	✓	✓		
						CTEL - Cellular telephone 1(fixed installation or portable)	✓	✓	✓	✓			
						TELE-AID,E-call or cellular telephone - Telematic system	✓	✓	✓				
					TV - TV tuner(Not valid for Japan)		✓	✓	✓				
					Seats and Doors	DCM-L - Door control module left		✓	✓	✓	✓	✓	
						DCM-R - Door control module right		✓	✓	✓	✓	✓	
						ESA driver - Electric seat adjustment front passenger(vehicle)	✓	✓	✓	✓	✓	✓	
						ESA passenger - Electric seat adjustment front passenger(vehicle)	✓	✓	✓	✓	✓	✓	
					Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air conditioning	✓	✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors Teaching-in of rotary potentiometer for center nozzle and side outlets
					Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routines Read coding and/or transfer download to new control unit
						ESM - Electronic selector module		✓	✓	✓	✓	✓	
						ME-SFI - Motor electronics		✓	✓	✓	✓		

Mercedes	All	2005-2009	CLK	209	ENGINE	ME-SFI 2.8 - Motor electronics 2.8	✓	✓	✓	✓	✓	
						ME9.7-Motor electronics 9.7	✓	✓	✓	✓	✓	
						ME9.7(AMG) - Motor electronics 9.7(AMG)	✓	✓	✓	✓	✓	
						CDI2 - Common Rail Diesel Injection	✓	✓	✓	✓	✓	Adjustment On temperature of heater booster(Electric heater booster) Injector classification/Injector shutoff
						CDI3 - Common Rail Diesel Injection 3	✓	✓	✓	✓	✓	
						CDI4 - Common Rail Diesel Injection 4	✓	✓	✓	✓	✓	
					Chassis	ESP - Electronic stability program	✓	✓	✓	✓	✓	Road test
						TPC - Tire pressure monitor	✓	✓	✓	✓	✓	
					Body	AB - Airbag	✓	✓	✓	✓		
						OCP - Overhead control panel	✓	✓	✓	✓	✓	Read coding and change if necessary
						EIS - Electronic ignition switch/KG -Keyless Go(Special)	✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment	✓	✓	✓	✓	✓	Read coding and change if necessary Zero position adjustment of axle or level sensors
						LCP - Lower control panel	✓	✓	✓	✓	✓	Initial startup
						UCP - Upper control panel	✓	✓	✓	✓	✓	
						SAM-F - Signal acquisition and actuation module front	✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓	
						RVC - Rollover bar soft top control module	✓	✓	✓	✓	✓	
						AHE - Trailer recognition	✓	✓	✓	✓	✓	
					On-board electrical system (voltage supply)	✓	✓	✓	✓			
					Information and communication	ICM - Instrument cluster with maintenance interval display	✓	✓	✓	✓	✓	✓
						SCM - Steering column module(AS of model year 2002)	✓	✓	✓	✓	✓	Initial startup
						PTS - Parktronic system	✓	✓	✓	✓	✓	
						AGW - Audio gateway	✓	✓	✓	✓	✓	
						COMAND/AUDIO - Audio50 or COMAND	✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer	✓	✓	✓	✓		
						HFS - Hands free system and microphone	✓	✓	✓	✓		
					CTEL - Telephone adapter for portable CTEL	✓	✓	✓	✓	✓		
					Seats and Doors	DCM-L - Door control module left	✓	✓	✓	✓	✓	
						DCM-R - Door control module right	✓	✓	✓	✓	✓	
						ESA driver - Electric seat adjustment front passenger(vehicle)	✓	✓	✓	✓	✓	
						ESA passenger - Electric seat adjustment front passenger(vehicle)	✓	✓	✓	✓	✓	
						TLC - Trunk lid control	✓	✓	✓	✓	✓	

					Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air conditi	✓	✓	✓	✓	✓	
						STH - Stationary heater with remote control	✓	✓	✓	✓	✓	
Mercedes	All	1984-1995	E-CLASS	124	Drive	HFM	✓	✓	✓	✓		
						PMS	✓	✓	✓	✓		
						DM(Diagntic Module)	✓	✓	✓	✓		
						EFP	✓	✓	✓	✓	✓	
						TPM	✓	✓	✓	✓	✓	
						ISC	✓	✓	✓	✓	✓	
					Chassis	EAG	✓	✓	✓	✓	✓	
					Body	RCL(DAS1/X)	✓	✓	✓	✓		
						RCL(DAS2/X)	✓	✓	✓	✓		
						ATA(Anti-Theft Alarm)	✓	✓	✓	✓		
						AB(Air bag)	✓	✓	✓	✓		
					Mercedes	All	1984-1995	E-CLASS	124 034/03 6	Drive	LH1	✓
DM(Diagntic Module)	✓	✓	✓	✓								
EFP	✓	✓	✓	✓							✓	
TPM	✓	✓	✓	✓							✓	
ISC	✓	✓	✓	✓							✓	
GM	✓	✓	✓	✓								
Chassis	ASR	✓	✓	✓						✓		
	ABS	✓	✓	✓						✓		
Body	ATA(Anti-Theft Alarm)	✓	✓	✓						✓		
	AB(Air bag)	✓	✓	✓						✓		
	RCL(DAS1)	✓	✓	✓						✓		
										Drive	HFM	✓
					ME2	✓	✓	✓	✓			
					ME1RE	✓	✓	✓	✓			
					DM	✓	✓	✓	✓			
					EVE	✓	✓	✓	✓		✓	
					EFP	✓	✓	✓	✓		✓	
					TPM	✓	✓	✓	✓		✓	
					ISC	✓	✓	✓	✓		✓	
					ABS	✓	✓	✓	✓			
					ASR	✓	✓	✓	✓			

Mercedes	All	1996-1997	E-CLASS	210	Chassis	ETS	✓	✓	✓	✓		
						ESP	✓	✓	✓	✓		
						BAS	✓	✓	✓	✓		
						ADS	✓	✓	✓	✓		
						EGS	✓	✓	✓	✓	✓	
						EAG	✓	✓	✓	✓	✓	
						PML	✓	✓	✓	✓		
					Body	RFL	✓	✓	✓	✓		
						RCL(DAS1/X)	✓	✓	✓	✓		
						RCL(DAS2/X)	✓	✓	✓	✓		
						KFB	✓	✓	✓	✓		
						PSE	✓	✓	✓	✓		
						ATA	✓	✓	✓	✓		
						AB	✓	✓	✓	✓		
						KI	✓	✓	✓	✓	✓	
						PTS	✓	✓	✓	✓	✓	
						LWR	✓	✓	✓	✓		
						APS	✓	✓	✓			
						Audio,COMMAND	✓	✓	✓	✓	✓	
						Tele-AID	✓	✓	✓			
						CDC	✓	✓	✓	✓	✓	
						E-Call	✓	✓	✓	✓	✓	
						SKF	✓	✓	✓	✓	✓	
					Air conditioning	Air Conditioning	✓	✓	✓	✓	✓	
						STH	✓	✓	✓	✓	✓	
					Drive	Transmission	✓	✓	✓	✓	✓	
						ESM - Electronic selector module	✓	✓	✓	✓	✓	Initail startup
						HFM-SFI - Hot film engine management	✓	✓	✓	✓		
						ME2-SFI - Motor electronics	✓	✓	✓	✓		
						IFI- Electronic in-line injection system diesel/DFI- Elect	✓	✓	✓	✓		
CDI - Common Rail Diesel Injection	✓	✓	✓	✓								
ABS	✓	*	✓	✓		✓						
ASR	✓	✓	✓	✓	✓	Road test Learning processes Resetting of variant locking						

Mercedes	All	1998-2002	E-CLASS	210	Chassis	ETS	✓	✓	✓	✓	✓	
						ESP	✓	✓	✓	✓	✓	
						ADS - Adaptive damping system	✓	✓	✓	✓		
						BAS - Brake assist	✓	✓	✓	✓		
						VP - Vacuum pump brake booster	✓	✓	✓	✓	✓	
						SPS - Speed-sensitive power steering	✓	✓	✓			
					Body	AB - Airbag	✓	*	✓	✓		Read coding and change if necessary Coded vehicle data
						OCP - Overhead control panel	✓	✓	✓	✓	✓	
						EIS - Electronic ignition switch ELCODE	✓	✓	✓	✓		
						PSE - Pneumatic system equipment	✓	✓	✓	✓		Variant coding
						SAM - Signal acquisition and actuation module	✓	✓	✓	✓		
						LCP - Lower control panel	✓	✓	✓	✓		
						HRA - Headlamp range adjustment	✓	✓	✓	✓		
						SVMCM - Special vehicle multifunction control module	✓	✓	✓			
					Information and communication	ICM - Instrument cluster	✓	✓	✓	✓	✓	Clock Reset odometer to 0 km Oil change
						D2B - COMAND or AUDIO	✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer	✓	✓	✓	✓	✓	
						VCS - Voice control system	✓	✓	✓			
						CTEL - Cellular telephone 1(fixed installation or portable)	✓	✓	✓			
						APS - Auto pilot system	✓	✓	✓			
						PTS - Parktronic system	✓	✓	✓	✓	✓	
						TELE AID,E-call or cellular telephone	✓	✓	✓	✓	✓	
						DN - Dynamic navigation by means of CTEL(K-wire)	✓	✓	✓			
						TV - TV tuner	✓	✓	✓			
					Seats and Doors	DCM1 - Door control module front driver side	✓	✓	✓	✓		
						DCM2 - Door control module front passenger side	✓	✓	✓	✓		
						DCM3 - Door control module rear driver side	✓	✓	✓	✓		
						DCM4 - Door control module rear passenger side	✓	✓	✓	✓		
						ESA-FL - Electric seat adjustment front left	✓	✓	✓	✓		
						ESA-FR - Electric seat adjustment front right	✓	✓	✓	✓		
					Air conditioning	TAC - Automatic temperature control/AAC - Automatic air conditioning	✓	✓	✓	✓		Read coding and change if necessary
						STH - Stationary heater	✓	✓	✓			

Mercedes	All	2003-2005	E-CLASS	211	Drive	Transmission	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
						ESM - Electronic selector module	✓	✓	✓	✓	✓	Read coding and change if necessary
						DTR - Distronic	✓	✓	✓	✓		
						ME-SFI - Motor electronics	✓	✓	✓	✓		
						ME-SFI 2.8- Motor electronics 2.8	✓	✓	✓	✓	✓	
						CDI 3 - Common Rail Diesel Injection 3	✓	✓	✓	✓	✓	
					Chassis	SBC - Sensotronic Brake Control	✓	✓	✓	✓		Deactive system Active system bleed brake system Control unit adaptations
						ESP - Electronic stability program	✓	✓	✓	✓	✓	
						Suspension	✓	✓	✓	✓	✓	Initial startup
						TPC - Tire pressure monitor	✓	✓	✓	✓	✓	Initial startup Control unit adaptations
					Body	AB - Airbag	✓	✓	✓	✓		Read coding and change if necessary Chassis number
						WSS - Weight sensor system	✓	✓	✓			
						RevETR-LF - Left front reversible emergency tensionin	✓	✓	✓	✓		
						RevETR-RF - Right front reversible emergency tension	✓	✓	✓	✓		
						CGW - Central gateway	✓	✓	✓			
						EIS - Electronic ignition switch/KG - Keyless GO(Speci	✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment	✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors
						OCP - Overhead control panel	✓	✓	✓	✓	✓	Read coding and change if necessary Panoramic sliding roof
						UCP - Upper control panel	✓	✓	✓	✓	✓	
						LCP - Lower control panel	✓	✓	✓	✓	✓	
						Dr-side SAM - Dr. signal acquisition and actuation	✓	✓	✓	✓	✓	
						Pass-side SAM - Pass-side signal acquisition and actu	✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation mod	✓	✓	✓	✓	✓	
System diagnosis	✓	✓	✓	✓								
BCM - Battery control module	✓	✓	✓	✓	✓							
AHE - Trailer recognition	✓	✓	✓	✓	✓	✓						
SVMCM -Special vehicle multifunction control	✓	✓	✓									

					On-board electrical system (voltage supply)		✓	✓	✓	✓		
				Information and communication	IC - Instrument cluster		✓	✓	✓	✓	✓	
					ASSYST Active Service System		✓	✓	✓	✓		AssystSetting
					ASSYST PLUS - PLUS Active Service System		✓	✓	✓	✓		General servicing Control unit adaptations
					SCM[MRM] - Steering column module		✓	✓	✓	✓	✓	Initial startup
					PTS - Parktronic system		✓	✓	✓	✓	✓	
					AGW - Audio gateway		✓	✓	✓	✓	✓	
					COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓	Read coding and change if necessary
					NAVI - Navigation(Only in combination with COMAND)		✓	✓	✓	✓	✓	
					CDC - CD changer		✓	✓	✓	✓		
					HFS - Hands free system and microphone		✓	✓	✓			
					TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓	
					CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓	✓	
					MB Portal - Telematic services WAP,E-mail,Mercedes-		✓	✓	✓			
				Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	Read coding and change if necessary
					DCM-FR - Door control module front right		✓	✓	✓	✓	✓	Read coding and change if necessary
					DCM-RL - Door control module rear left		✓	✓	✓	✓	✓	Read coding and change if necessary
					DCM-RR - Door control module rear right		✓	✓	✓	✓	✓	Read coding and change if necessary
					ESA driver - Electric seat adjustment driver		✓	✓	✓	✓	✓	
					ESA passenger - Electric seat adjustment FR. Pass.		✓	✓	✓	✓	✓	
					DS-LF - Left front dynamic seat		✓	✓	✓	✓	✓	
					DS-RF - Right front dynamic seat		✓	✓	✓	✓	✓	
					DSP - Pneumatic pump for dynamic seat		✓	✓	✓	✓	✓	
					TLC - Trunk lid control		✓	✓	✓	✓	✓	
				HS - Seat heater		✓	✓	✓				
				Air conditioning	C-AAC - Convenience automatic air conditioning		✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
					STH - Stationary heater with remote control		✓	✓	✓	✓	✓	
					HSW - Heated steering wheel		✓	✓	✓	✓	✓	
					Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
					ESM - Electronic selector module		✓	✓	✓	✓	✓	Read coding and change if necessary

<b>Mercedes</b>	All	2005-2006	E-CLASS	211	Drive	DTR - Distronic		✓	✓	✓	✓	✓	
						ME-SFI - Motor electronics		✓	✓	✓	✓		
						ME-SFI 2.8- Motor electronics 2.8		✓	✓	✓	✓	✓	
						ME 9.7 - Motor electronics 9.7		✓	✓	✓	✓	✓	Learning of the throttle valve stop
						CDI 3 - Common Rail Diesel Injection 3		✓	✓	✓	✓	✓	
						CDI 4 - Common Rail Diesel Injection 4		✓	✓	✓	✓	✓	
						CDI 5 - Common Rail Diesel Injection 5		✓	✓	✓	✓	✓	
					Chassis	SBC - Sensotronic Brake Control		✓	✓	✓	✓		Deactive system Active system bleed brake system Control unit adaptations
						ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test
						Suspension		✓	✓	✓	✓	✓	Initial startup
						TPC - Tire pressure monitor		✓	✓	✓	✓	✓	Initial startup Control unit adaptations
					Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Chassis number
						WSS - Weight sensor system		✓	✓	✓			
						RevETR-LF - Left front revesible emergency tensioning		✓	✓	✓	✓		
						RevETR-RF - Right front revesible emergency tensioning		✓	✓	✓	✓		
						CGW - Central gateway		✓	✓	✓			
						EIS - Electronic ignition switch/KG - Keyless GO(Special)		✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors
						OCP - Overhead control panel		✓	✓	✓	✓	✓	Read coding and change if necessary Panornamic sliding roof
						UCP - Upper control panel		✓	✓	✓	✓	✓	
						LCP - Lower control panel		✓	✓	✓	✓	✓	
						Dr-side SAM - Dr. signal acquisition and actuation		✓	✓	✓	✓	✓	
						Pass-side SAM - Pass-side signal acquisition and actuation		✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓	
						System diagnosis		✓	✓	✓	✓		
						BCM - Battery control module		✓	✓	✓	✓	✓	
					AHE - Trailer recognition		✓	✓	✓	✓	✓		
					SVMCM -Special vehicle multifunction control		✓	✓	✓				
					On-board electrical system (voltage supply)		✓	✓	✓	✓			

					IC - Instrument cluster		✓	✓	✓	✓	✓	
					ASSYST Active Service System		✓	✓	✓	✓		AssystSetting
					ASSYST PLUS - PLUS Active Service System		✓	✓	✓	✓		General servicing Control unit adaptations
					SCM[MRM] - Steering column module		✓	✓	✓	✓	✓	
					PTS - Parktronic system		✓	✓	✓	✓	✓	
					AGW - Audio gateway		✓	✓	✓	✓	✓	
					COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓	Read coding and change if necessary
					NAVI - Navigation(Only in combination with COMAND)		✓	✓	✓	✓	✓	
					CDC - CD changer		✓	✓	✓	✓		
					HFS - Hands free system and microphone		✓	✓	✓			
					TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓	
					CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓	✓	
					MB Portal - Telematic services WAP,E-mail,Mercedes-		✓	✓	✓			
				Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	Read coding and change if necessary
					DCM-FR - Door control module front right		✓	✓	✓	✓	✓	Read coding and change if necessary
					DCM-RL - Door control module rear left		✓	✓	✓	✓	✓	Read coding and change if necessary
					DCM-RR - Door control module rear right		✓	✓	✓	✓	✓	Read coding and change if necessary
					ESA driver - Electric seat adjustment driver		✓	✓	✓	✓	✓	
					ESA passenger - Electric seat adjustment FR. Pass.		✓	✓	✓	✓	✓	
					DS-LF - Left front dynamic seat		✓	✓	✓	✓	✓	
					DS-RF - Right front dynamic seat		✓	✓	✓	✓	✓	
					DSP - Pneumatic pump for dynamic seat		✓	✓	✓	✓	✓	
					TLC - Trunk lid control		✓	✓	✓	✓	✓	
					HS - Seat heater		✓	✓	✓			
				Air conditioning	C-AAC - Convenience automatic air conditioning/AAC		✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
					STH - Stationary heater with remote control		✓	✓	✓	✓	✓	
					HSW - Heated steering wheel		✓	✓	✓	✓	✓	
					Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
					ESM - Electronic selector module		✓	✓	✓	✓	✓	
					DTR - Distronic		✓	✓	✓	✓	✓	

Mercedes	All	2006-2008	E-CLASS	211	Drive	ME-SFI - Motor electronics		✓	✓	✓	✓	✓	
						ME 9.7		✓	✓	✓	✓	✓	Learning of the throttle valve stop
						ME 9.7(AMG)		✓	✓	✓	✓	✓	
						CDI D-Common Rail Diesel Injection		✓	✓	✓	✓	✓	
						CDI 4 - Common Rail Diesel Injection 4		✓	✓	✓	✓	✓	
						CDI 5 - Common Rail Diesel Injection 5		✓	✓	✓	✓	✓	
					Chassis	ABR - Adaptive Brake		✓	✓	✓	✓	✓	
						Suspension		✓	✓	✓	✓	✓	Initial startup
						TPC - Tire pressure monitor		✓	✓	✓	✓	✓	Initial startup Control unit adaptations
					Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Chassis number
						WSS - Weight sensor system		✓	✓	✓			
						RevETR-LF - Left front reversible emergency tensioning		✓	✓	✓	✓		
						RevETR-RF - Right front reversible emergency tensioning		✓	✓	✓	✓		
						CGW - Central gateway		✓	✓	✓			
						EIS - Electronic ignition switch/KG - Keyless GO(Special)		✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors
						XALWA-L - Xenon headlamp,left		✓	✓	✓	✓	✓	
						XALWA-R - Xenon headlamp,right		✓	✓	✓	✓	✓	
						OCP - Overhead control panel		✓	✓	✓	✓	✓	Read coding and change if necessary Panoramic sliding roof
						UCP - Upper control panel		✓	✓	✓	✓	✓	
						LCP - Lower control panel		✓	✓	✓	✓	✓	
						Dr-side SAM - Dr. signal acquisition and actuation		✓	✓	✓	✓	✓	
						Pass-side SAM - Pass-side signal acquisition and actuation		✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓	
						System diagnosis		✓	✓	✓	✓		
					AHE - Trailer recognition		✓	✓	✓	✓	✓		
SVMCM -Special vehicle multifunction control		✓	✓	✓									
On-board electrical system (voltage supply)		✓	✓	✓	✓	✓							
IC - Instrument cluster		✓	✓	✓	✓	✓							
ASSYST Active Service System		✓	✓	✓	✓		AssystSetting						

Information and communication	ASSYST PLUS - PLUS Active Service System	✓	✓	✓	✓		General servicing Control unit adaptations	
	SCM[MRM] - Steering column module	✓	✓	✓	✓	✓		
	PTS - Parktronic system	✓	✓	✓	✓	✓		
	AGW - Audio gateway	✓	✓	✓	✓	✓		
	COMAND/AUDIO - Audio50 or COMAND	✓	✓	✓	✓	✓	Read coding and change if necessary	
	NAVI - Navigation(Only in combination with COMAND)	✓	✓	✓	✓	✓		
	CDC - CD changer	✓	✓	✓	✓			
	HFS - Hands free system and microphone	✓	✓	✓				
	TV - TV tuner(Not valid for Japan and USA)	✓	✓	✓	✓	✓		
	CTEL - Telephone adapter for portable CTEL	✓	✓	✓	✓	✓		
	MB Portal - Telematic services WAP,E-mail,Mercedes-	✓	✓	✓				
	Seats and Doors	DCM-FL - Door control module front left	✓	✓	✓	✓	✓	Read coding and change if necessary
		DCM-FR - Door control module front right	✓	✓	✓	✓	✓	Read coding and change if necessary
DCM-RL - Door control module rear left		✓	✓	✓	✓	✓	Read coding and change if necessary	
DCM-RR - Door control module rear right		✓	✓	✓	✓	✓	Read coding and change if necessary	
ESA driver - Electric seat adjustment driver		✓	✓	✓	✓	✓		
ESA passenger - Electric seat adjustment FR. Pass.		✓	✓	✓	✓	✓		
DS-LF - Left front dynamic seat		✓	✓	✓	✓	✓		
DS-RF - Right front dynamic seat		✓	✓	✓	✓	✓		
DSP - Pneumatic pump for dynamic seat		✓	✓	✓	✓	✓		
TLC - Trunk lid control		✓	✓	✓	✓	✓		
HS - Seat heater		✓	✓	✓				
Air conditioning	C-AAC - Convenience automatic air conditioning/AAC	✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors	
	STH - Stationary heater with remote control	✓	✓	✓	✓	✓		
	HSW - Heated steering wheel	✓	✓	✓	✓	✓		
Drive	Transmission	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routines	
	ESM - Electronic selector module	✓	✓	✓	✓	✓	Read coding and change if necessary	
	DTR - Distronic	✓	✓	✓	✓		Control module adaptations	
	ME 9.7 - Motor electronics 9.7	✓	✓	✓	✓	✓		
	ME 9.7(AMG) - Motor electronics 9.7(AMG)	✓	✓	✓	✓	✓		

Mercedes	All	2005	CLS	219	ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓		
					CDI 4 - Common Rail Diesel Injection 4		✓	✓	✓	✓	✓		
					SBC - Sensotronic Brake Control		✓	✓	✓	✓		Deactive system Active system bleed brake system Control unit adaptations	
					ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test	
					AIRmatic		✓	✓	✓	✓	✓	Initial startup	
					TPC - Tire pressure monitor		✓	✓	✓	✓	✓	Initial startup Control unit adaptations	
					AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Chassis number	
					WSS - Weight sensor system (USA)		✓	✓	✓				
					RevETR-LF - Left front reversible emergency tensinoin	✓	✓	✓	✓				
					RevETR-RF - Right front reversible emergency tensinoin	✓	✓	✓	✓				
					CGW - Central gateway		✓	✓	✓				
					EIS - Electronic ignition switch/KG - Keyless GO(Speci	✓	✓	✓	✓	✓			
					HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors	
					OCP - Overhead control panel		✓	✓	✓	✓	✓	Read coding and change if necessary Panornamic sliding roof	
					UCP - Upper control panel		✓	✓	✓	✓	✓		
					LCP - Lower control panel		✓	✓	✓	✓	✓		
					Dr-side SAM - Dr. signal acquisition and actuation	✓	✓	✓	✓	✓			
					Pass-side SAM - Pass-side signal acquisition and actu	✓	✓	✓	✓	✓			
					REAR SAM - Rear signal acquisition and actuation mod	✓	✓	✓	✓	✓			
					System diagnosis		✓	✓	✓	✓			
					BCM - Battery control module		✓	✓	✓	✓	✓		
					On-board electrical system (voltage supply)		✓	✓	✓	✓	✓		
					IC - Instrument cluster		✓	✓	✓	✓			
					ASSYST Active Service System		✓	✓	✓	✓		AssystSetting	
					ASSYST PLUS - PLUS Active Service System		✓	✓	✓	✓		General servicing Control unit adaptations	
					SCM[MRM] - Steering column module		✓	✓	✓	✓	✓	Initail startup	
					PTS - Parktronic system		✓	✓	✓	✓	✓		
					AGW - Audio gateway(MOST network management,dis	✓	✓	✓	✓	✓	✓		

					COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓	Read coding and change if necessary
					CDC - CD changer		✓	✓	✓	✓		
					TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓	
					CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓		
				Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	Read coding and change if necessary
					DCM-FR - Door control module front right		✓	✓	✓	✓	✓	Read coding and change if necessary
					DCM-RL - Door control module rear left		✓	✓	✓	✓	✓	Read coding and change if necessary
					DCM-RR - Door control module rear right		✓	✓	✓	✓	✓	Read coding and change if necessary
					ESA driver - Electric seat adjustment driver(with memo	✓	✓	✓	✓	✓	✓	
					ESA passenger - Electric seat adjustment FR. Pass.(w	✓	✓	✓	✓	✓	✓	
					DS-LF - Left front dynamic seat		✓	✓	✓	✓	✓	
					DS-RF - Right front dynamic seat		✓	✓	✓	✓	✓	
					DSP - Pneumatic pump for dynamic seat		✓	✓	✓	✓	✓	
					TLC - Trunk lid control		✓	✓	✓	✓	✓	
				HS - Seat heater		✓	✓	✓	✓	✓		
				Air conditioning	C-AAC - Convenience automatic air conditioning/AAC	✓	✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
					STH - Stationary heater with remote control		✓	✓	✓	✓	✓	
					HSW - Heated steering wheel		✓	✓	✓	✓	✓	
				Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routines
					ESM - Electronic selector module		✓	✓	✓	✓	✓	
					DTR - Distronic		✓	✓	✓	✓		
					ME 9.7 - Motor electronics 9.7		✓	✓	✓	✓	✓	
					ME 9.7(AMG) - Motor electronics 9.7(AMG)		✓	✓	✓	✓	✓	
					ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓	
				CDI 4 - Common Rail Diesel Injection 4		✓	✓	✓	✓	✓		
				Chassis	SBC - Sensotronic Brake Control		✓	✓	✓	✓		Deactive system Active system bleed brake system Control unit adaptations
					ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test
					AIRmatic		✓	✓	✓	✓	✓	Initial startup

Mercedes	All	2005-2006	CLS	219	TPC - Tire pressure monitor		✓	✓	✓	✓	✓	Initial startup Control unit adaptations
					AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Chassis number
					WSS - Weight sensor system (USA)		✓	✓	✓			
					RevETR-LF - Left front reversible emergency tensinoin		✓	✓	✓	✓		
					RevETR-RF - Right front reversible emergency tensind		✓	✓	✓	✓		
					CGW - Central gateway		✓	✓	✓			
					EIS - Electronic ignition switch/KG - Keyless GO(Speci		✓	✓	✓	✓	✓	
					HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors
					OCP - Overhead control panel		✓	✓	✓	✓	✓	Read coding and change if necessary Panormamic sliding roof
					UCP - Upper control panel		✓	✓	✓	✓	✓	
					LCP - Lower control panel		✓	✓	✓	✓	✓	
					Dr-side SAM - Dr. signal acquisition and actuation		✓	✓	✓	✓	✓	
					Pass-side SAM - Pass-side signal acquisition and actu		✓	✓	✓	✓	✓	
					REAR SAM - Rear signal acquisition and actuation mod		✓	✓	✓	✓	✓	
					System diagnosis		✓	✓	✓	✓		
					BCM - Battery control module		✓	✓	✓	✓	✓	
					On-board electrical system (voltage supply)		✓	✓	✓	✓	✓	
					IC - Instrument cluster		✓	✓	✓	✓		
					ASSYST Active Service System		✓	✓	✓	✓		AssystSetting
					ASSYST PLUS - PLUS Active Service System		✓	✓	✓	✓		General servicing Control unit adaptations
					SCM[MRM] - Steering column module		✓	✓	✓	✓	✓	
					PTS - Parktronic system		✓	✓	✓	✓	✓	
					AGW - Audio gateway(MOST network management,dis		✓	✓	✓	✓	✓	
					COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓	Read coding and change if necessary
					CDC - CD changer		✓	✓	✓	✓		
					TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓	
					CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓		
					DCM-FL - Door control module front left		✓	✓	✓	✓	✓	Read coding and change if necessary
					DCM-FR - Door control module front right		✓	✓	✓	✓	✓	Read coding and change if necessary
					DCM-RL - Door control module rear left		✓	✓	✓	✓	✓	Read coding and change if necessary

				Seats and Doors	DCM-RR - Door control module rear right		✓	✓	✓	✓	✓	Read coding and change if necessary
					ESA driver - Electric seat adjustment driver(with memo		✓	✓	✓	✓	✓	
					ESA passenger - Electric seat adjustment FR. Pass.(w		✓	✓	✓	✓	✓	
					DS-LF - Left front dynamic seat		✓	✓	✓	✓	✓	
					DS-RF - Right front dynamic seat		✓	✓	✓	✓	✓	
					DSP - Pneumatic pump for dynamic seat		✓	✓	✓	✓	✓	
					TLC - Trunk lid control		✓	✓	✓	✓	✓	
					HS - Seat heater		✓	✓	✓	✓	✓	
				Air conditioning	C-AAC - Convenience automatic air conditioning/AAC		✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
					STH - Stationary heater with remote control		✓	✓	✓	✓	✓	
					HSW - Heated steering wheel		✓	✓	✓	✓	✓	
				Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
					ESM - Electronic selector module		✓	✓	✓	✓	✓	
					DTR - DISTRONIC		✓	✓	✓	✓	✓	
					ME 9.7		✓	✓	✓	✓	✓	
					ME 9.7(AMG)		✓	✓	✓	✓	✓	
					ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓	
				Chassis	CDI 4 - Common Rail Diesel Injection 4		✓	✓	✓	✓	✓	
					ABR - Adaptive Brake		✓	✓	✓	✓	✓	
					Suspension		✓	✓	✓	✓	✓	Initial startup
					TPC - Tire pressure monitor		✓	✓	✓	✓	✓	Initial startup Control unit adaptations
					AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Chassis number
					WSS - Weight sensor system (USA)		✓	✓	✓			
					RevETR-LF - Left front reversible emergency tensinoin		✓	✓	✓	✓		
					RevETR-RF - Right front reversible emergency tensinc		✓	✓	✓	✓		
					CGW - Central gateway		✓	✓	✓			
				EIS - Electronic ignition switch/KG - Keyless GO(Speci		✓	✓	✓	✓	✓		

Mercedes	All	2006-2009	CLS	219	Body	HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors
						OCP - Overhead control panel		✓	✓	✓	✓	✓	Read coding and change if necessary Panoramic sliding roof
						UCP - Upper control panel		✓	✓	✓	✓	✓	
						LCP - Lower control panel		✓	✓	✓	✓	✓	
						Dr-side SAM - Dr. signal acquisition and actuation	✓	✓	✓	✓	✓		
						Pass-side SAM - Pass-side signal acquisition and actuation	✓	✓	✓	✓	✓		
						REAR SAM - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓		
						System diagnosis		✓	✓	✓	✓		
						BCM - Battery control module		✓	✓	✓	✓	✓	
						On-board electrical system (voltage supply)		✓	✓	✓	✓	✓	
					Information and communication	IC - Instrument cluster		✓	✓	✓	✓		
						ASSYST Active Service System		✓	✓	✓	✓	AssystSetting	
						ASSYST PLUS - PLUS Active Service System	✓	✓	✓	✓		General servicing Control unit adaptations	
						SCM[MRM] - Steering column module		✓	✓	✓	✓		
						PTS - Parktronic system		✓	✓	✓	✓		
						AGW - Audio gateway(MOST network management, diagnosis)	✓	✓	✓	✓	✓		
						COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer		✓	✓	✓	✓		
						TV - TV tuner(Not valid for Japan and USA)	✓	✓	✓	✓	✓		
						CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓		
					Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	Read coding and change if necessary
						DCM-FR - Door control module front right		✓	✓	✓	✓	✓	Read coding and change if necessary
						DCM-RL - Door control module rear left		✓	✓	✓	✓	✓	Read coding and change if necessary
						DCM-RR - Door control module rear right		✓	✓	✓	✓	✓	Read coding and change if necessary
						ESA driver - Electric seat adjustment driver(with memo)	✓	✓	✓	✓	✓		
						ESA passenger - Electric seat adjustment FR. Pass.(with memo)	✓	✓	✓	✓	✓		
						DS-LF - Left front dynamic seat		✓	✓	✓	✓	✓	
						DS-RF - Right front dynamic seat		✓	✓	✓	✓	✓	
						DSP - Pneumatic pump for dynamic seat		✓	✓	✓	✓	✓	
						TLC - Trunk lid control		✓	✓	✓	✓	✓	
						HS - Seat heater		✓	✓	✓	✓	✓	

					Air conditioning	C-AAC - Convenience automatic air conditioning/AAC	✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
						STH - Stationary heater with remote control	✓	✓	✓	✓	✓	
						HSW - Heated steering wheel	✓	✓	✓	✓	✓	
<b>Mercedes</b>	All	1984-1991	S-CLASS	126	Body	AB	✓	✓	✓	✓		
<b>Mercedes</b>	All	1992-1999	S-CLASS	140	Drive	HFM	✓	✓	✓	✓		
						ME2	✓	✓	✓	✓		
						ME1RE	✓	✓	✓	✓		
						ME1LI	✓	✓	✓	✓		
						LH1	✓	✓	✓	✓		
						LH2	✓	✓	✓	✓		
						DM	✓	✓	✓	✓		
						ERE	✓	✓	✓	✓		
						EFP	✓	✓	✓	✓		
						TPM	✓	✓	✓	✓		
						ISC	✓	✓	✓	✓		
						GM	✓	✓	✓	✓		
						Chassis	ABS	✓	✓	✓	✓	
					ASR		✓	✓	✓	✓		
					ETS		✓	✓	✓	✓		
					ESP		✓	✓	✓	✓		
					BAS		✓	✓	✓	✓		
					ADS		✓	✓	✓	✓		
					EGS		✓	✓	✓	✓	✓	
					EAG		✓	✓	✓	✓	✓	
					PML		✓	✓	✓	✓		
					RFL		✓	✓	✓	✓		
					RCL(DAS1/X)	✓	✓	✓	✓			
RCL(DAS2/X)	✓	✓	✓	✓								
KFB	✓	✓	✓	✓								
PSE	✓	✓	✓	✓								
ATA	✓	✓	✓	✓								
AB	✓	✓	✓	✓								



Mercedes	All	2000-2003	S-CLASS	220	Body	EIS - Electronic ignition switch ELCODE(DAS 3)	✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment	✓	✓	✓	✓	✓	
						UCP - Upper control panel	✓	✓	✓	✓	✓	
						PSE - Pneumatic system equipment	✓	✓	✓	✓	✓	Lower or raise head restraints Read coding and change if necessary
						SAM-FL - Front left signal acquisition and actuation module	✓	✓	✓	✓	✓	
						SAM-FR - Front right signal acquisition and actuation module	✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓	
						AHE - Trailer recognition	✓	✓	✓	✓	✓	Control unit adaptations
						KG - Keyless Go	✓	✓	✓	✓	✓	
					SVMCM - Special vehicle multifunction control module	✓	✓	✓				
					Information and communication	ICM - Instrument cluster with maintenance interval display	✓	✓	✓	✓	✓	ASSYST settings
						SCM - Steering column module	✓	✓	✓	✓	✓	Initial startup
						PTS - Parktronic system	✓	✓	✓	✓	✓	
						D2B - COMAND or AUDIO	✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer	✓	✓	✓			
						VCS - Voice control system	✓	✓	✓			
						SOUND - Sound system	✓	✓	✓	✓		
						CTEL - Cellular telephone 1(fixed installation or portable)	✓	✓	✓			
						TV - TV tuner	✓	✓	✓			
						TELE AID,E-call or cellular telephone - Telematic system	✓	✓	✓	✓	✓	
						DN - Dynamic navigation by means of CTEL(K-wire)	✓	✓	✓			
					Seats and Doors	DCM-FL - Door control module front left	✓	✓	✓	✓	✓	
						DCM-FR - Door control module front right	✓	✓	✓	✓	✓	
						DCM-RL - Door control module rear left	✓	✓	✓	✓	✓	
						DCM-RR - Door control module rear right	✓	✓	✓	✓	✓	
						ESA-FL - Electric seat adjustment front left	✓	✓	✓	✓	✓	
						ESA-FR - Electric seat adjustment front right	✓	✓	✓	✓	✓	
						ESA-R - Electric seat adjustment rear	✓	✓	✓		✓	
						OSB-FL - Multicontour backrest front left	✓	✓	✓	✓	✓	
						OSB-FR - Multicontour backrest front right	✓	✓	✓	✓	✓	
						OSB-R - Multicontour backrest rear	✓	✓	✓	✓		
					Air	AAC - Automatic air conditioning	✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary
						REAR AC - Rear air conditioning	✓	✓	✓	✓	✓	

					conditioning	STH - Stationary heater(Up to 05/2000)		✓	✓	✓	✓	✓	
						STH - Stationary heater(As of 05/2000)		✓	✓	✓	✓	✓	
						HSW - Heated steering wheel		✓	✓	✓			
					Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routines
						ESM - Electronic selector module		✓	✓	✓	✓	✓	Detach the transport protection of control module N15/5(electronic selector lever module control module),personalizer or activate the control module.
						DTR - Distronic		✓	✓	✓	✓		Control unit adaptations
						ME2- SFI - Motor electronics		✓	✓	✓	✓	✓	
						ME- SFI 2.7 - Motor electronics 2.7		✓	✓	✓	✓	✓	
						CDI 3- Common Rail Diesel Injection 3		✓	✓	✓	✓		
						CDI-V - Common Rail Diesel Injection		✓	✓	✓	✓		
					Chassis	ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test Learning processes Resetting of variant locking
						AIRmatic		✓	✓	✓	✓	✓	Initial startup Level calibration
						TPC - Tire pressor monitor		✓	✓	✓	✓	✓	Control unit adaptations
						ABC - ABC active body control		✓	✓	✓	✓	✓	Calibration of the plunger travel sensors Level calibration Load adjustment
					Body	AB - Airbag		✓	✓	✓	✓	✓	Read coding and change if necessary Chassis number
						CGW - Central gateway		✓	✓	✓			
						RevETR-LF - Left front reversible emergency tensinoin		✓	✓	✓	✓		
						RevETR-RF - Right front reversible emergency tensinc		✓	✓	✓	✓		
						OCP - Overhead control panel		✓	✓	✓	✓	✓	
						EIS - Electronic ignition switch ELCODE(DAS 3)		✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	
						HLCM-L - Left headlamp control module		✓	✓	✓	✓	✓	
						HLCM-R - Right headlamp control module		✓	✓	✓	✓		
						UCP - Upper control panel		✓	✓	✓	✓	✓	
						PSE - Pneumatic system equipment		✓	✓	✓	✓	✓	Lower or raise head restraints Read coding and change if necessary
					SAM-FL - Front left signal acquisition and actuation mo		✓	✓	✓	✓	✓		

Mercedes	All	2004-2006	S-CLASS	220	SAM-FR - Front right signal acquisition and actuation module	✓	✓	✓	✓	✓		
					REAR SAM - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓		
					System diagnosis(Only interior CAN fault)	✓	✓	✓	✓			
					AHE - Trailer recognition	✓	✓	✓	✓	✓	Control unit adaptations	
					KG - Keyless Go	✓	✓	✓	✓	✓		
					SVMCM - Special vehicle multifunction control module	✓	✓	✓				
					Information and communication	ICM - Instrument cluster with maintenance interval display	✓	✓	✓	✓	✓	ASSYST settings
						SCM - Steering column module	✓	✓	✓	✓	✓	Initial startup
						PTS - Parktronic system	✓	✓	✓	✓	✓	
						AGW/D2B - Audio gateway(MOST network management)	✓	✓	✓	✓	✓	
						COMAND/SOUND - COMAND(Display and operating)	✓	✓	✓	✓		
						CDC - CD changer	✓	✓	✓	✓		
						HFS - Handsfree system and microphone	✓	✓	✓		✓	
						TV - TV tuner(Not valid for Japan and USA)	✓	✓	✓	✓		
						CTEL - Fixed installation cellular telephone/Cellular telephone	✓	✓	✓	✓		
						NAVI - Navigation ( Only in combination with COMAND)	✓	✓	✓			
						VCS - Voice control system	✓	✓	✓			
						TELE AID,E-call or cellular telephone - Telematic system	✓	✓	✓	✓	✓	
						Seats and Doors	DCM-FL - Door control module front left	✓	✓	✓	✓	✓
					DCM-FR - Door control module front right		✓	✓	✓	✓	✓	
					DCM-RL - Door control module rear left		✓	✓	✓	✓	✓	
					DCM-RR - Door control module rear right		✓	✓	✓	✓	✓	
					ESA-FL - Electric seat adjustment front left		✓	✓	✓	✓	✓	
					ESA-FR - Electric seat adjustment front right		✓	✓	✓	✓	✓	
					ESA-R - Electric seat adjustment rear		✓	✓	✓	✓	✓	
					DS-LF - Left front dynamic seat		✓	✓	✓	✓	✓	
					DS-RF - Right front dynamic seat		✓	✓	✓	✓	✓	
					OSB-FL - Multicontour backrest front left		✓	✓	✓	✓	✓	
					OSB-FR - Multicontour backrest front right		✓	✓	✓	✓	✓	
					OSB-R - Multiicontour backrest rear	✓	✓	✓	✓			
					Air conditioning	AAC - Automatic air conditioning	✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary
						REAR AC - Rear air conditioning	✓	✓	✓	✓	✓	
						STH - Stationary heater	✓	✓	✓	✓	✓	
						HSW - Heated steering wheel	✓	✓	✓			

<b>Mercedes</b>	All	2007-2009	S-CLASS	221	Drive	Transmission( Drive train CAN bus )	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
						ISM - Intelligent servo module( Drive train CAN bus )	✓	✓	✓	✓	✓	
						ME 9.7 - Motor electronics 9.7( Chassis CAN bus )	✓	✓	✓	✓	✓	
						CDI 5 -Common Rail Diesel Injection( Chassis CAN bus )	✓	✓	✓	✓	✓	
						DTR - Distronic( Vehicle dynamics CAN bus )	✓	✓	✓	✓		
						SGR - Rader sensors control unit( Chassis CAN bus )	✓	✓	✓	✓	✓	
					Chassis	ABR - Adaptive Brake( Chassis CAN bus )	✓	✓	✓	✓	✓	
						Electronic parking brake - Electric parking brake( Front	✓	✓	✓	✓	✓	
						Suspension( Chassis CAN bus )	✓	✓	✓	✓	✓	
						ABC - ABC active body control	✓	✓	✓	✓	✓	Initial startup
						TPC - Tire pressure monitor( Interior CAN bus )	✓	✓	✓	✓	✓	
					Body	CGW - Central gateway( Central CAN bus )	✓	✓	✓			
						EIS - Electronic ignition switch( Interior CAN bus )	✓	✓	✓	✓	✓	
						KG - Keyless Go( Interior CAN bus )	✓	✓	✓	✓	✓	
						AB - Airbag( Chassis CAN bus )	✓	✓	✓	✓	✓	
						WSS - Weight sensing system(USA)( Interior CAN bus	✓	✓	✓			
						Dr-side SAM - Driver signal acquisition and actuation m	✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation mod	✓	✓	✓	✓		
						XALWA-L - Xenon headlamp,left( Front end CAN bus )	✓	✓	✓	✓	✓	
						XALWA-R - Xenon headlamp,right( Front end CAN bus	✓	✓	✓	✓	✓	
						OCP - Overhead control panel( Interior CAN bus )	✓	✓	✓	✓	✓	
						UCP - Upper control panel( Interior CAN bus )	✓	✓	✓	✓	✓	
						RevETR-LF - Left front reversible emergency tensionin	✓	✓	✓	✓		
						RevETR-RF - Right front reversible emergency tension	✓	✓	✓	✓		
						System diagnosis( Diagnose CAN bus )	✓	✓	✓			
						BNS - Vehicle power supply control module( Chassis C	✓	✓	✓	✓	✓	
						IC - Instrument cluster( Central CAN bus )	✓	✓	✓	✓	✓	Setting main odometer forward and back Setting days since initial registration Resetting menu settings to manufacturer default settings
ASSYST Active Service System( Diagnose CAN bus )	✓	✓	✓	✓		✓	AssystSetting					

Information and communication	ASSYST PLUS - PLUS Active Service System( Diagnostics )	✓	✓	✓	✓	✓	General servicing Internal Assyst plus data(Reading of main odometer) Internal Assyst plus data(Days since initial registration) Average mileage per day
	SCM - Steering column module( Chassis CAN bus )	✓	✓	✓	✓	✓	
	NSA - Night vision assist( Vehicle dynamics CAN bus )	✓	✓	✓	✓	✓	
	PTS - Parktronic system( Interior CAN bus )	✓	✓	✓	✓	✓	
	RFK - Backup column module( Interior CAN bus )	✓	✓	✓	✓		
	COMAND - COMAND with integral telematics gateway	✓	✓	✓	✓	✓	
	Tuner - Radio tuner with amplifier	✓	✓	✓			
	CTEL - Mobile telephone adapter with universal interface	✓	✓	✓	✓	✓	
	VCS - Voice control(Linguatronic)	✓	✓	✓	✓	✓	
	TV - TV tuner(Not valid for Japan and USA)	✓	✓	✓	✓		
	SDAR - Satellite radio (Valid for USA)	✓	✓	✓	✓	✓	
	ZAN - Central Display	✓	✓	✓			
	COU[ZBE] - Central operating unit( Telematic CAN bus )	✓	✓	✓	✓	✓	
Seats and Doors	DCM-FL - Door control module front left( Interior CAN bus )	✓	✓	✓	✓	✓	Initialization of power closing
	DCM-FR - Door control module front right( Interior CAN bus )	✓	✓	✓	✓	✓	Initialization of power closing
	DCM-RL - Door control module rear left( Interior CAN bus )	✓	✓	✓	✓	✓	Initialization of power closing
	DCM-RR - Door control module rear right( Interior CAN bus )	✓	✓	✓	✓	✓	Initialization of power closing
	ESA-FL - Electric seat adjustment front left( Interior CAN bus )	✓	✓	✓	✓	✓	
	ESA-FR - Electric seat adjustment front right( Interior CAN bus )	✓	✓	✓	✓	✓	
	ESA-R - Electric seat adjustment rear( Interior CAN bus )	✓	✓	✓	✓	✓	
	DS-LF - Left front dynamic seat( Interior CAN bus )	✓	✓	✓	✓		
	DS-RF - Right front dynamic seat( Interior CAN bus )	✓	✓	✓	✓		
	DSP - Pneumatic pump for dynamic seat( Interior CAN bus )	✓	✓	✓	✓		
	TLC - Trunk lid control( Interior CAN bus )	✓	✓	✓	✓	✓	
Air conditioning	AAC - Automatic air conditioning( Interior CAN bus )	✓	✓	✓	✓	✓	
	KBE-H - Rear A/C operating unit( Telematic CAN bus )	✓	✓	✓			

Mercedes	All	1999-2002	CL	215	Drive	Transmission	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
						ESM - Electronic selector module	✓	✓	✓	✓	✓	Detach the transport protection of control module N15/5(electronic selector lever module control module),personalizer or activate the control module.
						DTR - Distronic	✓	✓	✓	✓		Control unit adaptations
						ME2- SFI - Motor electronics	✓	✓	✓	✓	✓	
						ME- SFI 2.7 - Motor electronics 2.7	✓	✓	✓	✓	✓	
					Chassis	ESP - Electronic stability program	✓	✓	✓	✓	✓	Road test Learning processes Resetting of variant locking
						ABC - ABC active body control	✓	✓	✓	✓	✓	Calibration of the plunger travel sensors Level calibration Load adjustment
						TPC - Tire pressure monitor	✓	✓	✓	✓	✓	Control unit adaptations
					Body	AB - Airbag	✓	✓	✓	✓		Read coding and change if necessary Coded vehicle data
						OCP - Overhead control panel	✓	✓	✓	✓	✓	Setting of limit position of excess force limiter Read coding and change if necessary
						EIS - Electronic ignition switch ELCODE(DAS 3)	✓	✓	✓	✓		
						UCP - Upper control panel	✓	✓	✓	✓	✓	
						PSE - Pneumatic system equipment	✓	✓	✓	✓	✓	Lower or raise head restraints Read coding and change if necessary
						SAM-FL - Front left signal acquisition and actuation module	✓	✓	✓	✓	✓	
						SAM-FR - Front right signal acquisition and actuation module	✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓	
						AHE - Trailer recognition	✓	✓	✓	✓	✓	Control unit adaptations
						KG - Keyless Go	✓	✓	✓	✓	✓	
					Information and	SVMCM - Special vehicle multifunction control module	✓	✓	✓			
						ICM - Instrument cluster with maintenance interval display	✓	✓	✓	✓	✓	ASSYST settings
SCM - Steering column module	✓	✓	✓	✓		✓	Initial startup					
PTS - Parktronic system	✓	✓	✓	✓		✓						
D2B - COMAND or AUDIO	✓	✓	✓	✓		✓	Read coding and change if necessary					
CDC - CD changer	✓	✓	✓									

				and communication	VCS - Voice control system		✓	✓	✓			
					SOUND - Sound system		✓	✓	✓	✓		
					CTEL - Cellular telephone 1(fixed installation or portabl		✓	✓	✓			
					TV - TV tuner		✓	✓	✓			
					TELE AID,E-call or cellular telephone - Telematic syste		✓	✓	✓	✓	✓	
					DN - Dynamic navigation by means of CTEL(K-wire)		✓	✓	✓			
				Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	
					DCM-FR - Door control module front right		✓	✓	✓	✓	✓	
					RCM - Rear control module		✓	✓	✓	✓	✓	
					ESA-FL - Electric seat adjustment front left		✓	✓	✓	✓	✓	
					ESA-FR - Electric seat adjustment front right		✓	✓	✓	✓	✓	
					OSB-FL - Multicontour backrest front left		✓	✓	✓	✓	✓	
					OSB-FR - Multicontour backrest front right		✓	✓	✓	✓	✓	
				Air conditioning	AAC - Automatic air conditioning		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary
					STH - Stationary heater(Up to 05/2000)		✓	✓	✓	✓	✓	
					STH - Stationary heater(As of 05/2000)		✓	✓	✓	✓	✓	
					HSW - Heated steering wheel		✓	✓	✓			
				Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routines
					ESM - Electronic selector module		✓	✓	✓	✓	✓	Detach the transport protection of control module N15/5(electronic selector lever module control module),personalizer or activate the control module.
					DTR - Distronic		✓	✓	✓	✓		Control unit adaptations
					ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓	
					ME-SFI 2.7.1		✓	✓	✓	✓	✓	
				Chassis	ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test Learning processes Resetting of variant locking
					ABC - ABC active body control		✓	✓	✓	✓	✓	Calibration of the plunger travel sensors Level calibration Load adjustment
					TPC - Tire pressure monitor		✓	✓	✓	✓	✓	Control unit adaptations
					AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Chassis number
					CGW - Central gateway		✓	✓	✓			

Mercedes	All	2003-2006	CL	215	Body	OCPC - Overhead control panel		✓	✓	✓	✓	✓	
						EIS - Electronic ignition switch ELCODE(DAS 3)		✓	✓	✓	✓		
						HLCM-L - Left headlamp control module		✓	✓	✓	✓	✓	
						HLCM-R - Right headlamp control module		✓	✓	✓	✓		
						UCP - Upper control panel		✓	✓	✓	✓	✓	
						PSE - Pneumatic system equipment		✓	✓	✓	✓	✓	Lower or raise head restraints Read coding and change if necessary
						SAM-FL - Front left signal acquisition and actuation module		✓	✓	✓	✓	✓	
						SAM-FR - Front right signal acquisition and actuation module		✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓	
						System diagnosis(Only interior CAN fault)		✓	✓	✓	✓		
						AHE - Trailer recognition		✓	✓	✓	✓	✓	Control unit adaptations
						KG - Keyless Go		✓	✓	✓	✓	✓	
						SVMCM - Special vehicle multifunction control module		✓	✓	✓			
					Information and communication	ICM - Instrument cluster with maintenance interval display		✓	✓	✓	✓	✓	ASSYST settings
						SCM - Steering column module		✓	✓	✓	✓	✓	initial startup
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						AGW - Audio gateway(MOST network management, display and control)		✓	✓	✓	✓	✓	
						COMAND - COMAND(Display and operating unit)		✓	✓	✓	✓		
						CDC - CD changer		✓	✓	✓	✓		
						HFS - Handsfree system and microphone		✓	✓	✓		✓	
						TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓		
						CTEL - Fixed installation cellular telephone		✓	✓	✓	✓		
					NAVI - Navigation ( Only in combination with COMAND)		✓	✓	✓	✓	✓		
					Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	
						DCM-FR - Door control module front right		✓	✓	✓	✓	✓	
						RCM - Rear control module		✓	✓	✓	✓	✓	
						ESA-FL - Electric seat adjustment front left		✓	✓	✓	✓	✓	
						ESA-FR - Electric seat adjustment front right		✓	✓	✓	✓	✓	
						OSB-FL - Multicontour backrest front left		✓	✓	✓	✓	✓	
						OSB-FR - Multicontour backrest front right		✓	✓	✓	✓	✓	
					Air conditioning	AAC - Automatic air conditioning		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary
						REAR AC - Rear air conditioning		✓	✓	✓	✓	✓	
						STH - Stationary heater		✓	✓	✓	✓	✓	

Mercedes	All	2008-2009	CL	216	HSW - Heated steering wheel	✓	✓	✓					
					Drive	Transmission( Drive train CAN bus )	✓	✓	✓	✓	✓		
						ISM - Intelligent servo module( Drive train CAN bus )	✓	✓	✓	✓	✓		
						ME 9.7 - Motor electronics 9.7( Chassis CAN bus )	✓	✓	✓	✓	✓		
						ME 2.7.2 - Motor electronics 2.7.2( Chassis CAN bus )	✓	✓	✓	✓	✓		
						FSCU - Fuel pump( Drive train CAN bus )	✓	✓	✓	✓	✓		
						DTR - Distronic( Vehicle dynamics CAN bus )	✓	✓	✓	✓			
						SGR - Rader sensors control unit( Chassis CAN bus )	✓	✓	✓	✓	✓		
					Chassis	ABR - Adaptive Brake( Chassis CAN bus )	✓	✓	✓	✓			
						Electronic parking brake - Electric parking brake( Front	✓	✓	✓	✓	✓		
						TPC - Tire pressure monitor( Interior CAN bus )	✓	✓	✓	✓	✓		
						Suspension( Chassis CAN bus )	✓	✓	✓	✓	✓		
					Body	AB - Airbag( Chassis CAN bus )	✓	✓	✓	✓			
						WSS - Weight sensing system(USA)( Interior CAN bus	✓	✓	✓				
						CGW - Central gateway( Central CAN bus )	✓	✓	✓				
						EZS - Electronic ignition switch( Interior CAN bus )	✓	✓	✓	✓			
						KG - Keyless Go( Interior CAN bus )	✓	✓	✓	✓	✓		
						XALWA-L - Xenon headlamp,left( Front end CAN bus )	✓	✓	✓	✓	✓		
						XALWA-R - Xenon headlamp,right( Front end CAN bus	✓	✓	✓	✓	✓		
						OCP - Overhead control panel( Interior CAN bus )	✓	✓	✓	✓	✓		
						UCP - Upper control panel( Interior CAN bus )	✓	✓	✓	✓	✓		
						COU[ZBE] - Central operating unit( Telematic CAN bus	✓	✓	✓	✓	✓		
						HBF(Rear control panel) - Rear control field( Telematic	✓	✓	✓	✓	✓		
						Dr-side SAM - Driver signal acquisition and actuation m	✓	✓	✓	✓	✓		
						REAR SAM - Rear signal acquisition and actuation mod	✓	✓	✓	✓			
						System diagnosis( Diagnose CAN bus )	✓	✓	✓				
						BNS - Vehicle power supply control module( Chassis C	✓	✓	✓	✓	✓		
						AHE - Trailer recognition( Interior CAN bus )	✓	✓	✓	✓	✓		
							NSA - Night vision assist( Vehicle dynamics CAN bus )	✓	✓	✓	✓	✓	
							IC - Instrument cluster( Central CAN bus )	✓	✓	✓	✓	✓	
					ASSYST Active Service System( Diagnose CAN bus )		✓	✓	✓	✓			
					ASSYST PLUS - PLUS Active Service System( Diagn		✓	✓	✓	✓			
					SCM - Steering column module( Chassis CAN bus )		✓	✓	✓	✓	✓		
RFK - Backup column module( Interior CAN bus )	✓	✓	✓	✓	✓								

				Information and communication	PTS - Parktronic system( Interior CAN bus )		✓	✓	✓	✓	✓	
					COMAND - COMAND with integral telematics gateway		✓	✓	✓	✓	✓	
					Tuner - Radio tuner with amplifier		✓	✓	✓			
					CTEL - Mobile telephone adapter with universal interfa		✓	✓	✓	✓	✓	
					VCS - Voice control(Linguatronic)		✓	✓	✓	✓	✓	
					TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓	
					SDAR - Satellite radio (Valid for USA)		✓	✓	✓	✓	✓	
					ZAN - Central Display		✓	✓	✓			
					COU[ZBE] - Central operating unit( Telematic CAN bus		✓	✓	✓	✓	✓	
					KBE-H -Rear A/C operating unit		✓	✓	✓	✓	✓	
				Seats and Doors	DCM-FL - Door control module front left( Interior CAN b		✓	✓	✓	✓	✓	
					DCM-FR - Door control module front right( Interior CAN		✓	✓	✓	✓	✓	
					ESA-FL - Electric seat adjustment front left( Interior CA		✓	✓	✓	✓	✓	
					ESA-FR - Electric seat adjustment front right( Interior C		✓	✓	✓	✓	✓	
					DS-LF - Left front dynamic seat( Interior CAN bus )		✓	✓	✓	✓		
					DS-RF - Right front dynamic seat( Interior CAN bus )		✓	✓	✓	✓		
					DSP - Pneumatic pump for dynamic seat( Interior CAN		✓	✓	✓	✓		
					TLC - Trunk lid control( Interior CAN bus )		✓	✓	✓	✓	✓	
				RCM - Rear control module( Interior CAN bus )		✓	✓	✓	✓	✓		
Air conditioning	AAC - Automatic air conditioning( Interior CAN bus )		✓	✓	✓	✓	✓					
Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit				
	ESM - Electronic selector module		✓	✓	✓	✓	✓					
	DTR - Distronic		✓	✓	✓							
	ME-SFI 2.7.1 - Motor electronics 2.7.1		✓	✓	✓	✓	✓					
	ME-SFI 2.7.2 - Motor electronics 2.7.2		✓	✓	✓	✓	✓					
	SGR - Radar sensors control unit		✓	✓	✓	✓	✓					
Chassis	SBCL - Sensotronic Brake Control Left		✓	✓	✓	✓		Deactive system Active system Control unit adaptations				
	SBCL - Sensotronic Brake Control Right		✓	✓	✓	✓						

Mercedes	All	2000-2009	Maybach	240	Chassis	ESP - Electronic stability program		✓	✓	✓	✓	✓		
						AIRmatic - AIRmatic		✓	✓	✓	✓	✓		
						TPC - Tire pressor monitor		✓	✓	✓	✓			
					Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Chassis number	
						BNS - Vehicle power supply control module		✓	✓	✓				
						CGW - Central gateway		✓	✓	✓				
						EIS - Electronic ignition switch/KG - Keyless Go(Special)	✓	✓	✓	✓	✓			
						HRA - Headlamp range adjustment		✓	✓	✓	✓	✓		
						OCP - Overhead control panel		✓	✓	✓	✓	✓		
						CRN - Center roof node		✓	✓	✓				
						VBF(Front control panel) - Front control panel	✓	✓	✓	✓				
						HBFB(Rear control panel) - Rear control field		✓	✓	✓	✓			
						PSE - Pneumatic system equipment		✓	✓	✓				
						Dr-side SAM - Dr. signal acquisition and actuation module	✓	✓	✓	✓	✓			
						Pass-side SAM - Pass-side signal acquisition and actuation module	✓	✓	✓	✓	✓			
						REAR SAM 1 - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓			
						REAR SAM 2 - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓			
						System diagnosis(only interior CAN fault)		✓	✓	✓	✓			
						SVMCM - Special vehicle multifunction control module	✓	✓	✓	✓	✓			
					Information and communication	ICM - Instrument cluster		✓	✓	✓	✓			
						SCM[MRM] - Steering column module		✓	✓	✓	✓	initial startup		
						PTS - Parktronic system		✓	✓	✓	✓	✓		
						AGW - Audio gateway		✓	✓	✓	✓			
						COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓		
						CDC - CD changer		✓	✓	✓	✓			
						CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓			
						NAVI - Navigation (Valid for China and Korea)		✓	✓	✓				
						VCS -Voice control		✓	✓	✓				
						TV - TV tuner		✓	✓	✓				
						SOUND - Bose sound system		✓	✓	✓				
					TELE - TELE AID		✓	✓	✓					
					Door	DCM-FL - Door control module front left		✓	✓	✓	✓	✓		
						DCM-FR - Door control module front right		✓	✓	✓	✓	✓		
DCM-RL - Door control module rear left		✓	✓	✓		✓	✓							

					Seats and Doors	DCM-RR - Door control module rear right		✓	✓	✓	✓	✓			
						PWC - Partition wall control module		✓	✓	✓					
						LDCA - Electric left door closing assist		✓	✓	✓					
						RDCA - Electric right door closing assist		✓	✓	✓					
						ESA-FL - Electric seat adjustment front left		✓	✓	✓	✓	✓			
						ESA-FR - Electric seat adjustment front right		✓	✓	✓	✓	✓			
						ESA-LR - Left rear electrical seat adjustment		✓	✓	✓					
						ESA-RR - Right rear electrical seat adjustment		✓	✓	✓					
						OSB-FL - Multicontour backrest front left		✓	✓	✓					
						OSB-FR - Multicontour backrest front right		✓	✓	✓					
						MKL-HL - Rear left multicontour backrest		✓	✓	✓					
						MKL-HR - Rear right multicontour backrest		✓	✓	✓					
						TLC - Trunk lid control		✓	✓	✓	✓	✓			
						Air conditioning	C-AAC - Convenience automatic air conditioning/AAC		✓	✓	✓	✓	✓		
					REAR AC - Rear air conditioning			✓	✓	✓					
					STH - Stationary heater with remote control			✓	✓	✓	✓	✓			
					HSW - Heated steering wheel			✓	✓	✓					
<b>Mercedes</b>	All	1984-1988	SL	107	Body	AB		✓	✓	✓	✓				
					Drive	HFM		✓	✓	✓	✓				
						ME1RE		✓	✓	✓	✓				
						ME1LI		✓	✓	✓	✓				
						LH1		✓	✓	✓	✓				
						LH2		✓	✓	✓	✓				
						DM		✓	✓	✓	✓				
						EFP		✓	✓	✓	✓				
						TPM		✓	✓	✓	✓				
						ISC		✓	✓	✓	✓				
						GM		✓	✓	✓	✓				
					Chassis	ABS		✓	✓	✓	✓				
						ASR		✓	✓	✓	✓				
						ETS		✓	✓	✓	✓				
						ESP		✓	✓	✓	✓				
						BAS		✓	✓	✓	✓				
						ADS		✓	✓	✓	✓				
<b>Mercedes</b>	All	1989-1998	SL	129											

Mercedes	All	1999-2002	SL	129	Body	EGS	✓	✓	✓	✓	✓	
						EAG	✓	✓	✓	✓	✓	
						RFL	✓	✓	✓	✓		
						RCL(DAS2/X)	✓	✓	✓	✓		
						ATA	✓	✓	✓	✓		
						AB	✓	✓	✓	✓		
						KI	✓	✓	✓	✓	✓	
						LWR	✓	✓	✓	✓	✓	
						APS	✓	✓	✓	✓		
						Audio,COMMAND	✓	✓	✓	✓		
						TELE-AID	✓	✓	✓	✓		
						CDC	✓	✓	✓	✓		
						E-Call	✓	✓	✓	✓		
						Air conditioning	Air Conditioning	✓	✓	✓		
					STH		✓	✓	✓			
					Drive	ME2-SFI	✓	✓	✓	✓	✓	
						ME1RE	✓	✓	✓	✓		
						ME1LI	✓	✓	✓	✓		
						ETC	✓	✓	✓	✓	✓	
					Chassis	ABS,ASR,ETS,ESP	✓	✓	✓	✓	✓	Control unit adaptations
						BAS	✓	✓	✓	✓		
						ADS	✓	✓	✓	✓		
					Body	AB	✓	✓	✓	✓		Control unit adaptations
HRA	✓	✓	✓	✓								
ATA	✓	✓	✓	✓		✓						
RFL	✓	✓	✓	✓		✓						
RS	✓	✓	✓	✓		✓						
Information and communication	ICM	✓	✓	✓	✓	✓	Setting					
	TELE AID,E-call	✓	✓	✓	✓	✓						
	DN	✓	✓	✓								
	D2B	✓	✓	✓	✓	✓	Read coding and change if necessary					
	CDC	✓	✓	✓								
	VCS	✓	✓	✓								
CTEL	✓	✓	✓									

						APS	✓	✓	✓				
						Air conditioning	STH	✓	✓	✓	✓		
						Air conditioning	AAC	✓	✓	✓	✓	Read coding and change if necessary	
						Drive	Transmission	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
						Drive	ESM - Electronic selector module	✓	✓	✓	✓	✓	
						Drive	DTR - Distronic	✓	✓	✓	✓	✓	Control unit adaptations
						Drive	ME-SFI 2.8 - Motor electronics 2.8	✓	✓	✓	✓	✓	
						Chassis	SBC - Sensotronic Brake Control	✓	✓	✓	✓		Deactive system Active system Control unit adaptations
						Chassis	ESP - Electronic stability program	✓	✓	✓	✓	✓	Road test Erase zero point offset error of component N49(steering angle sensor)
						Chassis	ABC - ABC active body control	✓	✓	✓	✓	✓	Calibration of the plunger travel sensors Level calibration Load adjustment
						Chassis	TPC - Tire pressure monitor	✓	✓	✓	✓	✓	Control unit adaptations
						Body	AB - Airbag	✓	✓	✓	✓		Read coding and change if necessary Coded vehicle data
						Body	BNS - Vehicle power supply control module	✓	✓	✓	✓		
						Body	OCP - Overhead control panel	✓	✓	✓	✓	✓	
						Body	EIS - Electronic ignition switch	✓	✓	✓	✓		
						Body	HRA-FL - Front left headlamp range control	✓	✓	✓	✓	✓	
						Body	HRA-FR - Front right headlamp range control	✓	✓	✓	✓		
						Body	LCP - Lower control panel	✓	✓	✓	✓	✓	
						Body	PSE - Pneumatic system equipment	✓	✓	✓	✓	✓	Read coding and change if necessary
						Body	Dr-side SAM - Dr. signal acquisition and actuation mod	✓	✓	✓	✓	✓	
						Body	Pass-side SAM - Pass-side signal acquisition and actu	✓	✓	✓	✓	✓	
						Body	REAR SAM - Rear signal acquisition and actuation mod	✓	✓	✓	✓	✓	
						Body	RVC - Rollover bar/vario roof control module	✓	✓	✓	✓	✓	
						Body	KG - Keyless Go	✓	✓	✓	✓	✓	
						Body	System diagnosis	✓	✓	✓			
						Body	ICM - Instrument cluster with maintenance interval disp	✓	✓	✓	✓	✓	ASSYST settings

					SCM - Steering column module		✓	✓	✓	✓	✓	initial startup
					PTS - Parktronic system		✓	✓	✓	✓	✓	
					D2B - COMAND or AUDIO		✓	✓	✓	✓	✓	Read coding and change if necessary
					CDC - CD changer		✓	✓	✓			
					VCS - Voice control system		✓	✓	✓			
					SOUND - Sound system		✓	✓	✓			
					CTEL - Cellular telephone 1(fixed installation or portabl		✓	✓	✓			
					TELE AID,E-call or cellular telephone - Telematic syste		✓	✓	✓	✓		
					TV - TV tuner(Not valid for Japan)		✓	✓	✓		✓	
				Seats and Doors	DCM-L - Door control module left		✓	✓	✓	✓	✓	
					DCM-R - Door control module right		✓	✓	✓	✓	✓	
					RCM - Rear control module		✓	✓	✓	✓	✓	
					ESA-FL - Electric seat adjustment front left		✓	✓	✓	✓	✓	
					ESA-FR - Electric seat adjustment front right		✓	✓	✓	✓	✓	
					OSB-FL - Multicontour backrest front left		✓	✓	✓	✓	✓	
					OSB-FR - Multicontour backrest front right		✓	✓	✓	✓	✓	
				Air conditioning	AAC - Automatic air conditioning		✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors Teaching-in of rotary potentiometer for center nozzle and side outlets
					STH - Stationary heater with remote control		✓	✓	✓	✓	✓	
					HSW - Heated steering wheel		✓	✓	✓			
				Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
					ESM - Electronic selector module		✓	✓	✓	✓	✓	
					DTR - Distronic		✓	✓	✓	✓	✓	Control unit adaptations
					ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓	
					ME 9.7 - Motor electronics 9.7		✓	✓	✓	✓	✓	
					ME-SFI 2.7.1 - Motor electronics 2.7.1		✓	✓	✓	✓	✓	
					SBC - Sensotronic Brake Control		✓	✓	✓	✓		Deactive system Active system Control unit adaptations

Mercedes	All	09/2003-05/2006	SL	230	Chassis	ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test Erase zero point offset error of component N49(steering angle sensor)
						ABC - ABC active body control		✓	✓	✓	✓	✓	Calibration of the plunger travel sensors Level calibration Load adjustment
						TPC - Tire pressure monitor		✓	✓	✓	✓	✓	Control unit adaptations
					Body	AB - Airbag		✓	✓	✓	✓	✓	Read coding and change if necessary Chassis number
						WSS - Weight sensor system(USA)		✓	✓	✓			
						CGW - Central gateway		✓	✓	✓			
						BNS - Vehicle power supply control module		✓	✓	✓	✓		
						OCP - Overhead control panel		✓	✓	✓	✓	✓	
						EIS - Electronic ignition switch		✓	✓	✓	✓		
						HRA-FL - Front left headlamp range control		✓	✓	✓	✓	✓	
						HRA-FR - Front right headlamp range control		✓	✓	✓	✓		
						LCP - Lower control panel		✓	✓	✓	✓	✓	
						PSE - Pneumatic system equipment		✓	✓	✓	✓	✓	Read coding and change if necessary
						Dr-side SAM - Dr. signal acquisition and actuation mod	✓	✓	✓	✓	✓	✓	
						Pass-side SAM - Pass-side signal acquisition and actu	✓	✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation mod	✓	✓	✓	✓	✓	✓	
						RVC - Rollover bar/vario roof control module		✓	✓	✓	✓	✓	
						KG - Keyless Go		✓	✓	✓	✓	✓	
					System diagnosis		✓	✓	✓	✓			
					Information and communication	ICM - Instrument cluster with maintenance interval disp	✓	✓	✓	✓			
						SCM - Steering column module		✓	✓	✓	✓	✓	initial startup
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						AGW - Audio gateway(MOST network management, d	✓	✓	✓	✓			
						COMAND - COMAND(Display and operating unit)	✓	✓	✓	✓	✓		
						CDC - CD changer		✓	✓	✓	✓		
						HFS - Handsfree system and microphone		✓	✓	✓	✓		
						TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓		
						CTEL - Fixed installation cellular telephone		✓	✓	✓	✓		
						MB Portal - Telematic services WAP,E-mail,Mercedes-	✓	✓	✓				
						VCS - Voice control system		✓	✓	✓			
						TELE AID,E-call or cellular telephone - Telematic syste	✓	✓	✓	✓			

Seats and Doors	DCM-L - Door control module left	✓	✓	✓	✓	✓	
	DCM-R - Door control module right	✓	✓	✓	✓	✓	
	RCM - Rear control module	✓	✓	✓	✓	✓	
	ESA-FL - Electric seat adjustment front left	✓	✓	✓	✓	✓	
	ESA-FR - Electric seat adjustment front right	✓	✓	✓	✓	✓	
	OSB-FL - Multicontour backrest front left	✓	✓	✓	✓	✓	
	OSB-FR - Multicontour backrest front right	✓	✓	✓	✓	✓	
Air conditioning	AAC - Automatic air conditioning	✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors Teaching-in of rotary potentiometer for center nozzle and side outlets
	STH - Stationary heater with remote control	✓	✓	✓	✓	✓	
	HSW - Heated steering wheel	✓	✓	✓			
Drive	Transmission	✓	✓	✓	✓	✓	
	ESM - Electronic selector module	✓	✓	✓	✓	✓	
	DTR - Distronic	✓	✓	✓	✓	✓	Control unit adaptations
	ME-SFI 2.8 - Motor electronics 2.8	✓	✓	✓	✓	✓	
	ME 9.7 - Motor electronics 9.7	✓	✓	✓	✓	✓	
	ME-SFI 2.7.1 - Motor electronics 2.7.1	✓	✓	✓	✓	✓	
	ME-SFI 2.7.2 - Motor electronics 2.7.2	✓	✓	✓	✓	✓	
Chassis	SBC - Sensotronic Brake Control	✓	✓	✓	✓	✓	
	ESP - Electronic stability program	✓	✓	✓	✓	✓	
	ABC - ABC active body control	✓	✓	✓	✓	✓	Calibration of the plunger travel sensors Level calibration Load adjustment
	TPC - Tire pressure monitor	✓	✓	✓	✓	✓	Control unit adaptations
Body	AB - Airbag	✓	✓	✓	✓		
	WSS - Weight sensor system(USA)	✓	✓	✓			
	CGW - Central gateway	✓	✓	✓			
	BNS - Vehicle power supply control module	✓	✓	✓	✓		
	OCP - Overhead control panel	✓	✓	✓	✓	✓	
	EIS - Electronic ignition switch	✓	✓	✓	✓		
	HRA-FL - Front left headlamp range control	✓	✓	✓	✓	✓	
HRA-FR - Front right headlamp range control	✓	✓	✓	✓	✓		

Mercedes	All	06/2006-02/2008	SL	230	Body	LCP - Lower control panel	*	*	*	*	*	
						PSE - Pneumatic system equipment	*	*	*	*	*	
						Dr-side SAM - Dr. signal acquisition and actuation mod	√	√	√	√	√	
						Pass-side SAM - Pass-side signal acquisition and actuation mod	√	√	√	√	√	
						REAR SAM - Rear signal acquisition and actuation mod	√	√	√	√	√	
						RVC - Rollover bar/vario roof control module	√	√	√	√	√	
						KG - Keyless Go	√	√	√	√	√	
						System diagnosis	√	√	√	√		
					Information and communication	ICM - Instrument cluster with maintenance interval display	*	*	*	*		
						SCM - Steering column module	√	√	√	√	√	initial startup
						PTS - Parktronic system	√	√	√	√	√	
						AGW - Audio gateway(MOST network management,diagnostic)	√	√	√	√		
						COMAND - COMAND(Display and operating unit)	√	√	√	√	√	
						CDC - CD changer	√	√	√	√		
						HFS - Handsfree system and microphone	√	√	√	√		
						TV - TV tuner(Not valid for Japan and USA)	√	√	√	√		
						CTEL - Fixed installation cellular telephone	√	√	√	√		
						MB Portal - Telematic services WAP,E-mail,Mercedes-AMG	√	√	√			
						VCS - Voice control system	√	√	√			
					TELE AID,E-call or cellular telephone - Telematic system	√	√	√	√			
					Seats and Doors	DCM-L - Door control module left	*	*	*	*	*	
						DCM-R - Door control module right	*	*	*	*	*	
						RCM - Rear control module	√	√	√	√	√	
						ESA-FL - Electric seat adjustment front left	√	√	√	√	√	
						ESA-FR - Electric seat adjustment front right	√	√	√	√	√	
						OSB-FL - Multicontour backrest front left	√	√	√	√	√	
						OSB-FR - Multicontour backrest front right	√	√	√	√	√	
					Air conditioning	AAC - Automatic air conditioning	*	*	*	*	*	
						STH - Stationary heater with remote control	√	√	√	√	√	
						HSW - Heated steering wheel	√	√	√			

Mercedes	All	2002-2009	SLR	199	Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
						ESM - Electronic selector module		✓	✓	✓	✓	✓	
						ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓	
					Chassis	SBC - Sensotronic Brake Control		✓	✓	✓	✓	Deactive system Active system Control unit adaptations	
						ESP - Electronic stability program		✓	✓	✓	✓		
						TPC - Tire pressure monitor		✓	✓	✓	✓	Read coding and change if necessary	
					Body	AB - Airbag		✓	✓	✓	✓		
						CGW - Central gateway		✓	✓	✓			
						BNS - Vehicle power supply control module		✓	✓	✓	✓		
						OCP - Overhead control panel		✓	✓	✓	✓	✓	
						EIS - Electronic ignition switch		✓	✓	✓	✓		
						HRA-FR - Front right headlamp range control		✓	✓	✓	✓	✓	
						HRA-FL - Front left headlamp range control		✓	✓	✓	✓	✓	
						LCP - Lower control panel		✓	✓	✓	✓	✓	
						Dr-side SAM - Driver signal acquisition and actuation module		✓	✓	✓	✓	✓	
						Pass-side SAM - Passenger-side signal acquisition and actuation module		✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓	
						ACL[ZLB] - Air brake(spoiler)and central locking control		✓	✓	✓			
					Information and communication	ICM - Instrument cluster with maintenance interval display		✓	✓	✓	✓	✓	
						SCM - Steering column module		✓	✓	✓	✓	✓	initial startup
						D2B - AUDIO		✓	✓	✓	✓	✓	
						CDC - CD changer		✓	✓	✓			
						SOUND - Sound system		✓	✓	✓	✓		
						CTEL - Cellular telephone 1(fixed installation or portable)		✓	✓	✓			
						TELE AID - Telematic system(K-wrie)		✓	✓	✓	✓		
					Seats and Doors	DCM-L - Door control module left		✓	✓	✓	✓	✓	
						DCM-R - Door control module right		✓	✓	✓	✓	✓	
					Air conditioning	AAC - Automatic air conditioning		✓	✓	✓	✓	✓	

Mercedes	All	1996-1998	SLK	170(38-PIN)	Drive	ETC - Electronic transmission control	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit	
						HFM-SFI - Hot film engine management	✓	✓	✓	✓			
						ME2-SFI - Motor electronics	✓	✓	✓	✓			
					Chassis	Traction systems ABS,ASR,ETS,ESP	✓	✓	✓	✓	✓	Road test Learning processes Resetting of variant locking	
						BAS - Brake assist	✓	✓	✓	✓	✓		
					Body	AB - Airbag	✓	✓	✓	✓		Read coding and change if necessary Coded vehicle data	
						RFL - Radio frequency locking/electric central locking	✓	✓	✓	✓	✓		
						RFL(DAS2) - Radio frequency locking(drive authorizati	✓	✓	✓	✓	✓		
						PSE - Pneumatic system equipment	✓	✓	✓	✓	✓		
						CCM - Multifunction control module	✓	✓	✓	✓	✓		
						VR - Vario roof	✓	✓	✓	✓	✓		
						ATA - Anti-theft alarm system	✓	✓	✓	✓	✓		
					Information and communication	ICM - Instrument cluster with maintenance interval disp	✓	✓	✓	✓	✓		
						D2B - AUDIO	✓	✓	✓	✓	✓	Read coding and change if necessary	
						CDC - CD changer	✓	✓	✓				
						VCS - Voice control system	✓	✓	✓				
						CTEL - Cellular telephone 1(fixed installation or portabl	✓	✓	✓				
					Air conditioning	TAC - Automatic temperature control/AAC - Automatic	✓	✓	✓	✓	✓		
						Drive	Transmission	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
							ESM - Electronic selector module	✓	✓	✓	✓	✓	
ME-SFI - Motor electronics	✓	✓	✓	✓			✓						
Chassis	ESP - Electronic stability program	✓	✓	✓		✓	✓						
	BAS - Brake assist	✓	✓	✓		✓	✓						

Mercedes	All	1999-2004	SLK	170(16-PIN)	VP - Vacuum pump brake booster		✓	✓	✓	✓	✓		
					Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Coded vehicle data
						RFL - Radio frequency locking/electric central locking		✓	✓	✓	✓		
						PSE - Pneumatic system equipment		✓	✓	✓	✓		
						CCM - Multifunction control module		✓	✓	✓	✓		
						VR - Vario roof		✓	✓	✓	✓		
						ATA - Anti-theft alarm system		✓	✓	✓	✓		
						HRA - Headlamp range adjustment		✓	✓	✓	✓		
					Information and communication	ICM - Instrument cluster with maintenance interval display		✓	✓	✓	✓	✓	
						D2B - AUDIO		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer		✓	✓	✓			
						VCS - Voice control, hands-free system and microphone		✓	✓	✓			
						CTEL - Cellular telephone 1(fixed installation or portable)		✓	✓	✓			
					Air conditioning	TELE AID, E-call or cellular telephone - Telematic system		✓	✓	✓			
						TAC - Automatic temperature control/AAC - Automatic		✓	✓	✓	✓	✓	
					Drive	STH - Stationary heater		✓	✓	✓			
						Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routines
						ESM - Electronic selector module		✓	✓	✓	✓	✓	
						ME-SFI - Motor electronics		✓	✓	✓	✓	✓	
ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓		✓	✓						
Chassis	ME 9.7 - Motor electronics 9.7		✓	✓	✓	✓	✓						
	ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test					
Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Chassis number					
	CGW - Central gateway		✓	✓	✓								
	EIS - Electronic ignition switch/KG - Keyless GO(Special)		✓	✓	✓	✓							
	VR - Vario roof		✓	✓	✓	✓	✓						
	HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors					
	OCP - Overhead control panel		✓	✓	✓	✓	✓	Read coding and change if necessary Panoramic sliding roof					
	UCP - Upper control panel		✓	✓	✓	✓	✓						

Mercedes	All	2005	SLK	171	SAM-F - Signal acquisition and actuation module front	✓	✓	✓	✓	✓		
					REAR SAM - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓		
					On-board electrical system(voltage supply)	✓	✓	✓	✓			
					System diagnosis	✓	✓	✓	✓			
					Information and communication	IC - Instrument cluster	✓	✓	✓	✓	✓	
						ASSYST Active Service System	✓	✓	✓	✓		AssystSetting
						ASSYST PLUS - PLUS Active Service System	✓	✓	✓	✓		General servicing Control unit adaptations
						SCM[MRM] - Steering column module	✓	✓	✓	✓	✓	initial startup
						PTS - Parktronic system	✓	✓	✓	✓	✓	
						AGW - Audio gateway(MOST network management,diagnosis)	✓	✓	✓	✓	✓	
						COMAND/AUDIO - Audio50 or COMAND	✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer	✓	✓	✓	✓		
						TV - TV tuner(Not valid for Japan and USA)	✓	✓	✓	✓	✓	
						CTEL - Telephone adapter for portable CTEL	✓	✓	✓	✓		
					Seats and Doors	DCM-L - Door control module left	✓	✓	✓	✓	✓	Read coding and change if necessary
						DCM-R - Door control module right	✓	✓	✓	✓	✓	Read coding and change if necessary
						ESA driver - Electric seat adjustment driver(with memo)	✓	✓	✓	✓	✓	
						ESA passenger-Electric seat adjustment FR. Pass.(with memo)	✓	✓	✓	✓	✓	
						HS - Seat heater	✓	✓	✓	✓	✓	
					Air conditioning	C-AAC - Convenience automatic air conditioning/AAC	✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
						HSW - Heated steering wheel	✓	✓	✓	✓	✓	
					Drive	Transmission	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
						ESM - Electronic selector module	✓	✓	✓	✓	✓	
						ME-SFI - Motor electronics	✓	✓	✓	✓	✓	
						ME-SFI 2.8 - Motor electronics 2.8	✓	✓	✓	✓	✓	
						ME 9.7 - Motor electronics 9.7	✓	✓	✓	✓	✓	
					Chassis	ESP - Electronic stability program	✓	✓	✓	✓	✓	Road test
	AB - Airbag	✓	✓	✓	✓		Read coding and change if necessary Chassis number					
	WSS - Weight sensor system (USA)	✓	✓	✓								

Mercedes	All	2006-2009	SLK	171	Body	CGW - Central gateway		✓	✓	✓			
						EIS - Electronic ignition switch/KG - Keyless GO(Speci	✓	✓	✓	✓			
						VR - Vario roof		✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors
						OCP - Overhead control panel		✓	✓	✓	✓	✓	Read coding and change if necessary Panoramic sliding roof
						UCP - Upper control panel		✓	✓	✓	✓	✓	
						SAM-F - Signal acquisition and actuation module front	✓	✓	✓	✓	✓		
						REAR SAM - Rear signal acquisition and actuation mod	✓	✓	✓	✓	✓		
						On-board electrical system(voltage supply)		✓	✓	✓	✓		
						System diagnosis		✓	✓	✓	✓		
					Information and communication	IC - Instrument cluster		✓	✓	✓	✓	✓	
						ASSYST Active Service System		✓	✓	✓	✓		AssystSetting
						ASSYST PLUS - PLUS Active Service System	✓	✓	✓	✓			General servicing Control unit adaptations
						SCM[MRM] - Steering column module		✓	✓	✓	✓	✓	
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						AGW - Audio gateway(MOST network management,dis	✓	✓	✓	✓	✓	✓	
						COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer		✓	✓	✓	✓		
						TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓	
						CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓		
					Seats and Doors	DCM-L - Door control module left		✓	✓	✓	✓	✓	
						DCM-R - Door control module right		✓	✓	✓	✓	✓	
						ESA driver - Electric seat adjustment driver(with memo	✓	✓	✓	✓	✓	✓	
						ESA passenger-Electric seat adjustment FR. Pass.(wit	✓	✓	✓	✓	✓	✓	
						HS - Seat heater		✓	✓	✓	✓	✓	
					Air conditioning	C-AAC - Convenience automatic air conditioning/AAC	✓	✓	✓	✓	✓		Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
						HSW - Heated steering wheel		✓	✓	✓	✓	✓	

Mercedes	All	1998-2005	M-CLASS	163	Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
						ESM - Electronic selector module		✓	✓	✓	✓	✓	
						ME2-SFI - Motor electronics 2		✓	✓	✓	✓	✓	
						CDI - Common Rail Diesel Injection		✓	✓	✓	✓		
						CDI-V1 - Common Rail Diesel Injection		✓	✓	✓	✓		
						VG - Transfer case		✓	✓	✓	✓		
					Chassis	Traction system ABS,ASR,ETS,ESP		✓	✓	✓	✓	✓	
						BAS - Brake assist		✓	✓	✓	✓	✓	
					Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Coded vehicle data
						AAM - All Activity Module		✓	✓	✓	✓	✓	
						EAM - Extended activity module(As of module year 200		✓	✓	✓	✓	✓	
						DAS - Drive authorization system(As of module year 20		✓	✓	✓	✓		
						LCP - Lower perating panel with power window functio		✓	✓	✓	✓	✓	initial startup
						SEM - Security Module(Up to module year 1999)		✓	✓	✓			
						HRA - Headlamp range adjustment(As of module year		✓	✓	✓	✓	✓	
					Information and communication	ICM - Instrument cluster with maintenance interval disp		✓	✓	✓	✓	✓	
						PTS - Parktronic system		✓	✓	✓	✓	✓	Read coding and change if necessary
						D2B - COMAIND,MCS or AUDIO		✓	✓	✓	✓	✓	Read coding and change if necessary
						MCS navigation in MCS		✓	✓	✓			
						MCS CD - CD player in MCS		✓	✓	✓			
						CDC - CD changer		✓	✓	✓			
						VCS - Voice control system		✓	✓	✓			
						SOUND - Sound system		✓	✓	✓	✓		
						CTEL - Cellular telephone 1(fixed installation or portabl		✓	✓	✓			
						TELE AID,E-call or cellular telephone - Telematic syste		✓	✓	✓	✓		
					Seats and Doors	ESA-FL - Electric seat adjustment front left		✓	✓	✓	✓	✓	
						ESA-FR - Electric seat adjustment front right		✓	✓	✓	✓	✓	
Air conditioning	AAC - Automatic air conditioning(As of model year 200		✓	✓	✓	✓	✓						
	STH - Stationary heater		✓	✓	✓	✓							

Mercedes	All	2006-2009	M-CLASS	164	Drive	Transmission	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routines
						VG - Transfer case	✓	✓	✓	✓	✓	
						ISM - Intelligent servo module	✓	✓	✓	✓		
						ME-SFI 2.8 - Motor electronics 2.8	✓	✓	✓	✓	✓	
						ME9.7-Motor electronics 9.7	✓	✓	✓	✓	✓	
						ME 9.7(AMG) - Motor electronics 9.7(AMG)	✓	✓	✓	✓	✓	
						CDI 4 - Common Rail Diesel Injection	✓	✓	✓	✓	✓	
						CDI 5 - Common Rail Diesel Injection	✓	✓	✓	✓	✓	
					Chassis	AIRmatic	✓	✓	✓	✓	✓	
						ESP - Electronic stability program	✓	✓	✓	✓	✓	
						TPC - Tire pressure monitor	✓	✓	✓	✓		
					Body	AB-Airbag	✓	✓	✓	✓		
						WSS - Weight sensor system (USA)	✓	✓	✓	✓		
						RevETR-LF - Left front reversible emergency tensioning	✓	✓	✓	✓	✓	
						RevETR-RF - Right front reversible emergency tensioning	✓	✓	✓	✓	✓	
						EIS - Electronic ignition switch/KG - Keyless Go(Special)	✓	✓	✓	✓		
						CGW - Central gateway	✓	✓	✓			
						KG - Keyless Go	✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment	✓	✓	✓	✓	✓	
						OCP - Overhead control panel	✓	✓	✓	✓	✓	
						UCP - Upper control panel	✓	✓	✓	✓	✓	
						HBF(Rear control panel) - Rear control field	✓	✓	✓	✓	✓	
						SAM-F - Signal acquisition and actuation module front	✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓	
					System diagnosis(only interior CAN fault)	✓	✓	✓	✓			
					Information and communication	IC - Instrument cluster	✓	✓	✓	✓	✓	
						ASSYST - Active Service System	✓	✓	✓	✓		AssystSetting
						ASSYST PLUS - PLUS Active Service System	✓	✓	✓	✓		General servicing Control unit adaptations
						CM - Compass module	✓	✓	✓	✓		
						SCM - Steering column module	✓	✓	✓	✓	✓	
PTS - Parktronic system	✓	✓	✓	✓		✓						
AGW - Audio gateway(MOST network management,diagnosis)	✓	✓	✓	✓		✓						

					COMAND /AUDIO - Audio 50(Display and operating ur	✓	✓	✓	✓	✓		
					NAVI - Navigation(Only in combination with COMAND)	✓	✓	✓	✓			
					CDC - CD changer	✓	✓	✓	✓			
					SOUND - Sound system	✓	✓	✓	✓			
					CTEL - Mobile phone adapter with universal interface	✓	✓	✓	✓			
				Seats and Doors	DCM-FL - Door control module front left	✓	✓	✓	✓	✓		
					DCM-FR - Door control module front right	✓	✓	✓	✓	✓		
					REDC - Rear-end door closing control module	✓	✓	✓	✓	✓		
					ESA driver - Electric seat adjustment driver(with memo	✓	✓	✓	✓	✓		
					ESA passenger - Electric seat adjustment front passen	✓	✓	✓	✓	✓		
					DS-LF - Left front dynamic seat	✓	✓	✓	✓	✓		
					DS-RF - Right front dynamic seat	✓	✓	✓	✓	✓		
					DSP - Pneumatic pump for dynamic seat	✓	✓	✓	✓	✓		
					HS - Seat heater	✓	✓	✓				
				Air conditioning	AAC - Automatic air conditioning	✓	✓	✓	✓	✓		
					STH - Stationary heater with remote control	✓	✓	✓	✓	✓		
					HSW - Heated steering wheel	✓	✓	✓	✓	✓		
				Drive	Transmission	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness	
					ISM - Intelligent servo module	✓	✓	✓	✓			
					ME-SFI 2.8 - Motor electronics 2.8	✓	✓	✓	✓	✓		
					ME9.7-Motor electronics 9.7	✓	✓	✓	✓	✓	Learning of the throttle valve stop	
					ME 9.7(AMG) - Motor electronics 9.7(AMG)	✓	✓	✓	✓	✓		
					CDI 4 - Common Rail Diesel Injection	✓	✓	✓	✓	✓		
				Chassis	Suspension	✓	✓	✓	✓	✓		
					ESP - Electronic stability program	✓	✓	✓	✓	✓		
					TPC - Tire pressure monitor	✓	✓	✓	✓			
					AB-Airbag	✓	✓	✓	✓			
					WSS - Weight sensing system	✓	✓	✓	✓			
					RevETR-LF - Left front reversible emergency tensionin	✓	✓	✓	✓	✓		
					RevETR-RF - Right front reversible emergency tension	✓	✓	✓	✓	✓		
					EIS - Electronic ignition switch/KG - Keyless Go(Specia	✓	✓	✓	✓			
					CGW - Central gateway	✓	✓	✓				

Mercedes	All	2006-2009	R-CLASS	251	Body	KG - Keyless Go		✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	
						OCP - Overhead control panel		✓	✓	✓	✓	✓	
						UCP - Upper control panel		✓	✓	✓	✓	✓	
						HBF(Rear control panel) - Rear control field		✓	✓	✓	✓	✓	
						SAM-F - Signal acquisition and actuation module front		✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓	
						System diagnosis (only interior CAN fault)		✓	✓	✓	✓		
						Information and communication	IC - Instrument cluster		✓	✓	✓	✓	✓
					ASSYST - Active Service System			✓	✓	✓	✓		AssystSetting
					ASSYST PLUS - PLUS Active Service System			✓	✓	✓	✓		General servicing Control unit adaptations
					CM - Compass module			✓	✓	✓	✓		
					SCM - Steering column module			✓	✓	✓	✓	✓	
					PTS - Parktronic system			✓	✓	✓	✓		
					AGW - Audio 20 with integrated gateway(display and control)			✓	✓	✓	✓		
					CDC - CD changer			✓	✓	✓	✓		
					SOUND - Sound system			✓	✓	✓	✓		
					CTEL - Telephone adapter for portable CTEL			✓	✓	✓	✓		
					Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	
						DCM-FR - Door control module front right		✓	✓	✓	✓	✓	
						REDC - Rear-end door closing control module		✓	✓	✓	✓	✓	
						ESA driver - Electric seat adjustment driver(with memo)		✓	✓	✓	✓	✓	
						ESA passenger-Electric seat adjustment FR. Pass.(with memo)		✓	✓	✓	✓	✓	
						DS-LF - Left front dynamic seat		✓	✓	✓	✓	✓	
						DS-RF - Right front dynamic seat		✓	✓	✓	✓	✓	
						DSP - Pneumatic pump for dynamic seat		✓	✓	✓	✓	✓	
						HS - Seat heater		✓	✓	✓	✓	✓	
					Air conditioning	AAC - Automatic air conditioning		✓	✓	✓	✓	✓	
						STH - Stationary heater with remote control		✓	✓	✓	✓	✓	
						HSW - Heated steering wheel		✓	✓	✓	✓	✓	
Mercedes	All	1991-	G-CLASS	461(38)		ABS		✓	✓	✓	✓		
						ASR		✓	✓	✓	✓		
						ETS		✓	✓	✓	✓		
						ESP		✓	✓	✓	✓		

Mercedes	All	2001	G-CLASS	Pin)		RFL(DAS2)		✓	✓	✓	✓			
						AB		✓	✓	✓	✓			
						KI		✓	✓	✓	✓	✓		
						STH		✓	✓	✓				
Mercedes	All	2002-2007	G-CLASS	461(16 PIN)	Drive	ETC - Electronic transmission control		✓	✓	✓	✓	✓		
						ESM - Electronic selector module		✓	✓	✓	✓	✓		
						VG - Transfer case		✓	✓	✓	✓			
						CDI 2 - Common Rail Diesel Injection		✓	✓	✓	✓			
					Body	AB - Airbag		✓	✓	✓	✓	✓		
						Information and communication	IC - Instrument cluster		✓	✓	✓	✓	✓	
							AUDIO		✓	✓	✓	✓	✓	
Air conditioning	Air conditioning		✓	✓	✓	✓	✓							
	STH - Stationary heater		✓	✓	✓	✓								
Mercedes	All	1991-1997	G-CLASS	463(4Pin)	Drive	HFM		✓	✓	✓	✓			
						EFP		✓	✓	✓	✓			
						TPM		✓	✓	✓	✓			
						ISC		✓	✓	✓	✓			
					Body	RCL(DAS1/X)		✓	✓	✓	✓			
						RCL(DAS2/X)		✓	✓	✓	✓			
						ATA(Anti-Theft Alarm)		✓	✓	✓	✓			
						AB(Air Bag)		✓	✓	✓	✓			
Mercedes	All	1997-	G-CLASS	463(38 Pin)	Drive	ETC - Electronic transmission control		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit	
						ESM - Electronic selector module		✓	✓	✓	✓	✓		
						HFM-SFI- Hot film engine management		✓	✓	✓	✓			
						ME2-SFI - Motor electronics		✓	✓	✓	✓			
					Chassis	Traction systems ABS,ASR,ETS,ESP		✓	✓	✓	✓	✓		
					Body	AB - Airbag		✓	✓	✓	✓	✓	Control unit adaptations	
						RFL(DAS2) - Radio frequency locking(drive authorizati		✓	✓	✓	✓	✓		
ATA - Anti-theft alarm system		✓	✓	✓		✓	✓							

						Information and communication	ICM - Instrument cluster with maintenance interval disp	✓	✓	✓	✓	✓	✓	✓	Clock Reset odometer to 0 km Oil change
							D2B - AUDIO		✓	✓	✓	✓	✓	✓	Read coding and change if necessary
							CDC - CD changer		✓	✓	✓				
							VCS - Voice control system		✓	✓	✓				
							CTEL - Cellular telephone 1(fixed installation or portabl	✓	✓	✓					
							APS - Auto pilot system		✓	✓	✓				
						Air conditioning	Air conditioning		✓	✓	✓	✓			Read coding and change if necessary
							STH - Stationary heater		✓	✓	✓				
						Drive	ETC - Electronic transmission control		✓	✓	✓	✓	✓		Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
							ESM - Electronic selector module		✓	✓	✓	✓	✓		
							ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓		
							CDI-V1 - Common Rail Diesel Injection		✓	✓	✓	✓	✓		
							CDI 2 - Common Rail Diesel Injection		✓	✓	✓	✓	✓		
							VG - Transfer case		✓	✓	✓	✓	✓		
						Chassis	Traction systems ABS,ASR,ETS,ESP		✓	✓	✓	✓	✓		
						Body	AB - Airbag		✓	✓	✓	✓			
							EIS - Electronic ignition switch		✓	✓	✓	✓			
							UCP - Upper control panel		✓	✓	✓	✓	✓		
							SAM-F - Signal acquisition and actuation module front	✓	✓	✓	✓	✓	✓		
							REAR SAM - Rear signal acquisition and actuation mo	✓	✓	✓	✓	✓	✓		
							AHE - Trailer recognition		✓	✓	✓	✓	✓		
							OCP - Overhead control panel		✓	✓	✓	✓	✓		
							VR - Electrohydraulic soft top		✓	✓	✓	✓	✓		
						MSS - Special vehicle multifunction control module	✓	✓	✓						
						Information and communication	ICM - Instrument cluster with maintenance interval disp	✓	✓	✓	✓	✓	✓		
							SCM[MRM] - Steering column module(As of model yea	✓	✓	✓	✓	✓	✓		
							D2B - COMAND or AUDIO		✓	✓	✓	✓	✓	Read coding and change if necessary	
							CDC - CD changer		✓	✓	✓				
							VCS - Voice control system		✓	✓	✓	✓			

				on	CTEL - Cellular telephone 1(fixed installation or portabl	✓	✓	✓			
					TELE AID,E-call or cellular telephone - Telematic syste	✓	✓	✓	✓		
					TV - TV tuner	✓	✓	✓			
				Seats and Doors	DCM-FL - Door control module front left	✓	✓	✓	✓	✓	
					DCM-FR - Door control module front right	✓	✓	✓	✓	✓	
					DCM-RL - Door control module rear left	✓	✓	✓	✓	✓	
					DCM-RR - Door control module rear right	✓	✓	✓	✓	✓	
					ESA driver - Electric seat adjustment driver(with memo	✓	✓	✓	✓	✓	
					ESA passenger - Electic seat adjustment front passeng	✓	✓	✓	✓	✓	
				Air conditioning	AAC- Automatic air conditioning	✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of postioning motors Teaching-in of rotary potentiometer for center nozzle and side outlets
					STH - Stationary heater with remote control	✓	✓	✓	✓	✓	
					HSW - Heated steering wheel	✓	✓	✓			
				Drive	ETC - Electronic transmission control	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
					ESM - Electronic selector module	✓	✓	✓	✓	✓	
					ME-SFI 2.8 - Motor electronics 2.8	✓	✓	✓	✓	✓	
					CDI-V1 - Common Rail Diesel Injection	✓	✓	✓	✓	✓	
					CDI 2 - Common Rail Diesel Injection	✓	✓	✓	✓	✓	
					VG - Transfer case	✓	✓	✓	✓	✓	
				Chassis	Traction systems ABS,ASR,ETS,ESP	✓	✓	✓	✓	✓	
				Body	AB - Airbag	✓	✓	✓	✓		
					EIS - Electronic ignition switch	✓	✓	✓	✓		
					UCP - Upper control panel	✓	✓	✓	✓	✓	
					SAM-F - Signal acquisition and actuation module front	✓	✓	✓	✓	✓	
					REAR SAM - Rear signal acquisition and actuation mo	✓	✓	✓	✓	✓	
					AHE - Trailer recognition	✓	✓	✓	✓	✓	
					OCP - Overhead control panel	✓	✓	✓	✓	✓	

Mercedes	6	2004-2006	G-CLASS	463(16 Pin)	VR - Electrohydraulic soft top		✓	✓	✓	✓	✓		
					MSS - Special vehicle multifunction control module		✓	✓	✓				
					Information and communication	ICM - Instrument cluster with maintenance interval display		✓	✓	✓	✓	✓	
						SCM[MRM] - Steering column module(As of model year 2005)		✓	✓	✓	✓	✓	
						D2B - COMAND or AUDIO		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer		✓	✓	✓			
						VCS - Voice control system		✓	✓	✓	✓		
						CTEL - Cellular telephone 1(fixed installation or portable)		✓	✓	✓			
						TELE AID,E-call or cellular telephone - Telematic system		✓	✓	✓	✓		
						TV - TV tuner		✓	✓	✓			
					Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	
						DCM-FR - Door control module front right		✓	✓	✓	✓	✓	
						DCM-RL - Door control module rear left		✓	✓	✓	✓	✓	
						DCM-RR - Door control module rear right		✓	✓	✓	✓	✓	
						ESA driver - Electric seat adjustment driver(with memory)		✓	✓	✓	✓	✓	
						ESA passenger - Electric seat adjustment front passenger		✓	✓	✓	✓	✓	
					Air conditioning	AAC- Automatic air conditioning		✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors Teaching-in of rotary potentiometer for center nozzle and side outlets
						STH - Stationary heater with remote control		✓	✓	✓	✓	✓	
						HSW - Heated steering wheel		✓	✓	✓			
					Drive	ETC - Electronic transmission control		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
						ESM - Electronic selector module		✓	✓	✓	✓	✓	
						ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓	
						CDI 4 - Common Rail Diesel Injection		✓	✓	✓	✓	✓	
						VG - Transfer case		✓	✓	✓	✓	✓	
					Chassis	ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test
						TPC - Tire pressure monitor		✓	✓	✓	✓	✓	Read coding and change if necessary
						AB - Airbag		✓	✓	✓	✓		
EIS - Electronic ignition switch		✓	✓	✓		✓	✓						
UCP - Upper control panel		✓	✓	✓		✓	✓						

Mercedes	All	2006-2007	G-CLASS	463(16 Pin)	Body	SAM-F - Signal acquisition and actuation module front	✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓	
						AHE - Trailer recognition	✓	✓	✓	✓	✓	
						OCP - Overhead control panel	✓	✓	✓	✓	✓	Read coding and change if necessary
						ALWR - Headlamp range adjustment	✓	✓	✓	✓	✓	
						MSS - Special vehicle multifunction control module	✓	✓	✓			
					Information and communication	ICM - Instrument cluster with maintenance interval display	✓	✓	✓	✓	✓	Oil change
						SCM[MRM] - Steering column module(As of model year)	✓	✓	✓	✓	✓	
						AGW - Audio gateway	✓	✓	✓	✓	✓	
						COMAND/AUDIO - Audio50 or COMAND	✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer	✓	✓	✓	✓		
						HFS - Hands free system and microphone	✓	✓	✓			
					Seats and Doors	CTEL - Telephone adapter for portable CTEL	✓	✓	✓	✓	✓	
						DCM-FL - Door control module front left	✓	✓	✓	✓	✓	
						DCM-FR - Door control module front right	✓	✓	✓	✓	✓	
						DCM-RL - Door control module rear left	✓	✓	✓	✓	✓	
						DCM-RR - Door control module rear right	✓	✓	✓	✓	✓	
						ESA driver - Electric seat adjustment front passenger(vehicle)	✓	✓	✓	✓	✓	
					Air conditioning	ESA passenger - Electric seat adjustment front passenger(vehicle)	✓	✓	✓	✓	✓	
						AAC- Automatic air conditioning	✓	✓	✓	✓	✓	
						STH - Stationary heater with remote control	✓	✓	✓	✓	✓	
					Drive	HSW - Heated steering wheel	✓	✓	✓	✓	✓	
						ETC - Electronic transmission control	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routines
						ESM - Electronic selector module	✓	✓	✓	✓	✓	
						ME-SFI 2.8 - Motor electronics 2.8	✓	✓	✓	✓	✓	
						CDI 2 - Common Rail Diesel Injection	✓	✓	✓	✓	✓	
						CDI-V1 - Common Rail Diesel Injection	✓	✓	✓	✓		
VG - Transfer case	✓	✓	✓	✓		✓						
Chassis	ESP - Electronic stability program	✓	✓	✓		✓	✓	Road test				
	TPC - Tire pressure monitor	✓	✓	✓		✓	✓	Read coding and change if necessary				
	AB - Airbag	✓	✓	✓		✓						
	EIS - Electronic ignition switch	✓	✓	✓		✓	✓					

Mercedes	All	2007-2009	G-CLASS	463(16 Pin)	Body	UCP - Upper control panel	✓	✓	✓	✓	✓	
						SAM-F - Signal acquisition and actuation module front	✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓	
						AHE - Trailer recognition	✓	✓	✓	✓	✓	
						OCP - Overhead control panel	✓	✓	✓	✓	✓	Read coding and change if necessary
						MSS - Special vehicle multifunction control module	✓	✓	✓	✓	✓	
						ALWR - Headlamp range adjustment	✓	✓	✓			
					Information and communication	ICM - Instrument cluster with maintenance interval display	✓	✓	✓	✓	✓	Oil change
						SCM[MRM] - Steering column module(As of model year)	✓	✓	✓	✓	✓	
						AGW - Audio gateway	✓	✓	✓	✓	✓	
						COMAND/AUDIO - Audio50 or COMAND	✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer	✓	✓	✓	✓		
						HFS - Hands free system and microphone	✓	✓	✓			
						CTEL - Telephone adapter for portable CTEL	✓	✓	✓	✓	✓	
					Seats and Doors	DCM-FL - Door control module front left	✓	✓	✓	✓	✓	
						DCM-FR - Door control module front right	✓	✓	✓	✓	✓	
						DCM-RL - Door control module rear left	✓	✓	✓	✓	✓	
						DCM-RR - Door control module rear right	✓	✓	✓	✓	✓	
						ESA driver - Electric seat adjustment front passenger(vehicle)	✓	✓	✓	✓	✓	
						ESA passenger - Electric seat adjustment front passenger	✓	✓	✓	✓	✓	
					Air conditioning	AAC - Automatic air conditioning	✓	✓	✓	✓	✓	
						STH - Stationary heater with remote control	✓	✓	✓	✓	✓	
						HSW - Heated steering wheel	✓	✓	✓	✓	✓	
					Drive	Transmission	✓	✓	✓	✓	✓	
						VG - Transfer case	✓	✓	✓	✓	✓	
						ISM - Intelligent servo module	✓	✓	✓	✓		
						ME 9.7 - Motor electronics 9.7	✓	✓	✓	✓	✓	
						CDI 4 - Common Rail Diesel Injection	✓	✓	✓	✓	✓	
						CDI 5 - Common Rail Diesel Injection	✓	✓	✓	✓	✓	
					Chassis	AIRmatic	✓	✓	✓	✓	✓	
ESP - Electronic stability program	✓	✓	✓	✓		✓						
TPC - Tire pressure monitor	✓	✓	✓	✓								
	AB-Airbag	✓	✓	✓	✓							
	WSS - Weight sensor system	✓	✓	✓	✓							

Mercedes	All	2006-2009	GL-CLASS	X164	Body	RevETR-LF - Left front reversible emergency tensioning	✓	✓	✓	✓	✓	
						RevETR-RF - Right front reversible emergency tensioning	✓	✓	✓	✓	✓	
						EIS - Electronic ignition switch/KG - Keyless Go(Special)	✓	✓	✓	✓		
						CGW - Central gateway	✓	✓	✓			
						KG - Keyless Go	✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment	✓	✓	✓	✓	✓	
						OCP - Overhead control panel	✓	✓	✓	✓	✓	
						UCP - Upper control panel	✓	✓	✓	✓	✓	
						HBF(Rear control panel) - Rear control field	✓	✓	✓	✓	✓	
						SAM-F - Signal acquisition and actuation module front	✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓	
						System diagnosis(only interior CAN fault)	✓	✓	✓	✓		
						Information and communication	IC - Instrument cluster	✓	✓	✓	✓	✓
					ASSYST - Active Service System		✓	✓	✓	✓		AssystSetting
					ASSYST PLUS - PLUS Active Service System		✓	✓	✓	✓		General servicing Control unit adaptations
					CM - Compass module		✓	✓	✓	✓		
					SCM - Steering column module		✓	✓	✓	✓	✓	
					PTS - Parktronic system		✓	✓	✓	✓		
					AGW - Audio gateway(MOST network management,discovery)		✓	✓	✓	✓	✓	
					COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓		
					CDC - CD changer		✓	✓	✓	✓		
					TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓	
					CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓	✓	
					Seats and doors	DCM-FL - Door control module front left	✓	✓	✓	✓	✓	
						DCM-FR - Door control module front right	✓	✓	✓	✓	✓	
						REDC - Rear-end door closing control module	✓	✓	✓	✓	✓	
						ESA driver - Electric seat adjustment driver(with memo)	✓	✓	✓	✓	✓	
						ESA passenger - Electric seat adjustment front passenger	✓	✓	✓	✓	✓	
						DS-LF - Left front dynamic seat	✓	✓	✓	✓	✓	
						DS-RF - Right front dynamic seat	✓	✓	✓	✓	✓	
						DSP - Pneumatic pump for dynamic seat	✓	✓	✓	✓	✓	
						ERA - Electric fold-down backrest system(3rd seat row)	✓	✓	✓	✓	✓	
						HS - Seat heater	✓	✓	✓			
					Air	AAC - Automatic air conditioning	✓	✓	✓	✓	✓	

					All Conditioning	STH - Stationary heater with remote control		✓	✓	✓	✓	✓	
						HSW - Heated steering wheel		✓	✓	✓	✓	✓	
Mercedes	All	2008-2009	GLK	X204	Drive	ME 9.7 - Motor electronics 9.7( Chassis CAN bus )		✓	✓	✓	✓	✓	
						CDI 6 - Common Rail Diesel Injection( Chassis CAN bus )		✓	✓	✓	✓	✓	
						FSCU - Fuel Pump( Drive train CAN bus )		✓	✓	✓	✓	✓	
						Transmission		✓	✓	✓	✓	✓	
						ESM - Electronic selector module( Drive train CAN bus )		✓	✓	✓	✓	✓	
					Chassis	ABR - Adaptive Brake( Chassis CAN bus )		✓	✓	✓	✓		
						Suspension( Chassis CAN bus )		✓	✓	✓	✓	✓	
						TPC - Tire pressure monitor( Interior CAN bus )		✓	✓	✓	✓	✓	
					Body	CGW - Central gateway( Central CAN bus )		✓	✓	✓	✓		
						EZS - Electronic ignition switch( Interior CAN bus )		✓	✓	✓	✓		
						KG - Keyless Go( Interior CAN bus )		✓	✓	✓			
						XALWA-L - Xenon headlamp,left( Front end CAN bus )		✓	✓	✓	✓	✓	
						XALWA-R - Xenon headlamp,right( Front end CAN bus )		✓	✓	✓	✓	✓	
						AB - Airbag		✓	✓	✓	✓		
						WSS - Weight sensor system (USA)( Interior CAN bus )		✓	✓	✓			
						System 'Dr-side SAM' with connected LIN components		✓	✓	✓	✓	✓	
						System 'REAR SAM' with connected LIN components(		✓	✓	✓	✓	✓	
						OCP - Overhead control panel( Interior CAN bus )		✓	✓	✓	✓	✓	
						COU[ZBE] - Central operating unit( Telematic CAN bus )		✓	✓	✓	✓	✓	
						RevETR-LF - Left front reversible emergency tensinoin		✓	✓	✓	✓		
						RevETR-RF - Right front reversible emergency tensinoin		✓	✓	✓	✓		
					Information and communication	ICM - Instrument cluster with maintenance interval disp		✓	✓	✓	✓	✓	
						SCM[MRM] - Steering column module( Chassis CAN bus )		✓	✓	✓	✓	✓	
						PTS - Parktronic( Interior CAN bus )		✓	✓	✓	✓	✓	
RFK - Backup camera Japan( Interior CAN bus )		✓	✓	✓		✓							
COMAND - COMAND with integral telematics gateway		✓	✓	✓		✓	✓						
Tuner - Radio tuner with amplifier		✓	✓	✓									
CTEL - Mobile telephone adapter with universal interfa		✓	✓	✓		✓	✓						
VCS - Voice control(Linguatronic)		✓	✓	✓		✓	✓						
TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓		✓							
SDAR - Satellite radio (Valid for USA)		✓	✓	✓		✓	✓						
ZAN - Central Display		✓	✓	✓	✓	✓							

					COU[ZBE] - Central operating unit( Telematic CAN bus	✓	✓	✓	✓	✓	
					KBE-H -Rear A/C operating unit	✓	✓	✓	✓		
				Seats and Doors	System 'Door control module front left' with connected	✓	✓	✓	✓	✓	
					System 'Door control module front right' with connected	✓	✓	✓	✓	✓	
					DCM-RL - Door control module rear left( Interior CAN b	✓	✓	✓	✓	✓	
					DCM-RR - Door control module rear right( Interior CAN	✓	✓	✓	✓	✓	
					ESA driver - Electric seat adjustment driver( Interior CA	✓	✓	✓	✓	✓	
				Air conditioning	AAC - Automatic air conditioning( Interior CAN bus )	✓	✓	✓	✓	✓	
Mercedes	All	1996-2003	VITO/V-CLASS	638	ME2 - Fuel injection and ignition system	✓	✓	✓	✓		
					V6 - 6-cylinder gasoline engine	✓	✓	✓	✓		
					CDI - Common rail diesel injection	✓	✓	✓	*	✓	
					ABS - Anti-lock brake system	✓	✓	✓	✓		
					WSP - Immobilizer	✓	✓	✓	✓		
					AB - Airbag	*	*	*	*		
					AG - Automatic transmisstion for V6 engines	✓	✓	✓	✓		
					AGN - Automatic transmisstion	✓	✓	✓	✓		
					KR - Combination relay	✓	✓	✓	✓		
					HZR - Heating control	✓	✓	✓	✓		
					ATA - Anti-theft alarm system	✓	✓	✓	✓	✓	
					ENR - Electronic level control	✓	✓	✓			
					ERE - Electronic inline	✓	✓	✓	✓	✓	
					EVE - Evecronic distributor injection	✓	✓	✓	✓	✓	
					APS - Auto pilot system	✓	✓	✓			
					KI - Instrument cluster	✓	✓	✓	✓		
				Drive	ETC - Electronic transmission control	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
					ESM - Electronic selector module	✓	✓	✓	✓	✓	
					ME-SFI - Motor electronics	✓	✓	✓	✓	✓	
					CDI - Common Rail	✓	✓	✓	✓	✓	
					ENR - Electronic level control	✓	✓	✓			

Mercedes	All	2004-2007	VITO/VIANO	639	Chassis	ESP - Electronic stability program	✓	✓	✓	✓							
						TPC - Tire pressure monitor	✓	✓	✓								
					Body	AAG - Trailer connection unit	✓	✓	✓								
						OCP - Overhead control panel	✓	✓	✓	✓							
						EIS - Electronic ignition switch	✓	✓	✓	✓							
						CGW - Central gateway	✓	✓	✓								
						UCP - Upper control panel	✓	✓	✓	✓	✓						
						SAM - Signal acquisition and actuation module	✓	✓	✓	✓	✓						
						SDE-H - Rear sliding/tilting sunroof unit	✓	✓	✓	✓	✓						
						SRS - Supplemental restraint system	✓	✓	✓	✓							
					Information and Communication	IC - Instrument cluster	✓	✓	✓	✓	✓						
						PTS - Parktronic system	✓	✓	✓								
						AGW Audio gateway(MOST master),COMAND,AUDIO	✓	✓	✓	✓	✓						
					Seats and doors	ESA passenger - Electric seat adjustment passenger	✓	✓	✓								
						ESA driver - Electric seat adjustment driver	✓	✓	✓								
						DCM-FL - Door control module front left	✓	✓	✓	✓	✓						
						DCM-FR - Door control module front right	✓	✓	✓	✓	✓						
					Air Conditioning	AAC - Automatic air conditioning/automatic temperature	✓	✓	✓	✓	✓	Control unit reset Perform normalizing of component M16/8(Blending air flap actuator motor)					
						PTC - Electric heater booster	✓	✓	✓	✓	✓	Control unit reset					
						REAR AC - Rear air conditioning/Rear heater	✓	✓	✓	✓	✓						
						STH - Stationary heater/Heater booster	✓	✓	✓	✓	✓						
					Mercedes	All	2002-2005	VANEO	414	Drive	ECM - Engine control monolith	✓	✓	✓	✓		
											ACS - Automatic clutch system	✓	✓	✓	✓	✓	
											FTC - Front transmission control	✓	✓	✓	✓	✓	
ESM - Electronic selector module	✓	✓	✓	✓							✓						
CDI - Common Rail	✓	✓	✓														
Chassis	ESP - Electronic stability program	✓	✓	✓						✓							
Body	AB - Airbag	✓	✓	✓						✓	✓						
	ATA - Anti-theft alarm system	✓	✓	✓						✓	✓						
	DAS - Drive authorization system	✓	✓	✓						✓	✓						
Information and Communication	ICM - Instrument cluster with maintenance interval display	✓	✓	✓						✓	✓						
	PTS - Parktronic system	✓	✓	✓						✓	✓						
	D2B - AUDIO	✓	✓	✓						✓	✓						

					Communication	CDC - CD changer	✓	✓	✓			
						CTEL - Cellular telephone 1(fixed installation or portab	✓	✓	✓			
					Seats and doors	CL - Central locking	✓	✓	✓	✓	✓	
					Air Conditioning	TAC - Automatic temperature control	✓	✓	✓			
						STH - Stationary heater	✓	✓	✓	✓	✓	
Mercedes	All	2006-2009	Sprinter	906	Drive	ETC - Electronic transmission control	✓	✓	✓	✓	✓	
						ESM - Electronic selector module	✓	✓	✓	✓	✓	
						ME Motor electronics(4 Cylinder ,M271)	✓	✓	✓	✓	✓	
						CDI4 Common Rail Diesel Injection(EURO4,EU4)	✓	✓	✓	✓	✓	
						VG Transfer case	✓	✓	✓	✓	✓	
					Chassis	ENR - Electronic level control	✓	✓	✓			
						ESP - Electronic stability program	✓	✓	✓	✓		
					Body	EIS - Electronic ignition switch	✓	✓	✓	✓	✓	
						KE - Keyless Entry	✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment	✓	✓	✓	✓	✓	
						SCM - Steering column module	✓	✓	✓	✓	✓	
						UCP - Upper control panel	✓	✓	✓	✓	✓	
						SAM - Signal acquisition and actuation module	✓	✓	✓	✓	✓	
						SRS - Supplemental restraint system	✓	✓	✓	✓	✓	
					Information and Communication	CDC - CD changer	✓	✓	✓	✓		
						KI - Instrument cluster	✓	✓	✓	✓	✓	
						NAVI - Navigation system	✓	✓	✓	✓		
						PTS - Parktronic system	✓	✓	✓	✓		
						RADIO Sound5	✓	✓	✓	✓	✓	
					TEL Telephone control unit	✓	✓	✓	✓	✓		
Seats and doors	TSG Door control module	✓	✓	✓	✓	✓						
Air Conditioning	AAC - Automatic air conditioning/automatic temperatur	✓	✓	✓								
Mercedes	All	2000-	Sprinter	901.6, 902.6, 903.6	CR - Common rail	✓	✓	✓	✓			
					ME - Fuel injection and ignition system	✓	✓	✓	✓			
					KI - Instrument cluster	✓	✓	✓	✓	✓		
					WSP - Immobilizer	✓	✓	✓	✓			
					AB - Airbag	✓	✓	✓	✓			

Mercedes	All	2006	Sprinter	905.6, 904.6, 905.6	ABS - Anti-lock brake system	✓	✓	✓	✓	✓	
					ESP - Electronic Stability Program	✓	✓	✓	✓	✓	
					HZR heating control	✓	✓	✓			
					SSG Sprintshift transmission	✓	✓	✓			
					Radio	✓	✓	✓	✓	✓	
Mercedes	All	2000-2006	Sprinter	901.0/ 3/4,90 2.0/3/4 ,903.0/ 3/4,90 4.0/3/4	ME - Fuel injection and ignition system	✓	✓	✓	✓		
					V6 - 6-cylinder gasoline engine	✓	✓	✓	✓		
					CDI - Common rail diesel injection	✓	✓	✓	✓		
					KI - Instrument cluster	✓	✓	✓	✓	✓	
					ABS - Anti-lock brake system	✓	✓	✓	✓	✓	
					WSP - Immobilizer	✓	✓	✓	✓		
					AB - Airbag	✓	✓	✓	✓	✓	
					AG - Automatic transmission for V6 engines	✓	✓	✓	✓		
					AGN - Automatic transmission	✓	✓	✓	✓		
					KR - Combination relay	✓	✓	✓	✓		
					HZR - Heating control	✓	✓	✓			
					ATA - Anti-theft alarm system	✓	✓	✓	✓	✓	
					ENR - Electronic level control	✓	✓	✓			
					ERE - Electronic inline	✓	✓	✓	✓	✓	
APS - Auto pilot system	✓	✓	✓								
Mercedes	All	2000-2006	Sprinter	690.6	CR - Common rail	✓	✓	✓	✓		
					ME - Fuel injection and ignition system	✓	✓	✓	✓		
					KI - Instrument cluster	✓	✓	✓	✓	✓	
					WSP - Immobilizer	✓	✓	✓	✓		
					AB - Airbag	✓	✓	✓	✓		
					ABS - Anti-lock brake system	✓	✓	✓	✓	✓	
					ESP - Electronic Stability Program	✓	✓	✓	✓	✓	
					HZR heating control	✓	✓	✓			
					SSG Sprintshift transmission	✓	✓	✓			
Radio	✓	✓	✓	✓	✓						