

Mark X Description Function is supported.

Special Function

Automaker	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations	Special Functions
HONDA	CANADA	1996-2014	All	All	All	PGM FI		X	X	X	X	X	1.TP sensor reset 2.REPLACE ECM/PCM
HONDA	CANADA	1996-2014	All	All	All	ABS TCS VSA		X	X	X	X	X	All sensor calibration
HONDA	CANADA	1996-2014	All	All	All	SRS		X	X	X	X	X	OPDS init
HONDA	CANADA	1996-2014	All	All	All	BODY(Gauges)		X	X	X	X	X	Gauge Control Module Replacement
HONDA	CANADA	1996-2014	All	All	All	BODY(Keyless)		X	X	X	X	X	Keyless Check
HONDA	CANADA	1996-2014	All	All	All	BODY(Power Windows)		X	X	X	X	X	1.Power Window Reset for Driver side 2.Power Window Reset for Passenger side 3.Power Window Reset for Left side 4.Power Window Reset for Right side
HONDA	CANADA	1996-2014	All	All	All	BODY(Front Panel)		X	X	X	X		Front Panel Check
HONDA	CANADA	1996-2014	All	All	All	BODY(HF LINK/TEL)		X	X	X			Passcode clear
HONDA	CANADA	1996-2014	All	All	All	IMMOBI							1.Add one key 2.Rewrite keys 3.All keys lost 4.Add Keys 5.Delete Keys 6.Replace ECM/PCM
HONDA	EUROPE	1996-2014	All	All	All	PGM FI		X	X	X	X	X	1.TP sensor reset 2.REPLACE ECM/PCM
HONDA	EUROPE	1996-2014	All	All	All	ABS TCS VSA		X	X	X	X	X	All sensor calibration
HONDA	EUROPE	1996-2014	All	All	All	SRS		X	X	X	X	X	OPDS init
HONDA	EUROPE	1996-2014	All	All	All	BODY(Gauges)		X	X	X	X	X	Gauge Control Module Replacement
HONDA	EUROPE	1996-2014	All	All	All	BODY(Keyless)		X	X	X	X	X	Keyless Check
HONDA	EUROPE	1996-2014	All	All	All	BODY(Power Windows)		X	X	X	X	X	1.Power Window Reset for Driver side 2.Power Window Reset for Passenger side 3.Power Window Reset for Left side 4.Power Window Reset for Right side
HONDA	EUROPE	1996-2014	All	All	All	BODY(Front Panel)		X	X	X	X		Front Panel Check
HONDA	EUROPE	1996-2014	All	All	All	BODY(HF LINK/TEL)		X	X	X			Passcode clear
HONDA	EUROPE	1996-2014	All	All	All	IMMOBI							1.Add one key 2.Rewrite keys 3.All keys lost 4.Add Keys 5.Delete Keys 6.Replace ECM/PCM
HONDA	EUROPE	1996-2014	All	All	All	DIESEL		X	X	X	X	X	1. ECM Reset 2. DPF DIFFERENTIAL PRESSURE SENSOR INITIAL LEARN 3. MAF Sensor Learning Clear

Mark  
X Description  
Function is supported.

Mark	Description	Function is supported.											
													4. Reset 'Calculated PM Value' 5. AF Sensor 1 Learning Clear 6. ISV Forced Learning 7. DPF Regeneration
HONDA	GENERAL	1996-2014	All	All	All	PGM FI		X	X	X	X	X	1.TP sensor reset 2.REPLACE ECM/PCM
HONDA	GENERAL	1996-2014	All	All	All	ABS TCS VSA		X	X	X	X	X	All sensor calibration
HONDA	GENERAL	1996-2014	All	All	All	SRS		X	X	X	X	X	OPDS init
HONDA	GENERAL	1996-2014	All	All	All	BODY(Gauges)		X	X	X	X	X	Gauge Control Module Replacement
HONDA	GENERAL	1996-2014	All	All	All	BODY(Keyless)		X	X	X	X	X	Keyless Check
HONDA	GENERAL	1996-2014	All	All	All	BODY(Power Windows)		X	X	X	X	X	1.Power Window Reset for Driver side 2.Power Window Reset for Passenger side 3.Power Window Reset for Left side 4.Power Window Reset for Right side
HONDA	GENERAL	1996-2014	All	All	All	BODY(Front Panel)		X	X	X	X		Front Panel Check
HONDA	GENERAL	1996-2014	All	All	All	BODY(HF LINK/TEL)		X	X	X			Passcode clear
HONDA	GENERAL	1996-2014	All	All	All	IMMOBI							1.Add one key 2.Rewrite keys 3.All keys lost 4.Add Keys 5.Delete Keys 6.Replace ECM/PCM
HONDA	GENERAL	1996-2014	All	All	All	DIESEL		X	X	X	X	X	1. ECM Reset 2. DPF DIFFERENTIAL PRESSURE SENSOR INITIAL LEARN 3. MAF Sensor Learning Clear 4. Reset 'Calculated PM Value' 5. AF Sensor 1 Learning Clear 6. ISV Forced Learning 7. DPF Regeneration
HONDA	JAPAN	1996-2014	All	All	All	PGM FI		X	X	X	X	X	1.TP sensor reset 2.REPLACE ECM/PCM
HONDA	JAPAN	1996-2014	All	All	All	ABS TCS VSA		X	X	X	X	X	All sensor calibration
HONDA	JAPAN	1996-2014	All	All	All	SRS		X	X	X	X	X	OPDS init
HONDA	JAPAN	1996-2014	All	All	All	BODY(Gauges)		X	X	X	X	X	Gauge Control Module Replacement
HONDA	JAPAN	1996-2014	All	All	All	BODY(Keyless)		X	X	X	X	X	Keyless Check
HONDA	JAPAN	1996-2014	All	All	All	BODY(Power Windows)		X	X	X	X	X	1.Power Window Reset for Driver side 2.Power Window Reset for Passenger side 3.Power Window Reset for Left side 4.Power Window Reset for Right side

Mark X Description Function is supported.

HONDA	JAPAN	1996-2014	All	All	All	BODY(Front Panel)		X	X	X	X		Front Panel Check
HONDA	JAPAN	1996-2014	All	All	All	BODY(HF LINK/TEL)		X	X	X			Passcode clear
HONDA	JAPAN	1996-2014	All	All	All	IMMOBI							1.Add one key 2.Rewrite keys 3.All keys lost 4.Add Keys 5.Delete Keys 6.Replace ECM/PCM
HONDA	USA	1996-2014	All	All	All	PGM FI		X	X	X	X	X	1.TP sensor reset 2.REPLACE ECM/PCM
HONDA	USA	1996-2014	All	All	All	ABS TCS VSA		X	X	X	X	X	All sensor calibration
HONDA	USA	1996-2014	All	All	All	SRS		X	X	X	X	X	OPDS init
HONDA	USA	1996-2014	All	All	All	BODY(Gauges)		X	X	X	X	X	Gauge Control Module Replacement
HONDA	USA	1996-2014	All	All	All	BODY(Keyless)		X	X	X	X	X	Keyless Check
HONDA	USA	1996-2014	All	All	All	BODY(Power Windows)		X	X	X	X	X	1.Power Window Reset for Driver side 2.Power Window Reset for Passenger side 3.Power Window Reset for Left side 4.Power Window Reset for Right side
HONDA	USA	1996-2014	All	All	All	BODY(Wiper)		X	X	X	X	X	
HONDA	USA	1996-2014	All	All	All	BODY(Front Panel)		X	X	X	X		Front Panel Check
HONDA	USA	1996-2014	All	All	All	BODY(HF LINK/TEL)		X	X	X			Passcode clear
HONDA	USA	1996-2014	All	All	All	IMMOBI							1.Add one key 2.Rewrite keys 3.All keys lost 4.Add Keys 5.Delete Keys 6.Replace ECM/PCM

Basic Function

Automaker	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations
HONDA	CANADA	1996-2014	All	All	All	PGM FI		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	AT		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	ABS TCS VSA		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	SRS		X	X	X	X	X

Mark X	Description Function is supported.											
HONDA	CANADA	1996-2014	All	All	All	EPS		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	DCT(Dual Clutch Transmission)		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	SBW		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	OPDS(Occupant Position Detection System)		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	SWS(Seat Weight Sensor)		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	E-Pretensioner		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	ACM(Active Control Mount)		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	MANAGEMENT ECU		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	HEV BATTERY		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	HEV MOTOR GEN		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	HEV MOTOR TRC		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	EV BATTERY		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	EV MOTOR		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	Drive Motor Control Module		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	Fuel Cell Power Plant System		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	AIMA		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	Twin Motor Unit Left		X	X	X	X	

Mark X	Description Function is supported.											
HONDA	CANADA	1996-2014	All	All	All	Twin Motor Unit Right		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	METER		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	DBW (NSX)		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	Electric Servo Brake System		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	City-Brake Active system		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	Head Up Display		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	FCW/LDW		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	Real Time AWD/AWD with Intelligent Control		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	AVAS(Acoustic Vehicle Alerting System)		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	Precision All Wheel Steer		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	EDLC		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	BODY(Gauges)		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	BODY(Lighting)		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	BODY(Door Locks)		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	BODY(Keyless)		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	BODY(Power Windows)		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	BODY(Wiper)		X	X	X	X	X

Mark X	Description Function is supported.											
HONDA	CANADA	1996-2014	All	All	All	BODY(Security)		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	BODY(HVAC/Climate control)		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	BODY(Power Sliding Door)		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	BODY(Power Tailgate)		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	BODY(Auto Light Leveling)		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	BODY(Power Seat/Power Mirror)		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	BODY(Adaptive Front Lighting)		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	BODY(YOP Security)		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	BODY(YOP ECU)		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	BODY(Front Panel)		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	BODY(HF LINK/TEL)		X	X	X		
HONDA	CANADA	1996-2014	All	All	All	BODY(OnStar)		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	BODY(Power Trunk Lid)		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	BODY(YOP R/C ENG Starter)		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	BODY(Parking Sensor)		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	BODY(Auto AC Sub display)		X	X	X		
HONDA	CANADA	1996-2014	All	All	All	IMMOBI						

Mark X	Description Function is supported.											
HONDA	CANADA	1996-2014	All	All	All	IMA		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	TPMS		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	SH-AWD		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	SMART KEY		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	ONE-PUSH START		X	X	X	X	X
HONDA	CANADA	1996-2014	All	All	All	ATTS		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	VTM 4		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	BRAKE SYSTEM		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	Active Damper System		X	X	X	X	
HONDA	CANADA	1996-2014	All	All	All	SVT		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	PGM FI		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	AT		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	ABS TCS VSA		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	SRS		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	EPS		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	DCT(Dual Clutch Transmission)		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	SBW		X	X	X	X	

Mark X Description Function is supported.

HONDA	EUROPE	1996-2014	All	All	All	OPDS(Occupant Position Detection System)		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	SWS(Seat Weight Sensor)		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	E-Pretensioner		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	ACM(Active Control Mount)		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	MANAGEMENT ECU		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	HEV BATTERY		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	HEV MOTOR GEN		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	HEV MOTOR TRC		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	EV BATTERY		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	EV MOTOR		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	Drive Motor Control Module		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	Fuel Cell Power Plant System		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	AIMA		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	Twin Motor Unit Left		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	Twin Motor Unit Right		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	METER		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	DBW (NSX)		X	X	X	X	



Mark X	Description Function is supported.											
HONDA	EUROPE	1996-2014	All	All	All	Electric Servo Brake System		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	City-Brake Active system		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	Head Up Display		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	FCW/LDW		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	Real Time AWD/AWD with Intelligent Control		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	AVAS(Acoustic Vehicle Alerting System)		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	Precision All Wheel Steer		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	EDLC		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	BODY(Gauges)		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	BODY(Lighting)		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	BODY(Door Locks)		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	BODY(Keyless)		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	BODY(Power Windows)		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	BODY(Wiper)		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	BODY(Security)		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	BODY(HVAC/Climate control)		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	BODY(Power Sliding Door)		X	X	X	X	X

Mark X	Description Function is supported.											
HONDA	EUROPE	1996-2014	All	All	All	BODY(Power Tailgate)		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	BODY(Auto Light Leveling)		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	BODY(Power Seat/Power Mirror)		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	BODY(Adaptive Front Lighting)		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	BODY(YOP Security)		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	BODY(YOP ECU)		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	BODY(Front Panel)		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	BODY(HF LINK/TEL)		X	X	X		
HONDA	EUROPE	1996-2014	All	All	All	BODY(OnStar)		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	BODY(Power Trunk Lid)		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	BODY(YOP R/C ENG Starter)		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	BODY(Parking Sensor)		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	BODY(Auto AC Sub display)		X	X	X		
HONDA	EUROPE	1996-2014	All	All	All	IMMOBI						
HONDA	EUROPE	1996-2014	All	All	All	IMA		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	DIESEL		X	X	X	X	X
HONDA	EUROPE	1996-2014	All	All	All	SH-AWD		X	X	X	X	

Mark X	Description Function is supported.											
HONDA	EUROPE	1996-2014	All	All	All	4WS		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	ATTS		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	DRIVING SUPPORT		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	i-SHIFT		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	BRAKE SYSTEM		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	POP-UP HOOD		X	X	X	X	
HONDA	EUROPE	1996-2014	All	All	All	SVT		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	PGM FI		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	AT		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	ABS TCS VSA		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	SRS		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	EPS		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	DCT(Dual Clutch Transmission)		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	SBW		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	OPDS(Occupant Position Detection System)		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	SWS(Seat Weight Sensor)		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	E-Pretensioner		X	X	X	X	

Mark X	Description Function is supported.											
HONDA	GENERAL	1996-2014	All	All	All	ACM(Active Control Mount)		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	MANAGEMENT ECU		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	HEV BATTERY		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	HEV MOTOR GEN		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	HEV MOTOR TRC		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	EV BATTERY		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	EV MOTOR		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	Drive Motor Control Module		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	Fuel Cell Power Plant System		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	AIMA		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	Twin Motor Unit Left		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	Twin Motor Unit Right		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	METER		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	DBW (NSX)		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	Electric Servo Brake System		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	City-Brake Active system		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	Head Up Display		X	X	X	X	

Mark X	Description Function is supported.											
HONDA	GENERAL	1996-2014	All	All	All	FCW/LDW		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	Real Time AWD/AWD with Intelligent Control		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	AVAS(Acoustic Vehicle Alerting System)		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	Precision All Wheel Steer		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	EDLC		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	BODY(Gauges)		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	BODY(Lighting)		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	BODY(Door Locks)		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	BODY(Keyless)		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	BODY(Power Windows)		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	BODY(Wiper)		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	BODY(Security)		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	BODY(HVAC/Climate control)		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	BODY(Power Sliding Door)		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	BODY(Power Tailgate)		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	BODY(Auto Light Leveling)		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	BODY(Power Seat/Power Mirror)		X	X	X	X	X

Mark X	Description Function is supported.											
HONDA	GENERAL	1996-2014	All	All	All	BODY(Adaptive Front Lighting)		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	BODY(YOP Security)		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	BODY(YOP ECU)		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	BODY(Front Panel)		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	BODY(HF LINK/TEL)		X	X	X		
HONDA	GENERAL	1996-2014	All	All	All	BODY(OnStar)		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	BODY(Power Trunk Lid)		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	BODY(YOP R/C ENG Starter)		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	BODY(Parking Sensor)		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	BODY(Auto AC Sub display)		X	X	X		
HONDA	GENERAL	1996-2014	All	All	All	IMMOBI						
HONDA	GENERAL	1996-2014	All	All	All	IMA		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	DIESEL		X	X	X	X	X
HONDA	GENERAL	1996-2014	All	All	All	TPMS		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	SH-AWD		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	SMART KEY		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	ONE-PUSH START		X	X	X	X	X

Mark X	Description Function is supported.											
HONDA	GENERAL	1996-2014	All	All	All	4WS		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	ATTS		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	VTM 4		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	BRAKE SYSTEM		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	POP-UP HOOD		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	Active Damper System		X	X	X	X	
HONDA	GENERAL	1996-2014	All	All	All	SVT		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	PGM FI		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	AT		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	ABS TCS VSA		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	SRS		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	EPS		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	DCT(Dual Clutch Transmission)		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	SBW		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	OPDS(Occupant Position Detection System)		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	SWS(Seat Weight Sensor)		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	E-Pretensioner		X	X	X	X	

Mark X	Description Function is supported.											
HONDA	JAPAN	1996-2014	All	All	All	ACM(Active Control Mount)		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	MANAGEMENT ECU		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	HEV BATTERY		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	HEV MOTOR GEN		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	HEV MOTOR TRC		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	EV BATTERY		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	EV MOTOR		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	Drive Motor Control Module		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	Fuel Cell Power Plant System		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	AIMA		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	Twin Motor Unit Left		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	Twin Motor Unit Right		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	METER		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	DBW (NSX)		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	Electric Servo Brake System		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	City-Brake Active system		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	Head Up Display		X	X	X	X	



Mark X	Description Function is supported.											
HONDA	JAPAN	1996-2014	All	All	All	FCW/LDW		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	Real Time AWD/AWD with Intelligent Control		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	AVAS(Acoustic Vehicle Alerting System)		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	Precision All Wheel Steer		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	EDLC		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	BODY(Gauges)		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	BODY(Lighting)		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	BODY(Door Locks)		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	BODY(Keyless)		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	BODY(Power Windows)		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	BODY(Wiper)		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	BODY(Security)		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	BODY(HVAC/Climate control)		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	BODY(Power Sliding Door)		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	BODY(Power Tailgate)		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	BODY(Auto Light Leveling)		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	BODY(Power Seat/Power Mirror)		X	X	X	X	X

Mark X	Description Function is supported.											
HONDA	JAPAN	1996-2014	All	All	All	BODY(Adaptive Front Lighting)		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	BODY(YOP Security)		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	BODY(YOP ECU)		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	BODY(Front Panel)		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	BODY(HF LINK/TEL)		X	X	X		
HONDA	JAPAN	1996-2014	All	All	All	BODY(OnStar)		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	BODY(Power Trunk Lid)		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	BODY(YOP R/C ENG Starter)		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	BODY(Parking Sensor)		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	BODY(Auto AC Sub display)		X	X	X		
HONDA	JAPAN	1996-2014	All	All	All	IMMOBI						
HONDA	JAPAN	1996-2014	All	All	All	IMA		X	X	X	X	X
HONDA	JAPAN	1996-2014	All	All	All	SH-AWD		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	SMART KEY		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	4WS		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	ATTS		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	VTM 4		X	X	X	X	

Mark X	Description Function is supported.											
HONDA	JAPAN	1996-2014	All	All	All	DRIVING SUPPORT		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	BRAKE SYSTEM		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	POP-UP HOOD		X	X	X	X	
HONDA	JAPAN	1996-2014	All	All	All	SVT		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	PGM FI		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	AT		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	ABS TCS VSA		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	SRS		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	EPS		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	DCT(Dual Clutch Transmission)		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	SBW		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	OPDS(Occupant Position Detection System)		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	SWS(Seat Weight Sensor)		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	E-Pretensioner		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	ACM(Active Control Mount)		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	MANAGEMENT ECU		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	HEV BATTERY		X	X	X	X	

Mark X	Description Function is supported.											
HONDA	USA	1996-2014	All	All	All	HEV MOTOR GEN		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	HEV MOTOR TRC		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	EV BATTERY		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	EV MOTOR		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	Drive Motor Control Module		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	Fuel Cell Power Plant System		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	AIMA		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	Twin Motor Unit Left		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	Twin Motor Unit Right		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	METER		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	DBW (NSX)		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	Electric Servo Brake System		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	City-Brake Active system		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	Head Up Display		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	FCW/LDW		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	Real Time AWD/AWD with Intelligent Control		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	AVAS(Acoustic Vehicle Alerting System)		X	X	X	X	

Mark X	Description Function is supported.											
HONDA	USA	1996-2014	All	All	All	Precision All Wheel Steer		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	EDLC		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	BODY(Gauges)		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	BODY(Lighting)		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	BODY(Door Locks)		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	BODY(Keyless)		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	BODY(Power Windows)		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	BODY(Wiper)		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	BODY(Security)		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	BODY(HVAC/Climate control)		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	BODY(Power Sliding Door)		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	BODY(Power Tailgate)		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	BODY(Auto Light Leveling)		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	BODY(Power Seat/Power Mirror)		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	BODY(Adaptive Front Lighting)		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	BODY(YOP Security)		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	BODY(YOP ECU)		X	X	X	X	

Mark X	Description Function is supported.											
HONDA	USA	1996-2014	All	All	All	BODY(Front Panel)		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	BODY(HF LINK/TEL)		X	X	X		
HONDA	USA	1996-2014	All	All	All	BODY(OnStar)		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	BODY(Power Trunk Lid)		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	BODY(YOP R/C ENG Starter)		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	BODY(Parking Sensor)		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	BODY(Auto AC Sub display)		X	X	X		
HONDA	USA	1996-2014	All	All	All	IMMOBI						
HONDA	USA	1996-2014	All	All	All	IMA		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	TPMS		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	SH-AWD		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	SMART KEY		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	ONE-PUSH START		X	X	X	X	X
HONDA	USA	1996-2014	All	All	All	ATTS		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	VTM 4		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	BRAKE SYSTEM		X	X	X	X	
HONDA	USA	1996-2014	All	All	All	Active Damper System		X	X	X	X	

Mark  
X Description  
Function is supported.

HONDA	USA	1996-2014	All	All	All	SVT		X	X	X	X	
-------	-----	-----------	-----	-----	-----	-----	--	---	---	---	---	--