

Mark
X Description
Function is supported.

Special Function

Automaker	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuation	Special Functions
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-TC Bosch	Powertrain		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.5L 4JK1-TC	Powertrain		X	X	X	X	X	X 1.Injector ID Code X 2.ID Code Registration
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.0L 4JJ1-TC	Powertrain		X	X	X	X	X	X 1.Injector ID Code X 2.ID Code Registration X 3.Lock ECU
ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		4JH1-TC Bosch	Engine		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-TC Bosch	Powertrain		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.5L 4JK1-TC	Powertrain		X	X	X	X	X	X 1.Injector ID Code X 2.ID Code Registration
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.0L 4JJ1-TC	Powertrain		X	X	X	X	X	X 1.Injector ID Code X 2.ID Code Registration X 3.Lock ECU
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4JH1-TC Bosch	Engine		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-TC Bosch	Powertrain		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-T Denso	Powertrain		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(4) 2004	(N*) ELF, NPR, NQR,VFR		4JH1-TC Bosch	Engine		X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(3) 2003	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain		X	X	X	X	X	* 1.Read/Store Trim Data

Mark X Description Function is supported.

													*2.Programming Trim Data *3.Reset Immobiliser Function	
ISUZU		(3) 2003	(UE) Rodeo/Amigo, Wizard/MU		3.0L L4 4JX1	Powertrain			X	X	X	X	X	* 1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-TC Bosch	Powertrain			X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-T Denso	Powertrain			X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(3) 2003	(N*) ELF, NPR, NQR,VFR		4JH1-TC Bosch	Engine			X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(2) 2002	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain			X	X	X	X	X	* 1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(2) 2002	(UE) Rodeo/Amigo, Wizard/MU		3.0L L4 4JX1	Powertrain			X	X	X	X	X	* 1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-TC Bosch	Powertrain			X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-T Denso	Powertrain			X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(2) 2002	TF/UC Thailand		4JH1-T Denso	Powertrain			X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(2) 2002	(N*) ELF, NPR, NQR,VFR		4JH1-TC Bosch	Engine			X	X	X	X	X	X 1.Program VIN X 2.Lock ECU
ISUZU		(1) 2001	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain			X	X	X	X	X	* 1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(1) 2001	(UE) Rodeo/Amigo, Wizard/MU		3.0L L4 4JX1	Powertrain			X	X	X	X	X	*1.Read/Store Trim Data

Mark
X Description
Function is supported.

														*2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(1) 2001	(UE) Rodeo/Amigo, Wizard/MU		4L30E	Powertrain		X	X	X				
ISUZU		(1) 2001	TF/UC Thailand		4JH1-T Denso	Powertrain		X	X	X	X	X		X 1.Program VIN X 2.Lock ECU
ISUZU		(1) 2001	(TF) LUV		4JH1-TC Bosch	Powertrain		X	X	X	X	X		X 1.Program VIN X 2.Lock ECU
ISUZU		(1) 2001	(N*) ELF, NPR, NQR,VFR		4JH1-TC Bosch	Engine		X	X	X	X	X		X 1.Program VIN X 2.Lock ECU
ISUZU		(Y) 2000	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain		X	X	X	X	X		* 1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU		3.0L L4 4JX1	Powertrain		X	X	X	X	X		*1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(X) 1999	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain		X	X	X	X	X		* 1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(X) 1999	(UE) Rodeo/Amigo, Wizard/MU		3.0L L4 4JX1	Powertrain		X	X	X	X	X		*1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(W) 1998	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain		X	X	X	X	X		*1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function
ISUZU		(W) 1998	(UE) Rodeo/Amigo, Wizard/MU		3.0L L4 4JX1	Powertrain		X	X	X	X	X		*1.Read/Store Trim Data *2.Programming Trim Data *3.Reset Immobiliser Function

Mark
X Description
Function is supported.

Basic Function

Automaker	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations
ISUZU		(A) 2010	N TRUCK		4JJ1-TC(C/Rail)	Powertrain		X	X	X	X	
ISUZU		(A) 2010	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.5 4JK1-TC (TransTron)	Powertrain		X	X	X	X	X
ISUZU		(A) 2010	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.0L 4JJ1-TC (TransTron)	Powertrain		X	X	X	X	X
ISUZU		(A) 2010	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		V6 Engine	Powertrain		X	X	X	X	X
ISUZU		(A) 2010	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X
ISUZU		(9) 2009	N TRUCK		4JJ1-TC(C/Rail)	Powertrain		X	X	X	X	
ISUZU		(9) 2009	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.5 4JK1-TC (TransTron)	Powertrain		X	X	X	X	X
ISUZU		(9) 2009	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.0L 4JJ1-TC (TransTron)	Powertrain		X	X	X	X	X
ISUZU		(9) 2009	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		V6 Engine	Powertrain		X	X	X	X	X
ISUZU		(9) 2009	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X
ISUZU		(8) 2008	N TRUCK		4JJ1-TC(C/Rail)	Powertrain		X	X	X	X	
ISUZU		(8) 2008	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.5 4JK1-TC (TransTron)	Powertrain		X	X	X	X	X
ISUZU		(8) 2008	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.0L 4JJ1-TC (TransTron)	Powertrain		X	X	X	X	X
ISUZU		(8) 2008	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		V6 Engine	Powertrain		X	X	X	X	X
ISUZU		(8) 2008	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X
ISUZU		(7) 2007	N TRUCK		4JJ1-TC(C/Rail)	Powertrain		X	X	X	X	

Mark
X Description
Function is supported.

ISUZU		(7) 2007	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		V6 Engine	Powertrain		X	X	X	X	X
ISUZU		(7) 2007	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-TC Bosch	Powertrain		X	X	X	X	X
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JA1-TC Bosch	Powertrain		X	X	X		
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.XL L4 HV240	Powertrain		X	X	X	X	X
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.5L 4JK1-TC	Powertrain		X	X	X	X	X
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.0L 4JJ1-TC	Powertrain		X	X	X	X	X
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.5L V6 6VE1 Hitachi	Powertrain		X	X	X	X	X
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AT JR405E	Powertrain		X	X	X	X	X
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AW30-40LE	Powertrain		X	X	X		
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Immobiliser		X	X	X		
ISUZU		(6) 2006	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Airbag		X	X	X	X	
ISUZU		(6) 2006	(N*) ELF, NPR, NQR, VFR		4JH1-TC Bosch	Engine		X	X	X	X	X
ISUZU		(6) 2006	(N*) ELF, NPR, NQR, VFR		4HV1(CNG)	Engine		X	X	X	X	X
ISUZU		(6) 2006	(N*) ELF, NPR, NQR, VFR		4HK1-TC (C/Rail)	Engine		X	X	X		
ISUZU		(6) 2006	(N*) ELF, NPR, NQR, VFR		4HL1-TC (C/Rail)	Engine		X	X	X		
ISUZU		(6) 2006	(N*) ELF, NPR, NQR, VFR		4HL1-NA (C/Rail)	Engine		X	X	X		

Mark
X Description
Function is supported.

ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		MIMAMORI	Engine		X	X	X		
ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		Hybrid System	Engine		X	X	X		
ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		Transmission	Smoother-E		X	X	X		
ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		Transmission	Smoother / Smoother-E Auto Shift		X	X	X		
ISUZU		(6) 2006	(N*) ELF, NPR, NQR,VFR		Chassis	ABS / ASR		X	X	X		
ISUZU		(6) 2006	(Off-Road) Industrial Engine		4JJ1-TC (C/Rail_TIER3)	Engine		X	X	X		
ISUZU		(6) 2006	(Off-Road) Industrial Engine		4HK1-TC (C/Rail_TIER3)	Engine		X	X	X		
ISUZU		(6) 2006	(Off-Road) Industrial Engine		6HK1-TC (C/Rail_TIER3)	Engine		X	X	X		
ISUZU		(6) 2006	(Off-Road) Industrial Engine		6UZ1-TC (C/Rail_TIER3)	Engine		X	X	X		
ISUZU		(6) 2006	(Off-Road) Industrial Engine		6WG1-TC (C/Rail_TIER3)	Engine		X	X	X		
ISUZU		(6) 2006	I-280			PCM(Automatic)			X	X	X	
ISUZU		(6) 2006	I-280			PCM(Manual)			X	X	X	
ISUZU		(6) 2006	I-280			ABS(With Traction Control System)			X	X	X	
ISUZU		(6) 2006	I-280			ABS(Without Traction Control System)			X	X	X	
ISUZU		(6) 2006	I-280			AIRBAG			X	X	X	
ISUZU		(6) 2006	I-280			BASE RADIO			X	X	X	
ISUZU		(6) 2006	I-280			BODY CONTROL MODULE			X	X	X	
ISUZU		(6) 2006	I-280			DIGITAL RADIO(GEN 2)			X	X	X	

Mark
X Description
Function is supported.

ISUZU	(6) 2006	I-280			DIGITAL RADIO(GEN 3)			X	X	X	
ISUZU	(6) 2006	I-280			INSTRUMENT PANEL CLUSTER			X	X	X	
ISUZU	(6) 2006	I-280			UPLEVEL RADIO			X	X	X	
ISUZU	(6) 2006	I-280			VEHICLE COMM INTERFACE MODULE(GPS)			X	X	X	
ISUZU	(6) 2006	I-280			VEHICLE COMM INTERFACE MODULE(SIG STR)			X	X	X	
ISUZU	(6) 2006	I-350			PCM(Automatic)			X	X	X	
ISUZU	(6) 2006	I-350			PCM(Manual)			X	X	X	
ISUZU	(6) 2006	I-350			ABS(With Traction Control System)			X	X	X	
ISUZU	(6) 2006	I-350			ABS(Without Traction Control System)			X	X	X	
ISUZU	(6) 2006	I-350			AIRBAG			X	X	X	
ISUZU	(6) 2006	I-350			BASE RADIO			X	X	X	
ISUZU	(6) 2006	I-350			BODY CONTROL MODULE			X	X	X	
ISUZU	(6) 2006	I-350			DIGITAL RADIO(GEN 2)			X	X	X	
ISUZU	(6) 2006	I-350			DIGITAL RADIO(GEN 3)			X	X	X	
ISUZU	(6) 2006	I-350			INSTRUMENT PANEL CLUSTER			X	X	X	
ISUZU	(6) 2006	I-350			UPLEVEL RADIO			X	X	X	
ISUZU	(6) 2006	I-350			VEHICLE COMM INTERFACE			X	X	X	

Mark
X Description
Function is supported.

						MODULE(GPS)							
ISUZU		(6) 2006	I-350			VEHICLE COMM INTERFACE MODULE(SIG STR)			X	X	X		
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-TC Bosch	Powertrain		X	X	X	X	X	
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JA1-TC Bosch	Powertrain		X	X	X			
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.XL L4 HV240	Powertrain		X	X	X	X	X	
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.5L 4JK1-TC	Powertrain		X	X	X	X	X	
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.0L 4JJ1-TC	Powertrain		X	X	X	X	X	
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.5L V6 6VE1 Hitachi	Powertrain		X	X	X	X	X	
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AT JR405E	Powertrain		X	X	X	X	X	
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AW30-40LE	Powertrain		X	X	X			
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X	
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Immobiliser		X	X	X			
ISUZU		(5) 2005	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Airbag		X	X	X	X		
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4JH1-TC Bosch	Engine		X	X	X	X	X	
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4JG2	Engine			X	X	X	X	
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4HG1(LPG)	Engine		X	X	X	X	X	
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4JG2(LPG)	Engine		X	X	X	X	X	

Mark
X Description
Function is supported.

ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4HV1(CNG)	Engine		X	X	X	X	X
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4HK1-TC (C/Rail)	Engine		X	X	X		
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4HL1-TC (C/Rail)	Engine		X	X	X		
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		4HL1-NA (C/Rail)	Engine		X	X	X		
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		MIMAMORI	Engine		X	X	X		
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		Hybrid System	Engine		X	X	X		
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		Transmission	Smoother-E		X	X	X		
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		Transmission	Smoother / Smoother-E Auto Shift		X	X	X		
ISUZU		(5) 2005	(N*) ELF, NPR, NQR,VFR		Chassis	ABS / ASR		X	X	X		
ISUZU		(5) 2005	(Off-Road) Industrial Engine		4JJ1-TC (C/Rail_TIER3)	Engine		X				
ISUZU		(5) 2005	(Off-Road) Industrial Engine		4HK1-TC (C/Rail_TIER3)	Engine		X	X	X		
ISUZU		(5) 2005	(Off-Road) Industrial Engine		6HK1-TC (C/Rail_TIER3)	Engine		X	X	X		
ISUZU		(5) 2005	(Off-Road) Industrial Engine		6UZ1-TC (C/Rail_TIER3)	Engine		X	X	X		
ISUZU		(5) 2005	(Off-Road) Industrial Engine		6WG1-TC (C/Rail_TIER3)	Engine		X	X	X		
ISUZU		(4) 2004	(UE) Rodeo/Amigo, Wizard/MU		3.2L V6 6VD1	Powertrain		X	X	X		
ISUZU		(4) 2004	(UE) Rodeo/Amigo, Wizard/MU		3.5L V6 6VE1 Hitachi	Powertrain		X	X	X		
ISUZU		(4) 2004	(UE) Rodeo/Amigo, Wizard/MU		Chassis	TPMS (Tire Pressure Monitoring System)		X	X	X	X	X

Mark
X Description
Function is supported.

ISUZU		(4) 2004	(UE) Rodeo/Amigo, Wizard/MU		Chassis	ABS		X	X	X	X	
ISUZU		(4) 2004	(UE) Rodeo/Amigo, Wizard/MU		Body	Immobiliser		X	X	X		
ISUZU		(4) 2004	(UP) Axiom		3.5L V6 6VE1 Hitachi	Powertrain		X	X	X		
ISUZU		(4) 2004	(UP) Axiom		Chassis	ABS		X	X	X	X	
ISUZU		(4) 2004	(UP) Axiom		Body	Immobiliser		X	X	X		
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-TC Bosch	Powertrain		X	X	X	X	X
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-T Denso	Powertrain		X	X	X	X	X
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JA1-TC Bosch	Powertrain		X	X	X		
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.XL L4 HV240	Powertrain		X	X	X	X	X
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.5L V6 6VE1 Hitachi	Powertrain		X	X	X	X	X
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AT JR405E	Powertrain		X	X	X	X	X
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AW30-40LE	Powertrain		X	X	X		
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Immobiliser		X	X	X		
ISUZU		(4) 2004	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Airbag		X	X	X	X	
ISUZU		(4) 2004	(N*) ELF, NPR, NQR, VFR		4JH1-TC Bosch	Engine		X	X	X	X	X
ISUZU		(4) 2004	(N*) ELF, NPR, NQR, VFR		4JG2	Engine			X	X	X	X
ISUZU		(4) 2004	(N*) ELF, NPR, NQR, VFR		4HF1(CNG)	Engine		X	X	X	X	X

Mark
X Description
Function is supported.

ISUZU		(4) 2004	(N*) ELF, NPR, NQR, VFR		4HG1(LPG)	Engine		X	X	X	X	X
ISUZU		(4) 2004	(N*) ELF, NPR, NQR, VFR		4JG2(LPG)	Engine		X	X	X	X	X
ISUZU		(4) 2004	(N*) ELF, NPR, NQR, VFR		4HL1-TC (C/Rail)	Engine		X	X	X		
ISUZU		(4) 2004	(N*) ELF, NPR, NQR, VFR		4HL1-NA (C/Rail)	Engine		X	X	X		
ISUZU		(4) 2004	(N*) ELF, NPR, NQR, VFR		MIMAMORI	Engine		X	X	X		
ISUZU		(4) 2004	(N*) ELF, NPR, NQR, VFR		Hybrid System	Engine		X	X	X		
ISUZU		(4) 2004	(N*) ELF, NPR, NQR, VFR		Chassis	ABS / ASR		X	X	X		
ISUZU		(3) 2003	(UB) Trooper, Bighorn, Jackaroo		3.2L V6 6VD1	Powertrain		X	X	X		
ISUZU		(3) 2003	(UB) Trooper, Bighorn, Jackaroo		3.5L V6 6VE1	Powertrain		X	X	X		
ISUZU		(3) 2003	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain		X	X	X	X	X
ISUZU		(3) 2003	(UB) Trooper, Bighorn, Jackaroo		4L30E	Powertrain		X	X	X		
ISUZU		(3) 2003	(UB) Trooper, Bighorn, Jackaroo		Body	Immobiliser		X	X	X		
ISUZU		(3) 2003	(UB) Trooper, Bighorn, Jackaroo		Body	Immobiliser (DDS)		X	X	X		
ISUZU		(3) 2003	(UE) Rodeo/Amigo, Wizard/MU		2.2L L4 X22SE	Powertrain		X	X	X	X	X
ISUZU		(3) 2003	(UE) Rodeo/Amigo, Wizard/MU		3.2L V6 6VD1	Powertrain		X	X	X		
ISUZU		(3) 2003	(UE) Rodeo/Amigo, Wizard/MU		3.0L L4 4JX1	Powertrain		X	X	X	X	X
ISUZU		(3) 2003	(UE) Rodeo/Amigo, Wizard/MU		4L30E	Powertrain		X	X	X		
ISUZU		(3) 2003	(UE) Rodeo/Amigo, Wizard/MU		Body	Immobiliser		X	X	X		

Mark
X Description
Function is supported.

ISUZU		(3) 2003	(UP) Axiom		3.5L V6 6VE1	Powertrain		X	X	X		
ISUZU		(3) 2003	(UP) Axiom		4L30E	Powertrain		X	X	X		
ISUZU		(3) 2003	(UP) Axiom		Chassis	ABS		X	X	X	X	
ISUZU		(3) 2003	(UP) Axiom		Body	Immobiliser		X	X	X		
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-TC Bosch	Powertrain		X	X	X	X	X
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-T Denso	Powertrain		X	X	X	X	X
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JA1-TC Bosch	Powertrain		X				
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		2.XL L4 SOHC	Powertrain		X	X	X	X	X
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.5L V6 6VE1 Hitachi	Powertrain		X	X	X	X	X
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AT JR405E	Powertrain		X	X	X	X	X
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AW30-40LE	Powertrain		X	X	X		
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Chassis	ABS		X	X	X	X	X
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Immobiliser		X	X	X		
ISUZU		(3) 2003	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		Body	Airbag		X	X	X	X	
ISUZU		(3) 2003	(TBR).		2.XL L4 HV240	Powertrain		X	X	X	X	X
ISUZU		(3) 2003	(N*) ELF, NPR, NQR, VFR		4JH1-TC Bosch	Engine		X	X	X	X	X
ISUZU		(3) 2003	(N*) ELF, NPR, NQR, VFR		4HL1/4HJ1(COMMON R	Engine		X	X	X		
ISUZU		(3) 2003	(N*) ELF, NPR, NQR, VFR		4HL1/4HJ1(Vehicle Interf	Engine		X	X	X		

Mark
X Description
Function is supported.

ISUZU		(3) 2003	(N*) ELF, NPR, NQR, VFR		4JG2	Engine			X	X	X	X
ISUZU		(3) 2003	(N*) ELF, NPR, NQR, VFR		Chassis	ABS / ASR		X	X	X		
ISUZU		(2) 2002	(UB) Trooper, Bighorn, Jackaroo		3.2L V6 6VD1	Powertrain		X	X	X		
ISUZU		(2) 2002	(UB) Trooper, Bighorn, Jackaroo		3.5L V6 6VE1	Powertrain		X	X	X		
ISUZU		(2) 2002	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain		X	X	X	X	X
ISUZU		(2) 2002	(UB) Trooper, Bighorn, Jackaroo		4L30E	Powertrain		X	X	X		
ISUZU		(2) 2002	(UB) Trooper, Bighorn, Jackaroo		Body	Immobiliser		X	X	X		
ISUZU		(2) 2002	(UB) Trooper, Bighorn, Jackaroo		Body	Immobiliser (DDS)		X	X	X		
ISUZU		(2) 2002	(UE) Rodeo/Amigo, Wizard/MU		2.2L L4 X22SE	Powertrain		X	X	X	X	X
ISUZU		(2) 2002	(UE) Rodeo/Amigo, Wizard/MU		3.2L V6 6VD1	Powertrain		X	X	X		
ISUZU		(2) 2002	(UE) Rodeo/Amigo, Wizard/MU		3.0L L4 4JX1	Powertrain		X	X	X	X	X
ISUZU		(2) 2002	(UE) Rodeo/Amigo, Wizard/MU		4L30E	Powertrain		X	X	X		
ISUZU		(2) 2002	(UE) Rodeo/Amigo, Wizard/MU		Chassis	ABS		X	X	X	X	
ISUZU		(2) 2002	(UE) Rodeo/Amigo, Wizard/MU		Body	Immobiliser		X	X	X		
ISUZU		(2) 2002	(UP) Axiom		3.5L V6 6VE1	Powertrain		X	X	X		
ISUZU		(2) 2002	(UP) Axiom		4L30E	Powertrain		X	X	X		
ISUZU		(2) 2002	(UP) Axiom		Chassis	ABS		X	X	X	X	
ISUZU		(2) 2002	(TF/UC) LUV, Rodeo/Frontier, LAO-Rodeo		4JH1-TC Bosch	Powertrain		X	X	X	X	X

Mark
X Description
Function is supported.

ISUZU		(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JH1-T Denso	Powertrain		X	X	X	X	X
ISUZU		(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		4JA1-TC Bosch	Powertrain		X				
ISUZU		(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X
ISUZU		(2) 2002	(TF/UC) LUV,Rodeo/Frontier,LAO-Rodeo		AT JR405E	Powertrain		X	X	X	X	X
ISUZU		(2) 2002	TF/UC Thailand		4JH1-T Denso	Powertrain		X	X	X	X	X
ISUZU		(2) 2002	(TBR).		2.2L L4 HV240	Powertrain		X	X	X		
ISUZU		(2) 2002	(N*) ELF, NPR, NQR,VFR		4JH1-TC Bosch	Engine		X	X	X	X	X
ISUZU		(2) 2002	(N*) ELF, NPR, NQR,VFR		4HL1/4HJ1(COMMON R	Engine		X	X	X		
ISUZU		(2) 2002	(N*) ELF, NPR, NQR,VFR		4HL1/4HJ1(Vehicle Interf	Engine		X	X	X		
ISUZU		(2) 2002	(N*) ELF, NPR, NQR,VFR		Chassis	ABS / ASR		X	X	X		
ISUZU		(1) 2001	(UB) Trooper, Bighorn, Jackaroo		3.2L V6 6VD1	Powertrain		X	X	X		
ISUZU		(1) 2001	(UB) Trooper, Bighorn, Jackaroo		3.5L V6 6VE1	Powertrain		X	X	X		
ISUZU		(1) 2001	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain		X	X	X	X	X
ISUZU		(1) 2001	(UB) Trooper, Bighorn, Jackaroo		4L30E	Powertrain		X	X	X		
ISUZU		(1) 2001	(UB) Trooper, Bighorn, Jackaroo		Body	Immobiliser		X	X	X		
ISUZU		(1) 2001	(UB) Trooper, Bighorn, Jackaroo		Body	Immobiliser (DDS)		X	X	X		
ISUZU		(1) 2001	(UE) Rodeo/Amigo, Wizard/MU		2.2L L4 X22SE	Powertrain		X	X	X	X	X
ISUZU		(1) 2001	(UE) Rodeo/Amigo, Wizard/MU		3.2L V6 6VD1	Powertrain		X	X	X		

Mark
X Description
Function is supported.

ISUZU		(1) 2001	(UE) Rodeo/Amigo, Wizard/MU		3.0L L4 4JX1	Powertrain		X	X	X	X	X
ISUZU		(1) 2001	(UE) Rodeo/Amigo, Wizard/MU		4L30E	Powertrain		X	X	X		
ISUZU		(1) 2001	(UE) Rodeo/Amigo, Wizard/MU		Chassis	ABS		X	X	X	X	
ISUZU		(1) 2001	(UE) Rodeo/Amigo, Wizard/MU		Body	Immobiliser		X	X	X		
ISUZU		(1) 2001	(UG) V-Cross		3.2L V6 6VD1	Powertrain		X	X	X	X	X
ISUZU		(1) 2001	(UG) V-Cross		3.5L V6 6VE1	Powertrain		X	X	X	X	X
ISUZU		(1) 2001	(UG) V-Cross		4L30E	Powertrain		X	X	X	X	X
ISUZU		(1) 2001	(UC) Frontier, LAO-Rodeo		3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X
ISUZU		(1) 2001	TF/UC Thailand		4JH1-T Denso	Powertrain		X	X	X	X	X
ISUZU		(1) 2001	(TF) LUV		4JH1-TC Bosch	Powertrain		X	X	X	X	X
ISUZU		(1) 2001	(TF) LUV		4JA1-TC Bosch	Powertrain		X	X	X		
ISUZU		(1) 2001	(TF) LUV		3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X
ISUZU		(1) 2001	(TF) LUV		Body	Immobiliser		X	X	X		
ISUZU		(1) 2001	(N*) ELF, NPR, NQR, VFR		4JH1-TC Bosch	Engine		X	X	X	X	X
ISUZU		(1) 2001	(N*) ELF, NPR, NQR, VFR		Chassis	ABS / ASR		X	X	X		
ISUZU		(Y) 2000	(UB) Trooper, Bighorn, Jackaroo		3.2L V6 6VD1	Powertrain		X	X	X		
ISUZU		(Y) 2000	(UB) Trooper, Bighorn, Jackaroo		3.5L V6 6VE1	Powertrain		X	X	X		
ISUZU		(Y) 2000	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain		X	X	X	X	X

Mark
X Description
Function is supported.

ISUZU		(Y) 2000	(UB) Trooper, Bighorn, Jackaroo		4L30E	Powertrain		X	X	X		
ISUZU		(Y) 2000	(UB) Trooper, Bighorn, Jackaroo		Body	Immobiliser		X	X	X		
ISUZU		(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU		2.2L L4 X22SE	Powertrain		X	X	X	X	X
ISUZU		(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU		3.2L V6 6VD1	Powertrain		X	X	X		
ISUZU		(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU		3.0L L4 4JX1	Powertrain		X	X	X	X	X
ISUZU		(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU		4L30E	Powertrain		X	X	X		
ISUZU		(Y) 2000	(UE) Rodeo/Amigo, Wizard/MU		Chassis	ABS		X	X	X	X	
ISUZU		(Y) 2000	(UG) V-Cross		3.2L V6 6VD1	Powertrain		X	X	X	X	X
ISUZU		(Y) 2000	(UG) V-Cross		3.5L V6 6VE1	Powertrain		X	X	X	X	X
ISUZU		(Y) 2000	(UG) V-Cross		4L30E	Powertrain		X	X	X	X	X
ISUZU		(Y) 2000	(UC) Frontier, LAO-Rodeo		3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X
ISUZU		(Y) 2000	(UC) Frontier, LAO-Rodeo		Body	Immobiliser		X	X	X		
ISUZU		(Y) 2000	(TF) LUV		3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X
ISUZU		(X) 1999	(UB) Trooper, Bighorn, Jackaroo		3.2L V6 6VD1	Powertrain		X	X	X	X	X
ISUZU		(X) 1999	(UB) Trooper, Bighorn, Jackaroo		3.5L V6 6VE1	Powertrain		X	X	X	X	X
ISUZU		(X) 1999	(UB) Trooper, Bighorn, Jackaroo		3.0L L4 4JX1	Powertrain		X	X	X	X	X
ISUZU		(X) 1999	(UB) Trooper, Bighorn, Jackaroo		4L30E	Powertrain		X	X	X	X	X
ISUZU		(X) 1999	(UB) Trooper, Bighorn, Jackaroo		Body	Immobiliser		X	X	X		

Mark
X Description
Function is supported.

ISUZU	(X) 1999	(UE) Rodeo/Amigo, Wizard/MU	2.2L L4 X22SE	Powertrain	X	X	X	X	X
ISUZU	(X) 1999	(UE) Rodeo/Amigo, Wizard/MU	3.2L V6 6VD1	Powertrain	X	X	X	X	X
ISUZU	(X) 1999	(UE) Rodeo/Amigo, Wizard/MU	3.0L L4 4JX1	Powertrain	X	X	X	X	X
ISUZU	(X) 1999	(UE) Rodeo/Amigo, Wizard/MU	4L30E	Powertrain	X	X	X	X	X
ISUZU	(X) 1999	(UE) Rodeo/Amigo, Wizard/MU	Chassis	ABS	X	X	X	X	
ISUZU	(X) 1999	(UG) V-Cross	3.2L V6 6VD1	Powertrain	X	X	X	X	X
ISUZU	(X) 1999	(UG) V-Cross	3.5L V6 6VE1	Powertrain	X	X	X	X	X
ISUZU	(X) 1999	(UG) V-Cross	4L30E	Powertrain	X	X	X	X	X
ISUZU	(X) 1999	(UC) Frontier, LAO-Rodeo	3.2L V6 6VD1 Hitachi	Powertrain	X	X	X	X	X
ISUZU	(X) 1999	(TF) LUV	3.2L V6 6VD1 Hitachi	Powertrain	X	X	X	X	X
ISUZU	(W) 1998	(UB) Trooper, Bighorn, Jackaroo	3.2L V6 6VD1	Powertrain	X	X	X	X	X
ISUZU	(W) 1998	(UB) Trooper, Bighorn, Jackaroo	3.5L V6 6VE1	Powertrain	X	X	X	X	X
ISUZU	(W) 1998	(UB) Trooper, Bighorn, Jackaroo	3.0L L4 4JX1	Powertrain	X	X	X	X	X
ISUZU	(W) 1998	(UB) Trooper, Bighorn, Jackaroo	4L30E	Powertrain	X	X	X	X	X
ISUZU	(W) 1998	(UB) Trooper, Bighorn, Jackaroo	Body	Immobiliser	X	X	X		
ISUZU	(W) 1998	(UE) Rodeo/Amigo, Wizard/MU	2.2L L4 X22SE	Powertrain	X	X	X	X	X
ISUZU	(W) 1998	(UE) Rodeo/Amigo, Wizard/MU	3.2L V6 6VD1	Powertrain	X	X	X	X	X
ISUZU	(W) 1998	(UE) Rodeo/Amigo, Wizard/MU	3.0L L4 4JX1	Powertrain	X	X	X	X	X

Mark
X Description
Function is supported.

ISUZU		(W) 1998	(UE) Rodeo/Amigo, Wizard/MU		4L30E	Powertrain		X	X	X	X	X
ISUZU		(W) 1998	(UE) Rodeo/Amigo, Wizard/MU		Chassis	ABS		X	X	X	X	
ISUZU		(W) 1998	(UC) Frontier, LAO-Rodeo		3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X
ISUZU		(W) 1998	(TF) LUV		3.2L V6 6VD1 Hitachi	Powertrain		X	X	X	X	X
ISUZU		(W) 1998	(TF) LUV		2.2L L4 SOHC	Powertrain		X	X	X	X	X
ISUZU		(B) 2012	D-MAX		4JK1-TC/TCX14	Engine		X	X	X	X	
ISUZU		(B) 2012	D-MAX		4JJ1-TCX14	Engine		X	X	X	X	
ISUZU		(B) 2012	D-MAX		4JK1-TC/TCX15	Transmission		X	X	X	X	
ISUZU		(B) 2012	D-MAX		4JJ1-TCX15	Transmission		X	X	X	X	
ISUZU		(B) 2013	D-MAX		4JK1-TC/TCX14	Engine		X	X	X	X	
ISUZU		(B) 2013	D-MAX		4JJ1-TCX14	Engine		X	X	X	X	
ISUZU		(B) 2013	D-MAX		4JK1-TC/TCX15	Transmission		X	X	X	X	
ISUZU		(B) 2013	D-MAX		4JJ1-TCX15	Transmission		X	X	X	X	
ISUZU		(B) 2014	D-MAX		4JK1-TC/TCX14	Engine		X	X	X	X	
ISUZU		(B) 2014	D-MAX		4JJ1-TCX14	Engine		X	X	X	X	
ISUZU		(B) 2014	D-MAX		4JK1-TC/TCX15	Transmission		X	X	X	X	
ISUZU		(B) 2014	D-MAX		4JJ1-TCX15	Transmission		X	X	X	X	
ISUZU		(B) 2015	D-MAX		4JK1-TC/TCX14	Engine		X	X	X	X	

Mark
X Description
Function is supported.

ISUZU		(B) 2015	D-MAX		4JJ1-TCX14	Engine		X	X	X	X	
ISUZU		(B) 2015	D-MAX		4JK1-TC/TCX15	Transmission		X	X	X	X	
ISUZU		(B) 2015	D-MAX		4JJ1-TCX15	Transmission		X	X	X	X	